



MITSUBISHI

type A6GPP/A6PHP(SW1GP-GPPK)

Operating Manual



Mitsubishi Programmable Controller

● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in the manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual for a description of the PC system safety precautions.

These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".



DANGER

Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



CAUTION

Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]



DANGER

- When performing the data change, program change, and status control of the PC in operation from a peripheral device, configure an interlock circuit in a sequence program so the safety of the overall system is always maintained.
Also, determine the troubleshooting method when data communication error occurs between the external device and the PC CPU.

[STARTING AND MAINTENANCE PRECAUTIONS]



CAUTION

- Carefully read the manual and secure operational safety especially when remote access before performing online operations to a peripheral device connected to the CPU module in operation (especially modifying a program, performing forced output, or changing the operation status).
False operation may damage the equipment or may cause an accident.

REVISIONS

※The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Jan., 1989	IB (NA) 66192-A	First edition

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-A Series of General Purpose Programmable Controllers. Please read this manual carefully so that the equipment is used to its optimum. A copy of this manual should be forwarded to the end User.

CONTENTS

1. INTRODUCTION	1-1 ~ 1-5
1.1 Operations Available Using the SW1GP-GPPK Operating System	1-2
1.2 System Configuration	1-4
2. STARTING PROCEDURE	2-1 ~ 2-8
2.1 GPP/PHP Starting Procedure Flow Chart	2-1
2.2 Initial Data Setting Procedure	2-2
2.3 Automatic FD Write Mode Selecting Method	2-3
2.3.1 Automatic FD write mode setting procedure	2-4
2.3.2 Automatic FD write timing	2-5
2.3.3 System name clear timing	2-6
2.4 Parameter setting	2-6
2.5 Layout of Display	2-7
2.6 Adjustment of A6GPP Buzzer Volume	2-8
3. BASIC OPERATIONS FOR THE GPP/PHP	3-1 ~ 3-2
3.1 GPP/PHP Applications	3-1
3.1.1 Program creation	3-1
3.1.2 Program check	3-2
3.1.3 Program storage	3-2
3.1.4 Print-OUT	3-2
4. LADDER MODE	4-1 ~ 4-41
4.1 Ladder Mode Introduction	4-1
4.2 Ladder Mode Functions	4-2
4.3 Ladder Write	4-4
4.3.1 Creation of new ladder	4-4
4.3.2 Correction of existing ladder	4-11
4.3.3 Insertion and addition of ladder block	4-14
4.4 Ladder Read	4-15
4.4.1 Ladder read by step number	4-15
4.4.2 Ladder read by contact or coil number	4-17
4.4.3 Ladder read by I/O number	4-18
4.4.4 Ladder read by instruction	4-19
4.4.5 Reading the final ladder using "END" instruction	4-20
4.4.6 Read of ladder with comment	4-21
4.5 Insertion and Deletion of Ladder Blocks	4-22
4.5.1 Insertion and addition in units of ladder symbols	4-22
4.5.2 Deletion of one ladder block	4-24
4.5.3 Deletion in units of ladder symbols	4-26
4.6 Circuit Utilization	4-28
4.6.1 Entry of utilized circuit	4-29
4.6.2 Incorporating a utilized circuit into the program	4-31

4.7	Programmable Controller Ladder Monitor.....	4-32
4.7.1	Ladder monitor.....	4-33
4.7.2	Stop of monitor screen.....	4-35
4.7.3	Screen stop by setting of monitor stop point.....	4-36
4.7.4	Entry monitor.....	4-37
4.7.5	Present value monitor of decimal number ↔ hexadecimal number.....	4-38
4.8	Test Operation to Programmable Controller.....	4-39
4.8.1	Forcing programmable controller devices.....	4-39
4.8.2	K3NCPU step run.....	4-40
5.	LIST MODE.....	5-1 ~ 5-23
5.1	List Mode Introduction.....	5-1
5.2	List Mode Functions.....	5-2
5.3	Write of Program List.....	5-3
5.3.1	All clear of memory (Continuous write of NOP).....	5-3
5.3.2	Write of program list.....	5-4
5.4	Read of Program List.....	5-7
5.4.1	Read of list by step number.....	5-7
5.4.2	Read of list by device.....	5-8
5.4.3	Read of list by instruction.....	5-9
5.4.4	Read of list with comments.....	5-10
5.4.5	Read of device used list.....	5-11
5.4.6	Read of contact and coil list.....	5-13
5.4.7	Read of T/C setting value list.....	5-14
5.5	Insertion and Deletion of Program List.....	5-15
5.5.1	Insertion of program list.....	5-15
5.5.2	Deletion of program list.....	5-16
5.6	Conversion of Devices.....	5-17
5.6.1	Batch change of devices.....	5-17
5.6.2	Batch conversion of "N/O" and "N/C" contacts.....	5-20
5.7	List Monitor.....	5-21
5.7.1	Batch monitor of devices.....	5-21
5.7.2	Display of device memory contents in GPP/PHP.....	5-23
6.	PC MODE.....	6-1 ~ 6-8
6.1	Functions in PC Mode.....	6-1
6.2	Menu Selection in Write, Read, and Verify.....	6-2
6.3	Write to Programmable Controller.....	6-4
6.4	Read from Programmable Controller.....	6-5
6.5	Verify with Memory Contents of Programmable Controller.....	6-6
6.6	Test to Programmable Controller.....	6-7
7.	FDD MODE.....	7-1 ~ 7-27
7.1	FDD Functions and File Names.....	7-1
7.1.1	FDD functions.....	7-1
7.1.2	Structure and contents of file name.....	7-2
7.2	Directory.....	7-4

7.3	Read from FD [I]	7-6
7.4	Read from FD [II] (For program)	7-8
7.5	Read from FD [III] (For comment)	7-11
7.6	Write to FD	7-13
7.7	Verify with FD	7-15
7.8	Deletion of File on FD	7-17
7.9	File Copy	7-19
7.10	Formatting of FD	7-22
7.11	Automatic Write to FD	7-24
7.12	Cleaning Disk	7-26
7.13	Save Printer Data	7-27
8.	COMMENT MODE	8-1 ~ 8-9
8.1	Comment Mode Functions	8-1
8.2	Comment Mode-General Information	8-2
8.3	Comment Mode Selection and Range Setting Operation	8-3
8.4	Write of New Comment Data	8-4
8.5	Write of Comment Data (Select "CONTINUE" on COMMENT screen)	8-6
8.6	Read of Comment Data	8-8
8.7	Deletion of Comment Data and Comment Range Data	8-9
9.	ROM MODE	9-1 ~ 9-10
9.1	ROM Mode Functions	9-1
9.1.1	A6GPP	9-1
9.1.2	A6PHP	9-1
9.2	Usable EP-ROMs and Memory Capacities	9-2
9.3	Setting of Memory Capacity	9-3
9.4	Read from ROM	9-4
9.5	Write to ROM	9-6
9.6	Verify with ROM	9-8
9.7	ROM Erasure Check	9-10
10.	PRINTER MODE	10-1 ~ 10-31
10.1	Printer Mode and Functions	10-1
10.2	Setting of Used Printer	10-3
10.3	Setting of Baud Rate (For K7PR)	10-4
10.4	Setting of Communication Mode (For general-purpose printer)	10-5
10.5	Setting of Print Paper Length (For K7PR, A7PR, and general-purpose printer)	10-6
10.6	Setting of Print Starting Position (For K7PR, A7PR, and general-purpose printer)	10-7
10.7	Mode Setting	10-8
10.8	Setting of Print Starting Page (For single (page setting) setting)	10-10
10.9	Setting of Printer Mode	10-11
10.10	Ladder Print	10-13
10.11	Command List Print Setting	10-18
10.12	Contact and Coil List Print	10-21
10.13	Device Used List Print	10-23
10.14	Comment List Print Setting	10-25
10.15	Utilized Circuit Print	10-27

10.16 Multiple Mode Print	10-29
10.17 Screen Copy	10-30
11. CONVERSION TO PROGRAM FOR K3.....	11-1 ~ 11-3
11.1 Conversion to K3 Program	11-2
12. MICROCOMPUTER MODE.....	12-1 ~ 12-5
12.1 Memory Map of Each CPU	12-1
12.2 Internal Configuration of Data Memory	12-2
12.3 Microcomputer Program Call Example	12-3
12.4 Microcomputer Mode Read.....	12-4
12.5 Microcomputer Mode Write.....	12-5
13. INITIAL DATA READING OR "SOFT RESTART".....	13-1 ~ 13-2
14. TROUBLESHOOTING	14-1 ~ 14-6
14.1 Troubleshooting when Loading the SW1-GPPK.....	14-1
14.2 Troubleshooting during Communication with Programmable Controller (PC).....	14-2
14.3 Troubleshooting during FDD Operation	14-3
14.4 Troubleshooting during ROM Operation.....	14-4
14.5 Troubleshooting during Printer Operation.....	14-5
14.6 Troubleshooting during Use of External CRT.....	14-6
15. MESSAGE LIST.....	15-1 ~ 15-5
15.1 Error Message List.....	15-1
15.2 Message List	15-4
15.3 Error Messages and Messages Printed on Print Paper	15-5
APPENDICES.....	APP-1 ~ APP-25
APPENDIX 1 Illogical Ladder Examples.....	APP-1
APPENDIX 2 Reading Data from K8GPP to GPP/PHP	APP-4
APPENDIX 3 Comparison of Functions between A6GPP (SW1GP-GPPK) and K8GPP.....	APP-6
APPENDIX 4 Processing Time List	APP-9
APPENDIX 5 Printer Output Codes	APP-11
APPENDIX 6 PC Availably	APP-13
APPENDIX 7 Quick Reference Summary	APP-15
APPENDIX 8 Floppy Disk Using Instructions.....	APP-23

1. INTRODUCTION

This manual describes the operating procedure for the A6GPP intelligent programming terminal, A6PHP plasma handy display with Mitsubishi MELSEC-K series programmable controllers.

Since the GPP/PHP is a general purpose programming unit, some of the hardware is not used in conjunction with the MELSEC-K series (e.g. light pen interface and memory cassette)

Full hardware instructions and specifications are given in the GPP/PHP users manual.

The operating system for the A6GPP (or GPP) or the A6PHP (or PHP) is stored on Floppy disk, (referred to as FD) part number SW1GP-GPPK0000*.

The GPP includes two floppy disk drives (FDD) one for the system FD and one for general program storage (user FD). Specifications for the floppy disks are as follows:

1. INTRODUCTION



1.1 Operations Available Using the SW1GP-GPPK Operating System

The GPP uses a variety of modes selected by the user. Each mode is further divided into functions depending on the mode selected. There are a total of ten modes available, most of which are divided into a series of functions. For example PC mode is divided up into the following functions WRITE, READ, VERIFY and TEST.


The following table indicates the modes available and their relevant functions:

SW1GP-GPPK A6GPP	Programming	Ladder mode	Write Creation of program by ladder symbols 4.3.1~4.3.3
		List mode	Read Read of program from GPP/PHP memory on ladder diagram basis . 4.4.1~4.4.6
			Insertion/addition Insertion/addition of program by ladder symbols. 4.5.1~4.5.3
			Circuit utilization Repeated circuit or ladder block format. 4.6.1~4.6.2
			Monitor Display of operating conditions of programmable controller CPU in ladder diagram 4.7.1~4.7.5
			Test Forced output to programmable controller CPU during monitor. 4.8.1
			Write Creation of program by command list 5.3.1~5.3.2
			Read Display of program command list in GPP/PHP memory 5.4.1~5.4.7
			Insertion/addition Insertion/addition of program by command list. 5.5.1~5.5.2
			Conversion Batch change of devices and "N/O" and "N/C" contacts. 5.6.1~5.6.2
		Monitor Display of operating conditions of programmable controller CPU in list 5.7.1	
	PC mode	Write Write to programmable controller CPU memory (memory area, device memory) 6.3	
		Read Read from programmable controller CPU memory (memory area, device memory) 6.4	
		Verify Verify between programmable controller CPU memory and GPP/PHP memory (memory area, device memory) 6.5	
		Test Forced output to programmable controller CPU 6.6	
	FD mode	Directory Read of directory of program file 7.2	
		Read Read of file from floppy disk. 7.3~7.5	
		Write Write from internal memory of GPP/PHP to floppy disk 7.6	
		Verify Verify between file on floppy disk and internal memory of GPP/PHP 7.7	
		Deletion of file Deletion of file on floppy disk 7.8	
		File copy Copy between floppy disks 7.9	
		FD formatting Formatting of floppy disk 7.10	
		Automatic write Automatic write to FD during programming. 7.11	
		Cleaning disk Cleaning of FDD head 7.12	
		Save printer data Save of data set in printer mode onto FD (SW0-GPPU). 7.13	
	Comment mode	Read Read of comment list. 8.6	
		Write Write of comment list. 8.4~8.5	
		Deletion Deletion of comment list 8.7	
	ROM mode	Read Read of the contents of ROM 9.4	
		Write Write of the contents of GPP internal memory to ROM 9.5	
		Verify Verify of the contents of ROM with those of internal memory of GPP/PHP. 9.6	
		Erase check Check of ROM erasure 9.7	
	Printer mode	Ladder Ladder diagram print out 10.10	
		Command list List print out 10.11	
		Contact and coil list List of elements used 10.12	
		Device used list List of device used. 10.13	
		Comment list Print out of comments 10.14	
		Utilized circuit Printing of utilized circuit stored in FD 10.15	
		Multiple Continuous printing after setting multiple functions from ladder to comment list print functions 10.16	
		Screen copy Printing of screen on CRT of GPP/PHP 10.17	
	Conversion mode	Conversion of programs for K0, K0J, K1, and K2 to program for K3. 11.1	
	Microcomputer mode	Read Read from internal memory of GPP in hexadecimal 12.4	
		Write Write of microcomputer program to internal memory of GPP 12.5	
	Re-read of initial data setting	Re-read operation of initial data setting screen during operation 13	

1. INTRODUCTION

MELSEC-A

To select the required mode, press the relevant mode key. To use COMMENT, ROM, PRINTER, CONVERSION, MICRO-COMPUTER or INITIAL DATA modes press the **OTHER** key and select the mode from the menu using the cursor and **GO** keys.



Once the mode has been chosen, the function is selected using the function keys or by choosing from menu options with the cursor and **GO** keys.

POINT


When used with the SW1GP-GPPK operating system, the upper keyboard of the A6GPP is only used for FDD mode operations and comment writing.


1. INTRODUCTION



1.2 System Configuration

Connection of the A6GPP with MELSEC-K series Programmable controllers and peripherals is as follows:






2. STARTING PROCEDURE

2. STARTING PROCEDURE

2.1 GPP/PHP Starting Procedure Flow Chart




2. STARTING PROCEDURE


MELSEC-A

2.2 Initial Data Setting Procedure

Start the system in the procedure described in Section 2.1. Prior to the mode selection, it is necessary to set the initial data. Set the PC type, memory capacity, and PC number.



Set the items in order, "PC TYPE", "MEMORY CAPACITY", "PC NO", and "CHARACTER SELECTION". To select each parameter, move the cursor with the \downarrow key and then press the $\boxed{\text{GO}}$ key.




*1: Refer to Section 8.1.

2. STARTING PROCEDURE

MELSEC-A


2.3 Automatic FD Write Mode Selecting Method

Automatic FD write mode allows automatic data write onto FD during ladder, list or comment creation without proceeding to FDD mode. After setting the initial data, set whether or not automatic FD write mode is selected. The initial screen displays automatic FD write mode.



2. STARTING PROCEDURE

2.3.1 Automatic FD write mode setting procedure



- (1) To select automatic FD write mode, insert the system disk into FDD **[A]** and the user disk into FDD **[B]**. If the user disk is not in FDD **[B]** during ladder, list, or comment creation after the GPP/PHP operation is initiated, "FLOPPY DISK ERROR" is displayed.
In this case, insert the SW0-GPPU into FDD **[B]** and operate properly.
- (2) When an existing file name is specified, "SYSTEM NAME ALREADY USED" is displayed in the message column and then "PRESS **[W]** TO WRITE NEW PROGRAM PRESS **[R]** TO READ PROG. FROM DISK". To over-write the previous file, enter "W". To read the program from the specified file, enter "R".
When the GPP/PHP is started or reset, the contents of the internal memory is cleared. Therefore, to execute automatic write mode after selecting an existing system name, be sure to enter "R", thereby reading the program from the FD.
When **R** is pressed, program and comments are read (if the same system name has been specified).
- (3) If an existing system name is specified after starting up or resetting the GPP/PHP, "SYSTEM NAME ALREADY USED" is displayed in the message column and then "PRESS **[W]** TO WRITE NEW PROGRAM PRESS **[R]** TO READ PROG. FROM DISK."
Press **[W]** to write a new program using the same system name. Press **[R]** to read and correct the existing program.
When executing automatic write mode after setting the same system name, **[R]** must be pressed to read the program from disk.
Pressing **[R]** reads the existing program and comments (if the same system name is specified).

2.3.2 Automatic FD write timing

In automatic FDD write mode, data is automatically written onto the FD when any of the following key operations is performed.

Ladder mode

- When **[CNV]** and **[GO]** are pressed during ladder write, the converted head step to END is written.
- When a ladder is deleted, the deleted head step to END is written.
- When a ladder is inserted, the inserted head step to END is written.

List mode

- By pressing **[MELSAP]** after writing a list, all sequence programs are written. In this case, if **[MELSAP]** is not pressed but the relevant mode key pressed after write, insertion, deletion, or conversion, all sequence programs are written automatically.

Comment mode

- By pressing **[F9]** after writing comments, all comments are written.

Microcomputer mode

- When **[MELSAP]** is pressed after writing microcomputer programs, all microcomputer programs are written. In this case, if **[MELSAP]** is not pressed but another mode key pressed, all microcomputer programs are written automatically.

2.3.3 System name clear timing

The system name set in automatic write mode is automatically cleared:

- 1) by resetting the GPP/PHP or switching the power off;
- 2) when read is executed in PC or ROM mode;
- 3) when read, write, delete, copy, or formatting is executed in FDD mode;
- 4) by setting the initial data;
- 5) by clearing the memory (writing NOPs);
- 6) when "NO" is selected for "AUTO-WRITE" in FDD mode; or
- 7) when FLOPPY DISK ERROR or WRITE-IN ERROR is displayed in automatic write mode.


REMARKS

For 1) to 5), automatic write mode is not cleared. For 6) and 7), automatic write mode is cleared at the same time.

2.4 Parameter Setting

For parameter setting, the GPP/PHP always verifies the GPP/PHP and PC CPU programs automatically prior to monitoring (ladder only) and displays the monitor screen. To perform the monitor operation without automatic verification, it is necessary to select "NO" in parameter mode.

Set as explained below.



Parameter entry →

* MONITOR AUTO-VERIFY SETTING *

YES

NO

↑

On the initial setting screen, the cursor is located on the left of "NO". To execute automatic verification, press to move the cursor to "YES" and then press the relevant mode key.

POINT


Automatic FD write mode must always be set after setting the initial data. The parameter may be set before setting monitor mode. For operating convenience, it is suggested to set the parameter after the initial data setting.

2. STARTING PROCEDURE


2.5 Layout of Display

Approximately one quarter of the lower area of the CRT screen displayed on the GPP/PHP is occupied by the "common display area". An explanation of the common display area is given in this section and the format remains similar in all modes.

In screens shown hereafter, the "common display area" is omitted.



The figure below shows an expanded common display area. An explanation of each item given is below.



*1 and *2 The displays in these columns differ depending on modes, as indicated below.

Mode	Display	Contents
Ladder, list, ROM, printer, program conversion, microcomputer	"MEMORY USED" "LEFT"	Indicates the amount of used memory and remaining amount in step numbers
Comment	"COMMENT USED" "LEFT"	Indicates the amount of used comment and remaining amount in comment numbers.
PC, FDD	No indication	

2. STARTING PROCEDURE

MELSEC-A

- *3 Indicates the current "MODE" of the A6GPP.
- *4 Indicates the current "FUNCTION" of the A6GPP.
- *5 Displays the data currently being keyed in (where appropriate).
- *6 Displays error messages and other information for the user.
- *7 In FDD mode or comment write mode, "MELSAP" is displayed. In other modes, "GPP" is displayed. When MELSAP is displayed, the upper (MELSAP) keyboard should be used and when GPP is displayed, the lower (GPP) keyboard should be used.
- *8 "SHIFT" is displayed when the **SHIFT** key had been pressed on the "GPP" keyboard.
(*Note: **SHIFT** may have been entered automatically in ladder or list mode according to the previous key strokes.*)
- *9 "AUTO" is displayed when automatic write to the FD has been selected.

2.6 Adjustment of A6GPP Buzzer Volume

To adjust the volume of electronic buzzer sounded when data is input:

(With MELSAP mode keys)

Input **CTRL** and **1** at the same time.


The volume is factory-set at a "low" level. By simultaneously inputting **CTRL** and **1**, the volume is set to a "high" level. To return to the "low" level, input **CTRL** and **1** at the same time.

3. BASIC OPERATIONS FOR THE GPP/PHP

This chapter describes general description for the GPP/PHP operations.

3.1 GPP/PHP Applications

The GPP/PHP+SW1GP-GPPK system applications are classified into the following:



3.1.1 Program creation

The most significant application of the GPP/PHP is program creation. The program creating procedures are available in ladder and list modes.

Ladder Mode	List Mode
Create sequence program using ladder symbols.	Create sequence program using instruction list.
	<pre> 0 LD X000 1 ANI X002 2 ORI X004 3 MOV K1 D1 6 LDI X001 7 OR X005 8 AND X003 9 MOV K10 D2 12 END </pre>
<p>The program created in ladder or list mode may be displayed in either mode, i.e. the ladder diagram may be displayed as a program list.</p>	

3. BASIC OPERATIONS FOR THE GPP/PHP



3.1.2 Program check

After the program creation, always check the program. To make the most effective check, use the monitor function. By using the monitor function, write the created program into the PC and monitor the PC operation result on the GPP/PHP CRT. The monitoring methods are available in ladder and list monitorings.

Ladder Monitor	List Monitor																																																																																																																
<p>Monitor the ladder diagram and check the contacts and output ON/OFF status. Data register contents in the ladder may be checked.</p>	<p>Monitor the devices.</p> <p style="text-align: center;">X BATCH MONITORING LIST X</p> <table border="0"> <tr><td>Y 000</td><td>Y 010</td><td>Y 020</td><td>Y 030</td><td>Y 040</td><td>Y 050</td><td>Y 060</td></tr> <tr><td>Y 001</td><td>Y 011</td><td>Y 021</td><td>Y 031</td><td>Y 041</td><td>Y 051</td><td>Y 061</td></tr> <tr><td>Y 002</td><td>Y 012</td><td>Y 022</td><td>Y 032</td><td>Y 042</td><td>Y 052</td><td>Y 062</td></tr> <tr><td>Y 003</td><td>Y 013</td><td>Y 023</td><td>Y 033</td><td>Y 043</td><td>Y 053</td><td>Y 063</td></tr> <tr><td>Y 004</td><td>Y 014</td><td>Y 024</td><td>Y 034</td><td>Y 044</td><td>Y 054</td><td>Y 064</td></tr> <tr><td>Y 005</td><td>Y 015</td><td>Y 025</td><td>Y 035</td><td>Y 045</td><td>Y 055</td><td>Y 065</td></tr> <tr><td>Y 006</td><td>Y 016</td><td>Y 026</td><td>Y 036</td><td>Y 046</td><td>Y 056</td><td>Y 066</td></tr> <tr><td>Y 007</td><td>Y 017</td><td>Y 027</td><td>Y 037</td><td>Y 047</td><td>Y 057</td><td>Y 067</td></tr> <tr><td>Y 008</td><td>Y 018</td><td>Y 028</td><td>Y 038</td><td>Y 048</td><td>Y 058</td><td>Y 068</td></tr> <tr><td>Y 009</td><td>Y 019</td><td>Y 029</td><td>Y 039</td><td>Y 049</td><td>Y 059</td><td>Y 069</td></tr> <tr><td>Y 00A</td><td>Y 01A</td><td>Y 02A</td><td>Y 03A</td><td>Y 04A</td><td>Y 05A</td><td>Y 06A</td></tr> <tr><td>Y 00B</td><td>Y 01B</td><td>Y 02B</td><td>Y 03B</td><td>Y 04B</td><td>Y 05B</td><td>Y 06B</td></tr> <tr><td>Y 00C</td><td>Y 01C</td><td>Y 02C</td><td>Y 03C</td><td>Y 04C</td><td>Y 05C</td><td>Y 06C</td></tr> <tr><td>Y 00D</td><td>Y 01D</td><td>Y 02D</td><td>Y 03D</td><td>Y 04D</td><td>Y 05D</td><td>Y 06D</td></tr> <tr><td>Y 00E</td><td>Y 01E</td><td>Y 02E</td><td>Y 03E</td><td>Y 04E</td><td>Y 05E</td><td>Y 06E</td></tr> <tr><td>Y 00F</td><td>Y 01F</td><td>Y 02F</td><td>Y 03F</td><td>Y 04F</td><td>Y 05F</td><td>Y 06F</td></tr> </table>	Y 000	Y 010	Y 020	Y 030	Y 040	Y 050	Y 060	Y 001	Y 011	Y 021	Y 031	Y 041	Y 051	Y 061	Y 002	Y 012	Y 022	Y 032	Y 042	Y 052	Y 062	Y 003	Y 013	Y 023	Y 033	Y 043	Y 053	Y 063	Y 004	Y 014	Y 024	Y 034	Y 044	Y 054	Y 064	Y 005	Y 015	Y 025	Y 035	Y 045	Y 055	Y 065	Y 006	Y 016	Y 026	Y 036	Y 046	Y 056	Y 066	Y 007	Y 017	Y 027	Y 037	Y 047	Y 057	Y 067	Y 008	Y 018	Y 028	Y 038	Y 048	Y 058	Y 068	Y 009	Y 019	Y 029	Y 039	Y 049	Y 059	Y 069	Y 00A	Y 01A	Y 02A	Y 03A	Y 04A	Y 05A	Y 06A	Y 00B	Y 01B	Y 02B	Y 03B	Y 04B	Y 05B	Y 06B	Y 00C	Y 01C	Y 02C	Y 03C	Y 04C	Y 05C	Y 06C	Y 00D	Y 01D	Y 02D	Y 03D	Y 04D	Y 05D	Y 06D	Y 00E	Y 01E	Y 02E	Y 03E	Y 04E	Y 05E	Y 06E	Y 00F	Y 01F	Y 02F	Y 03F	Y 04F	Y 05F	Y 06F
Y 000	Y 010	Y 020	Y 030	Y 040	Y 050	Y 060																																																																																																											
Y 001	Y 011	Y 021	Y 031	Y 041	Y 051	Y 061																																																																																																											
Y 002	Y 012	Y 022	Y 032	Y 042	Y 052	Y 062																																																																																																											
Y 003	Y 013	Y 023	Y 033	Y 043	Y 053	Y 063																																																																																																											
Y 004	Y 014	Y 024	Y 034	Y 044	Y 054	Y 064																																																																																																											
Y 005	Y 015	Y 025	Y 035	Y 045	Y 055	Y 065																																																																																																											
Y 006	Y 016	Y 026	Y 036	Y 046	Y 056	Y 066																																																																																																											
Y 007	Y 017	Y 027	Y 037	Y 047	Y 057	Y 067																																																																																																											
Y 008	Y 018	Y 028	Y 038	Y 048	Y 058	Y 068																																																																																																											
Y 009	Y 019	Y 029	Y 039	Y 049	Y 059	Y 069																																																																																																											
Y 00A	Y 01A	Y 02A	Y 03A	Y 04A	Y 05A	Y 06A																																																																																																											
Y 00B	Y 01B	Y 02B	Y 03B	Y 04B	Y 05B	Y 06B																																																																																																											
Y 00C	Y 01C	Y 02C	Y 03C	Y 04C	Y 05C	Y 06C																																																																																																											
Y 00D	Y 01D	Y 02D	Y 03D	Y 04D	Y 05D	Y 06D																																																																																																											
Y 00E	Y 01E	Y 02E	Y 03E	Y 04E	Y 05E	Y 06E																																																																																																											
Y 00F	Y 01F	Y 02F	Y 03F	Y 04F	Y 05F	Y 06F																																																																																																											
<p>By specifically using the ladder and list monitors, programs can be checked properly.</p>																																																																																																																	

3.1.3 Program storage

Created programs can be stored onto a floppy disk (FD), ROM ,etc. Since the A6GPP memory (into which created programs are entered) is not backed up by a battery, all programs will be cleared if the power is turned off or reset is executed. For this reason, it is recommended to use automatic FD write mode. In FDD mode, the program/comment edit function is available, which is useful during program creation.

3.1.4 Print-OUT

The A6GPP provides a wide variety of print out functions. Utilize these functions according to applications, such as program data storage, used device list, program diagram creation, and monitor diagram copying.


<p>POINT</p> <p>KCPU ON LINE</p> <p>KCPU ON LINE means that the K6HGPF is in the ONLINE mode and the KCPU is in the RUN mode. In the case of K3NCPU, however, KCPU ON LINE means that the KCPU is in the RUN or STEP-RUN mode.</p>
--

4. LADDER MODE

4.1 Ladder Mode Introduction

The ladder (or circuit) diagram is a convenient way of logically setting out a program using standard symbols derived from conventional relay diagrams.

Essentially, the ladder diagram consists of contacts and coils each with a "device number" which identifies it and defines its function (e.g. timer, counter etc.). These devices are connected to form blocks which in turn make up the ladder diagram. The following is a short example of a ladder diagram:



For detailed information on programming, refer to the relevant programming manual.

4.2 Ladder Mode Functions

In ladder mode sequence programs may be handled using the ladder symbol keys on the GPP key board.

The functions of ladder mode are as indicated below:

Ladder mode function	Ladder write	Creation of new ladder	Ladder is newly created.	(Section 4.3.1)
		Correction of existing ladder	Created ladder is corrected.	(Section 4.3.2)
		Insertion and/or addition of ladder block	Ladder block is added and/or inserted to sequence circuit.	(Section 4.3.3)
	Ladder read	Ladder read by step number	Ladder is read by specified step number.	(Section 4.4.1)
		Ladder read by contact or coil number	Ladder is read by specified contact or coil number.	(Section 4.4.2)
		Ladder read by I/O number	Ladder is read by specified I/O number.	(Section 4.4.3)
		Ladder read by instruction	Ladder is read by specified instruction.	(Section 4.4.4)
		The last ladder read by END	The last sequence ladder is read by END instruction.	(Section 4.4.5)
		Read of ladder with comment	Entered comment is annotated to ladder and displayed.	(Section 4.4.6)
	Ladder insertion/deletion	Insertion and/or addition in units of ladder symbol	Insertion and/or addition is made to ladder in units of ladder symbol.	(Section 4.5.1)
		Deletion of 1 ladder block	Deletion is made from ladder per ladder block.	(Section 4.5.2)
		Deletion in units of ladder symbol	Deletion is made from ladder in units of ladder symbol.	(Section 4.5.3)
	Ladder utilization	Entry of utilized ladder	Circuit pattern, which is to be utilized, is entered into FD.	(Section 4.6.1)
		Utilization of entered ladder	Entered circuit pattern is utilized for specified portion of program.	(Section 4.6.2)
	Ladder monitor of programmable controller CPU	Ladder monitor	Monitor in ladder mode.	(Section 4.7.1)
		Stop of monitor screen	Monitor screen is stopped during ladder monitor operation, irrespective of the operation of programmable controller CPU.	(Section 4.7.2)
		Screen stop by monitor stop point setting	Monitor screen is stopped at monitor stop point during ladder monitor operation, irrespective of the operation of programmable controller CPU.	(Section 4.7.3)
		Entry monitor	Used monitor devices, which are not displayed in the ladder, during ladder monitor operation.	(Section 4.7.4)
		Decimal ↔ hexadecimal present value monitor	T.C and D values of ladder monitor and entry monitor are displayed in decimal and hexadecimal.	(Section 4.7.5)
	Test operation to programmable controller CPU	Forced output to programmable controller CPU	Output is provided forcibly without regard to the operation of programmable controller CPU.	(Section 4.8.1)
Step run of K3NCPU		Function which allows the program in the programmable controller CPU to perform step run per step of software processing instruction when the A6GPP is connected with the K3NCPU.	(Section 4.8.2)	

POINT

- 1) In ladder mode, the numbers of contacts which can be created and displayed are as follows:

While writing a circuit, the number of parallel contacts is 22 points and that of serial contacts is 161 points.

While reading a circuit, the number of parallel contacts is 24 points and that of serial contacts is 211 points.


- 2) Step numbers are displayed in decimal.
Previously, for example, the K8GPP used for the K3NCPU displayed step "A000". However, the A6GPP displays step "10000".

4. LADDER MODE


4.3 Ladder Write

4.3.1 Creation of a new ladder

A new program is written. Any previous programs are deleted from the GPP memory



BASIC OPERATION



OPERATION PROCEDURE 1

* SYSTEM NAME SETTING * (AUTO-WRITE)

DRIVE B

SYSTEM NAME	EX5
COMMENT	DEMO

PRESS <CR>, WHEN OK

CLEAR MEMORY FOR NEW PROGRAM ?

* IF YES, PRESS <NOP> <GO>

* IF NO, PRESS <RD>

CR

Key in the required system name and comment on the MELSAP key board.
(Press **CR** to cancel auto write)


NOP → **GO** Clears the program area ready for the new program.

EXPLANATION

- (1) If FD Auto write has been selected (see section 2.3), the system name setting screen is displayed the first time that the **LDR** **WR** keys are pressed. The system name should be keyed in from the MELSAP Keyboard using a maximum of 8 characters, the first of which must be on alphabetic character. After pressing the **CR** key, a comment of up to 20 characters may be keyed in. Press the **CR** key to enter the comment and the message "PRESS **CR**, WHEN OK" is displayed. When the **CR** key is pressed a file with the designated system name is opened on the FD.
If a file already exists for the specified name "SYSTEM NAME ALREADY USED" is displayed in the message column followed by "PRESS **W** TO WRITE NEW PROGRAM, PRESS **R** TO READ PROG. FROM DISK". To overwrite the existing file, press "W". To read the program from the specified file, enter "R".
To cancel the auto-write function, press the **CR** key when the system name setting screen is displayed. In this case "PRESS **CR** TO CANCEL AUTO-WRITE" is displayed, when the **CR** key is pressed a second time, auto-write is cancelled.
- (2) Declare the start of a new circuit.
NOP → **GO** The previous programs are cleared and the work area prepared for a ladder.
RD If the previous program must not be cleared, press the **RD** key to proceed to read mode.

4. LADDER MODE

OPERATION PROCEDURE 2



EXPLANATION

- (1) After the previous programs have all been cleared, the new ladder screen is displayed.
Write the ladder, starting at the cursor position.

REMARKS

It is necessary to always start with a contact symbol, i.e.:

Example:  or  →  →  → 

SUMMARY

- (1) After ladder creation, be sure to press the **CNV** and **GO** keys. By pressing the **CNV** and **GO** keys, the ladder pattern is checked, converted into a list pattern, and then stored in the work area. If you have forgotten to press the **CNV** and **GO** keys and selected another function, "PRESS CNV?" is displayed in the message column. If it is not required to make the conversion, press the function key again.
- (2) Perform the conversion operation for every two screens written.
- (3) During conversion, the message column displays "EXECUTING". After the completion of conversion, the message column displays "COMPLETED * STEP NOS CHANGED".
- (4) When the **WR**, **+**, and **GO** keys are pressed after the **CNV** and **GO** keys are pressed, the created ladder display is cleared, the next step number is displayed, and the creation of the next ladder block can be performed.
- (5) If FD automatic write operation has been set, the program is automatically stored onto the FD when the **CNV** and **GO** keys are pressed. (For automatic write operation to the FD, refer to Section 7.11 and 2.3.)
- (6) If, during the write procedure, an incorrect device or number is keyed in, this may be erased from the key-in data column by using the **CLEAR** key.

REMARKS

- (1) When creating a new ladder, it is recommended to write , **CJ**, **K**, **0**, for the jump destination step number.
Be sure to press 0. ←
(Reason: If the jump destination of CJ instruction is other than K0, the execution of conversion after ladder write changes the jump destination of CJ instruction.)
After writing all ladders, press **RD**, , **CJ**, and **GO** keys to search for the CJ and change them to normal jump destination step numbers.
- (2) If an invalid jump destination step number (i.e. outside the range set on the initial data screen) is selected "CJ STEP NO. ERROR" is displayed.
- (3) Once a normal jump destination step has been set this is automatically changed if step numbers change due to ladder correction, etc.
- (4) The jump destination step of CJ instruction should always be located after the step of CJ (i.e. a higher step number) and before END.
In ladder mode, the error check of CJ instruction jump destination step (check if a jump destination step is located before or after CJ step) is not made.

4. LADDER MODE

The instruction input procedures in ladder mode are classified into five types.

- (1) LD, LDI, AND, ANI, OR, ORI, and OUT (except OUT T, C) instructions (sequence instructions)

Ladder symbol [SP] Device Device number GO

Example: LD X00 ⇒  [SP] X 0 GO

- (2) OUT T, C instruction (sequence instruction)

Ladder symbol [SP] Device Device number [SP] Set value GO

Example: OUT T0 K10 ⇒  [SP] T 0 [SP] K 1 0 GO

- (3) MC, MCR, SET, RST, SFT, CJ, and PLS instructions (sequence instructions)

Ladder symbol [SP] Instruction [SP] Device Device number GO



Example: SET Y0 ⇒  [SP] SET [SP] Y 0 GO

- (4) =, <, >, +, -, MOV, BIN, and BCD instructions (data instructions)

Ladder symbol [SP] Instruction [SP] Source data [SP] Destination data GO



Example: MOV D0 D1 ⇒  [SP] MOV [SP] D 0 [SP] D 1 GO

- (5) Vertical line and horizontal line

Ladder symbol GO

Example: Vertical line ⇒  GO

REMARKS

In the above, the [SP] (space) key can be omitted.
The following pages show examples of key inputs.

4. LADDER MODE



Instruction Input Procedure Examples

Instruction	Key Input	Screen Display	
		Before key input	After key input
LD	<p>↳ Device number</p>		
LDI			
AND			
ANI			
OR			
ORI			
OUT (Only Y, M, F)			
OUT For timer (T)			
OUT For counter (C)			

4. LADDER MODE



Instruction	Key Input	Screen Display	
		Before key input	After key input
MC			
MCR			
SET			
RST			
SFT			
CJ			
PLS			
=			

4. LADDER MODE



Instruction	Key Input	Screen Display	
		Before key input	After key input
<			
>			
+			
-			
MOV			
BIN			
BCD			
Vertical line			
Horizontal line			

4. LADDER MODE


MELSEC-A

4.3.2 Correction of existing ladder


To correct a ladder.

**LADDER
WRITE**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) By performing the read operation, display the ladder block, which is to be corrected.
- (2) Move the cursor to the head of the block to be corrected and then press the **WR** key. This causes the ladder block to be displayed at the top of the screen and the other ladder blocks to be cleared.
Move the cursor to the symbol to be corrected, by use of the cursor keys and then perform the instruction input operation.
- (3) After the correction of a ladder, be sure to press the **CNV** and **GO** keys.
- (4) Immediately after the **GO** key is pressed, "EXECUTING" is displayed in the message column. Upon completion of the conversion, "COMPLETED * STEP NOS. CHANGED" is displayed and the corrected ladder is displayed on the screen.
- (5) If the FD automatic write operation has been set, the program in the range from the corrected step to the END is automatically stored onto the FD. (For automatic write operation to the FD, refer to Section 2.3 and 7.11.)

POINT

If a ladder change involves the addition of lines of program between a conditional jump instruction and its relevant destination step number, then the "K" value associated with the CJ instruction is automatically adjusted to allow for the change in step number.

(6) A data instruction may be corrected using the following procedure: (This does not apply to contact, coil, timer, and counter.)

By moving the cursor to the head of a data instruction and pressing and **GO**, that data instruction and the cursor are displayed at the key-in data column.


(If and **GO** are pressed with the cursor anywhere other than the head of the data instruction, "OPERATOR ERROR" is displayed in the message column.)

The instruction may then be corrected by moving the cursor to the relevant part of the instruction and over writing it (Note the state of the shift key, displayed at lower right of screen). When the **GO** key is pressed after correction the corrected ladder is displayed.

This data instruction correcting procedure is applicable only to a write function (not applicable to an insert function).


POINT

Replacing a contact with a horizontal line, as in the example below, causes a NOP instruction to be placed at the end of the circuit block concerned. Hence the step numbers of other circuit blocks do not change.



(7) Line return for more than 11 contacts

1) Writing a 12th series contact during ladder creation automatically causes the return shown below.



2) The return symbol can also be written by pressing , **K**, **0**, and **GO** keys.

A return symbol can be written only to the 1st and 12th columns. For return symbols, serial numbers K0 to K255 are used in order, starting at 0. For OUT (→) and IN (↘), a pair of numbers should always be used and the same numbers cannot be used repeatedly. Other ladder symbols cannot be inserted between OUT (→) and IN (↘) lines.

3) A maximum of 15 returns can be made in one ladder block (161 contacts). If restrictions described in above 2) and 3) are not followed, "LADDER CONTINUATION ERROR" is displayed at conversion and conversion cannot be made.

4. LADDER MODE


MELSEC-A

4.3.3 Insertion and addition of ladder block


A ladder block is inserted or added to the program.

**LADDER
WRITE**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) The read operation displays the ladder block, to which insertion or addition is desired, on the CRT.
- (2) When a ladder block other than the one at the top of the read ladder is to be corrected, move the cursor to the head of the block to be corrected and then press the **WR** key. This causes the ladder block to be displayed at the top of the screen and the other ladder blocks to be cleared.
The **+** and **GO** keys allow a ladder block to be inserted after the specified step number.
(The **-** and **GO** keys allow a ladder block to be inserted before the specified step number.)
- (3) By performing the instruction input operation, write the additional ladder blocks.
- (4) After the addition or insertion of a ladder block, be sure to press the **CNV** and **GO** keys.

POINT

When the ladder block is inserted or added, the succeeding step numbers of the program and any jump destination of CJ instruction are automatically changed.

- (5) If the automatic write operation has been set, the program in the range from the corrected step to the END is automatically written to the FD (For the automatic write operation to the FD, refer to sections 2.3 and 7.11) when the **CNV** and **GO** keys are pressed.

4. LADDER MODE

MELSEC-A


4.4 Ladder Read

4.4.1 Ladder read by step number


The ladder diagram is read from the specified step number.

**LADDER
READ**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) A ladder, max. 12 lines, is displayed on the CRT, beginning with the specified step number.
- (2) If the specified step number is inside one ladder block, the ladder is displayed, beginning with the head step number of that ladder block.
- (3) By performing the basic operation and then pressing the **GO** key, the screen displays the next ladder block and succeeding ones.
- (4) When the **-** and **GO** keys are pressed, the CRT returns to the previous ladder display screen. When the **+** and **GO** keys are pressed, the CRT changes to the next ladder display.
- (5) If there are two or more ladder blocks and the 12th line is in the middle of a ladder block, only the first ladder block is displayed. By pressing the **GO** key after one screen is displayed, the rest of the ladder is displayed.

- By pressing the **↓** key with the cursor located at the bottom line, the screen is scrolled upward by one line and the first line of the succeeding circuit is added to the screen.
- By pressing the **↑** key with the cursor located at the top line, the screen is scrolled downward by one line and the 12th line of the preceding ladder is added to the screen.

REMARKS

If the ladder does not extend beyond the screen, the screen can be scrolled upward or downward by use of the **↑** or **↓** key. In this case, however, the screen merely moves up or down and the succeeding or preceding ladder is not displayed automatically.

- (7) When a ladder block consists of 25 or more lines, its 25th and subsequent lines cannot be displayed. (These lines can be displayed in list mode.) In the message column, "LADDER DISPLAYED OVERFLOWS" is displayed.
- (8) When there are two or more END instructions in a program, the ladder blocks below the first END instruction can be displayed only in the case of ladder read by step number.

REMARKS

The amount of used memory is displayed in number of steps to the first END instruction.

4. LADDER MODE


MELSEC-A

4.4.2 Ladder read by contact or coil number


The ladder block containing the specified contact or coil number is displayed.

**LADDER
READ**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) If there are several ladder blocks which include the specified contact or coil number, the ladder block with the lowest step number is displayed. Then, by pressing the **GO** key, the next ladder block is displayed below the preceding one. When the **GO** key is pressed after the screen has become full, the ladder block located at the top of screen is cleared and the succeeding ladder blocks scroll in due order.
- (2) If the specified contact or coil number has been changed during the operation, the ladder block with the new contact or coil number is displayed below the preceding ladder block.
- (3) When all the relevant ladder blocks have been displayed, "NOT FOUND" is displayed in the message column.
- (4) When the device has been specified in the search by contact, only "N/O" contacts are displayed. When the device has been specified in the search by contact, only the "N/C" contacts are displayed.
- (5) When the device has been set, the OUT, SET, RST, SFT, and PLS instructions are read.

REMARKS

When there are two or more END instructions in a program, the program is valid up to the first END instruction.


4. LADDER MODE

4.4.3 Ladder read by I/O number



A ladder block containing the specified device number is displayed.

LADDER
READ

BASIC OPERATION



OPERATION PROCEDURE



(Example: Read of output Y030)

EXPLANATION

- (1) If there are several ladder blocks which include the specified device number, the ladder block with the lowest step number is displayed. Then, by pressing the **GO** key, the next ladder block is displayed below the preceding display. When the **GO** key is pressed after the screen has become full, the ladder block located at the top of the screen is cleared and the succeeding ladder blocks scroll in due order.
- (2) If the specified device number has been changed to another one during the operation, the ladder block with the new device number is displayed below the preceding ladder block.
- (3) After all the corresponding ladder blocks have been displayed, "NOT FOUND" is displayed in the message column.

REMARKS

When there are two or more END instructions in a program, I/O numbers used in the program are valid up to the first END instruction.

4. LADDER MODE

MELSEC-A

4.4.4 Ladder read by instruction


A sequence ladder is read by use of the specified instruction and device number.

**LADDER
READ**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) If there are several ladder blocks which include the specified instruction and device number, the ladder block with the lowest step number is displayed. The specification of device number is not required for data instructions (MOV, >, <, =, +, -, BCD, BIN) and the CJ instruction.
- (2) By performing the basic operation and then pressing the **GO** key, the screen displays the ladder block with the next lowest step number, which includes the specified instruction and device number, below the preceding display.
- (3) If the specified instruction has been changed during the operation, the ladder block with the new instruction is displayed below the preceding ladder block.
- (4) When the screen is full, the ladder block located at the top of screen is cleared and the succeeding ladder blocks scroll in due order.
- (5) After all the corresponding ladder blocks have been displayed, "NOT FOUND" is displayed in the message column.

REMARKS

When there are two or more END instructions in a program, I/O numbers used in the program are valid up to the first END instruction.

4. LADDER MODE


MELSEC-A

4.4.5 Reading the final ladder block using "END" instruction


The ladder block immediately before the END instruction is displayed.

LADDER
READ

BASIC OPERATION



OPERATION PROCEDURE



(Example: Read of END instruction)



EXPLANATION

- (1) When there are two or more END instructions, the first END instruction is searched and the ladder blocks below the first END instruction are ignored and are not displayed.
- (2) By performing the basic operation and then pressing the **CLEAR**, **□**, and **GO** keys, the displayed ladder shifts downward and the preceding ladder block is displayed above that ladder.


4. LADDER MODE

4.4.6 Read of ladder with comment

The comment is displayed together with the ladder.



OPERATION PROCEDURE



EXPLANATION

- (1) After reading the ladder, press the **VER/COM** key. This causes the top five lines of displayed ladder to be displayed as a ladder with comment. Any of the ladder read procedures described in Section 4.4.1 to Section 4.4.5 can be used.
- (2) By performing the basic operation and then pressing the **GO** key, the next five lines are similarly displayed.
- (3) The display of ladder with comment is performed only for the upper five lines of the normal ladder display. The remainder of the 12 lines can be displayed by using the **↑** and/or **↓** keys.
- (4) To return the ladder with comment to the normal ladder, press the **VER/COM** key again.
- (5) Operations such as write, insert, and erase cannot be performed on a ladder with comments. To perform these operations, return the display to that of a normal ladder.

4. LADDER MODE

MELSEC-A


4.5 Insertion and Deletion of Ladder Blocks

4.5.1 Insertion and addition in units of ladder symbols


A block of ladder is added or inserted into the programme.

**LADDER
INSERT**

BASIC OPERATION




OPERATION PROCEDURE



EXPLANATION

- (1) Display the ladder block to which insertion or addition is to be made using the read operation.
- (2) Move the cursor to the head of the block to be corrected and then press the **INS** key. This causes the ladder block to be displayed at the top of the screen and the other ladder blocks to be cleared.
- (3) Move the cursor to the relevant position, and then perform the instruction input operation.
When a contact is inserted or added to a line which consists of 11 serial contacts, the line is automatically returned as shown below.



- (4) After the insertion or addition of a ladder block, be sure to press the **CNV** and **GO** keys.
Immediately after the **GO** key is pressed, "EXECUTING" is displayed in the message column. Upon completion of the conversion, "COMPLETED * STEP NOS. CHANGED" is displayed and the corrected ladder is displayed on the CRT.
- (5) Insertion cannot be made at the beginning or end of a ladder rung.

4. LADDER MODE



POINT

When ladder instructions are inserted or added, the succeeding step numbers of the program and the jump destination of CJ instructions are automatically changed.

- (5) If FD automatic write has been set, the program in the range from the corrected step to the END is automatically written to the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)
- (6) The addition and insertion procedures in units of ladder symbols are shown in the following table.

Addition/ Insertion	Key Input	Screen Display	
		Before key input	After key input
Contact insertion	INS → H X 1 0 GO		
Horizontal line insertion	INS — GO		
Vertical line insertion	INS GO		

4. LADDER MODE


MELSEC-A

4.5.2 Deletion of one ladder block


One ladder block is deleted.

**LADDER
DELETE**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) By performing the read operation, display the ladder block, which is to be deleted, on the CRT.
- (2) Move the cursor to the head of the block to be corrected and then press the **DEL** key. This causes the ladder block to be displayed at the first stage of the screen and the other ladder blocks to be cleared.
- (3) By pressing the  or  key and then pressing the **GO** key, the ladder block displayed on the screen is deleted. (At this time, "DELETE 1-CIRCUIT" is displayed in the message column.)

POINT

When the ladder block is deleted, the succeeding step numbers of the program and the jump destination of CJ instruction are automatically changed.

- (4) Even if the output device of a ladder block, which is to be deleted, is a data instruction, one ladder block can be deleted by pressing the **DEL**,  and **GO** keys.
Since deleted steps change to NOPs, the number of steps does not change.
- (5) For the deletion of one ladder block, it is not required to perform the conversion operation after deletion.
- (6) If the FD automatic write operation has been set, the program in the range from the corrected step to the END is automatically stored into the FD. (For the automatic write operation to the FD, refer to Section 2.3 and 7.11.)

POINT

If, in ladder write, several ladder blocks are created and converted and then one ladder block deletion operation is performed, all the ladder blocks displayed on the CRT will be deleted. To perform one ladder block deletion after conversion, perform the read operation and then proceed to the one ladder block deletion operation.


4. LADDER MODE

4.5.3 Deletion in units of ladder symbols


The ladder is deleted in units of symbols.

**LADDER
DELETE**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) By performing the read operation, display the ladder block, which is to be corrected.
- (2) Move the cursor to the head of the block to be corrected and then press the **[DEL]** key. This causes the ladder block to be displayed at the first stage of the screen and the other ladder blocks to be cleared from the screen.
- (3) By use of the cursor keys, move the cursor to the symbol which is to be deleted, delete the ladder symbol, and correct the ladder by performing the write operation.
- (4) After the correction of a ladder, be sure to press the **[CNV]** and **[GO]** keys. Immediately after the **[GO]** key is pressed, "EXECUTING" is displayed in the message column. Upon completion of the conversion, "COMPLETED * STEP NOS. CHANGED" is displayed and the corrected ladder is displayed on the CRT.
After correction, deleted instructions automatically change to NOPs and the number of steps does not change.

POINT

When deletion is in units of ladder symbols, the succeeding step numbers of the program and the jump destination of CJ instructions are automatically changed.

- (5) If the FD automatic write operation has been set, the program in the range from the corrected step to the END is automatically stored into the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)

4. LADDER MODE




- The deletion procedure in units of ladder symbols (example) is shown below.

Deletion	Key Input	Screen Display	
		Before key input	After key input
Contact deletion	<p>DEL → → GO</p> <p>or</p> <p>DEL → → ← GO</p>		
	<p>DEL → ↓ 4P GO</p>		
	<p>DEL → ↓ 4P GO</p>		
Vertical line insertion	<p>DEL → GO</p>		

4.6 Circuit Utilization

This allows the basic layout of a frequently occurring ladder block or circuit to be repeated as required.

Enter the circuit onto the FD in advance. When required, the circuit layout entered to the FD can be utilized.




For example, suppose that the circuit layout of steps 0 to 9 in the above diagram are to be repeated at steps 103 to 112. The circuit may be "utilized" as follows.


4. LADDER MODE

4.6.1 Entry of utilized circuit


The circuit pattern, which is to be utilized, is entered onto the FD.



BASIC OPERATION




OPERATION PROCEDURE



EXPLANATION

(1) By performing the ladder read or write operation, display the circuit pattern, which is to be utilized.



- 1) "Convert" the circuit pattern (into the list pattern) and enter it to the FD as the "n"th circuit pattern (with no device specification).
- 2) Enter the circuit pattern to the FD as the "n"th circuit pattern, without making circuit conversion (no device specification).
- 3) "Convert" the circuit pattern and then enter it to the FD as the "n"th circuit pattern with device names and numbers.
- 4) Enter the circuit pattern to the FD as the "n"th circuit pattern with device names and numbers, without making ladder conversion.

REMARKS

In the above, the meanings of N and D are as follows:

N: Circuit pattern is entered to the FD without making circuit conversion.

D: Circuit pattern is entered to the FD with device name.

When the utilized circuit has been entered by pressing the **[N]** and **[GO]** keys or the **[N]**, **[D]**, and **[GO]** keys, the program is not stored in the internal memory of GPP. Therefore, when the program is required, it is necessary to read it from the FD.

- (3) A maximum of 30 circuit pattern numbers "n" (n = 0 to 29) can be entered, and circuit patterns up to two screens long can be entered as one circuit pattern number.

- (4) Before entering the utilized circuit, be sure to insert the user FD into FDD[B].
If the FD is not inserted in FDD[B], "FLOPPY DISK ERROR" is displayed in the message column.
- (5) If the number selected for the utilized circuit has already been used, the message "SYSTEM NAME ALREADY USED" is displayed.
- (6) The utilized circuit is entered onto the FD under file name KRYUUYO.DAT.

4. LADDER MODE


MELSEC-A

4.6.2 Incorporating the utilized circuit into the program


The frequently occurring circuit block pattern entered onto the FD by the procedure described in the previous section, is utilized in the program.

**CIRCUIT
UTILIZATION**

BASIC OPERATION



OPERATION PROCEDURE



- (1) Display the portion of circuit at which the entered utilized circuit, is to be inserted on the screen.
- (2) By pressing the **WR**, **+**, **L**, **Circuit pattern number "n"**, and **GO** keys, insert the circuit pattern number "n" behind the circuit block displayed.
- (3) By pressing the **WR**, **-**, **L**, **Circuit pattern number "n"**, and **GO** keys, insert the circuit pattern number "n" immediately in front of the ladder block displayed.
- (4) If the utilized circuit has been entered by pressing the **CNV**, **S**, **Circuit pattern number "n"**, **D**, and **GO** keys, the entered ladder is inserted with all device names.
If the utilized circuit does not include device and device number information, the relevant circuit symbol is displayed in the "key-in data" column. If necessary, this may be changed by keying in the appropriate data. If an instruction includes device details and is to remain unchanged and subsequent instructions are to be altered, press the **CLEAR** key and move the cursor with the **→** **↑** **↓** **←** keys to the head of the required instruction. If the instruction is of the [] type, press the [] and **GO** keys to display the original data which may then be amended; otherwise re-write the complete instruction.
- (5) After the correction of a ladder, be sure to press the **CNV** and **GO** keys. Immediately after the **GO** key is pressed, "EXECUTING" is displayed in the message column. Upon completion of the conversion, "COMPLETED * STEP NOS CHANGED" is displayed and the corrected ladder is displayed on the CRT.




POINT

When the entered circuit is utilized, the succeeding step numbers of the program and the jump destination of CJ instructions are automatically changed.

4. LADDER MODE



4.7.1 Ladder monitor Monitor in ladder mode.



EXPLANATION


- (1) A maximum of eight present values or set values of T, C, and D used in the display screen are shown at the bottom of the monitor screen. Other values can be displayed by the entry monitor operation. (Refer to Section 4.7.4.)

The monitor of present values and set values is displayed after conversion into BCD. Therefore, the display of data stored in BCD will be misleading.

Example: BCD K99 D0 The display of D0 will be 153.

- (2) While monitoring, the GPP/PHP interrupts the programmable controller CPU. Therefore, a slight delay occurs between a CPU operation and the monitored result.
- (3) By pressing the GO key, the next program area is displayed and monitored.

(4) The program area to be monitored may also be called up as follows:



(5) The **MNT** key may be pressed after the ladder read operation to monitor the ladder area READ - pressing the **GO** key will stop monitoring - pressing the **MNT** key will resume monitoring.

4. LADDER MODE


MELSEC-A

4.7.2 Stop of monitor screen



The monitor screen may be frozen during monitoring independently of the PC.

**LADDER
MONITORING**

BASIC OPERATION



OPERATION PROCEDURE



(Example: Monitor starting at step number 0 and freeze the screen by pressing **CLEAR** key)

EXPLANATION

- (1) When it is necessary to stop the monitor screen, press the **CLEAR** key. The monitor screen stops and displays the device states as they were when the **CLEAR** key was pressed. By pressing the **MNT** key again, the monitor operation is resumed.


4. LADDER MODE

4.7.3 Screen stop by setting of monitor stop point


During ladder monitoring, the screen may be frozen on the activation of a given device.

LADDER
MONITORING

BASIC OPERATION



OPERATION PROCEDURE



(Example: Stop monitor screen when T20 has timed up)

EXPLANATION

- (1) When a given device is operated, the monitor screen is frozen. The stop is triggered either by the rise (OFF → ON) or fall (ON → OFF) of the signal.
- (2) Only one stop point can be set at one time.
- (3) The stop point can be set only for devices which have an OUT instruction or contact instruction and can also be set for devices which do not appear in the current monitor screen. Inputs may also be used to define stop points.
- (4) When setting the stop point, be sure to press the  key before pressing keys to define the device.




Fig. 7.1 Stop Trigger Point


- (5) When the defined stop point changes state at high speed (e.g. pulse instruction or timer/counter which resets itself), the GPP/PHP may not be able to respond fast enough. When the stop trigger point is activated, the buzzer "beeps", and the monitor screen stops.

4. LADDER MODE




4.7.4 Entry monitor

This function is used to monitor devices which are not displayed on the monitor screen.



BASIC OPERATION



OPERATION PROCEDURE

Ladder monitor operation

— T — 5 — GO

Entry monitor of T5

— Y — 3 — 6 — GO

Entry monitor of Y30

Entry monitor display

(Example: Entry monitor of T5 and Y036)

EXPLANATION


- (1) A maximum of 8 devices may be used for entry monitor on one screen. If a 9th device is entered, the displayed devices shift to the right by one device, the 9th one is displayed at the left end, and the first one is cleared.
- (2) Set up the entry monitor as follows: **LDR** → **MNT** → **[]** → [Entered device] → **GO**
- (3) To reset the entry monitor, press **[]** and then the **GO** key. This operation deletes the entry monitor display.

4. LADDER MODE


MELSEC-A

4.7.5 Present value monitor of decimal number ↔ hexadecimal number


The monitor of present values or set values of T, C, and D displayed during ladder monitor and entry monitor operations are normally displayed in decimal. This function is used to display the required data in hexadecimal.



BASIC OPERATION




OPERATION PROCEDURE



EXPLANATION

(1) When data is displayed in hexadecimal, H is shown in front of the data.



(2) To return the hexadecimal display to decimal display, press **[K]** and then **[GO]** or press the **[MNT]** key.


4. LADDER MODE

MELSEC-A


4.8 Test Operation to Programmable Controller

4.8.1 Forcing programmable controller devices



Test operation during ladder monitor forces devices and changes the present values of T, C, and D.



BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) Forcing programmable controller devices is useful for checking the wiring from output terminals, debugging programs, etc.
- (2) Forced output operation is classified into the following four as indicated in the Basic Operation above.
 - Forced output Y
 - Forced set of temporary memory M and failure element F
 - Forced reset of temporary memory M, failure element F, timer T, counter C, and data register D
 - Changing of the present values of timer T and counter C

To change a present value in decimal, input the new value after pressing K. To make a change in hexadecimal, input the new value after pressing H.
- (3) Pressing CLEAR during a test and pressing TEST after stopping monitoring allows the execution of monitoring and the resumption of test.

POINT

- (1) If forcing a coil with the programmable controller in RUN mode, the execution of the program has priority. Therefore, if the contact driving the coil is off, the coil turns on instantaneously and then immediately turns off.
- (2) When the [SET □] instruction is used for forced set, the device remains on after the execution of the instruction and does not turn off unless reset.

4. LADDER MODE


MELSEC-A

4.8.2 K3NCPU step run


This function allows a K3NCPU program to be run step by step when the A6GPP and K3NCPU are connected together.

**LADDER
STEP RUN**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) To perform the step run, move the RUN switch of the K3NCPU to the STEP-RUN position. With the GPP/PHP, monitor the relevant ladder area to be checked using the procedure given in Section 4.7.1.
- (2) The step run is performed after the program has run at least 1 scan. It is therefore necessary to set the number of loops required. Set the number of loops in the range 1 to 9999.
- (3) By pressing the **GO** key after setting the number of loops, the programmable controller CPU runs the program according to the number of loops (The set value is displayed on the left of the screen of the GPP/PHP and "1" is subtracted from this value for every loop until it reaches 0). When processing is completed, the step run stops at the specified step number. (However, when the stop step number is a hardware processing instruction, the step run stops at the step number of the first software processing instruction below the specified number.)

When processing is complete (i.e. after the set number of loop times), the value in the LEFT column of the screen is cleared to zero and the buzzer beeps. Thereafter, each time the **GO** key is pressed, the step run is performed at each of the next software processing instructions.

"Software processing instructions" (Step run possible)

SET F	OUT F	RST Y000 to Y255	=
RST F	OUT T	CJ	+
RST C	OUT C	MOV	-
SFT M	MC	>	BCD
PLS M	MCR	<	BIN

"Hardware processing instructions" (Step run is performed at the first software processing instruction following these instructions)

LD	ANB	SET Y	RES Y256 to 7FF
LDI	OR	SET M	OUT Y
AND	ORI	RST M	OUT M
ANI	ORB	NOP	END

- (4) During step run, the 10ms timer adds "1" per scan and the 100ms timer adds "1" per 10 scans.
- (5) During step run with a data link, the K3NCPU performs a dummy communication with the linked station every 50 ms. This is because, without dummy communication, the linked station output is turned off by the "communication stop timer" in the remote I/O or local PC.
X/Y information and data information transferred through the link does not change.
- (6) If the step specified as a stop step has not been executed because it has been passed due to a CJ, interrupt program, etc., that step is not counted as one operation loop time.
For example, if at step 800, there is an instruction which causes a conditional jump to step 1200 with the stop step set to 1000 and the number of loops is 1, the processor cannot stop at the stop step.
- (7) When changing between "RUN", "STEP RUN" and "STOP" conditions it is advisable to "RESET" the CPU.
- (8) The message "K1, K2, K3 SETTING ERROR" appears if any PC other than a K3NCPU is connected to the A6GPP during this procedure.

5. LIST MODE

5.1 List Mode Introduction

List mode programming uses a set of instructions based on standard logic statements such as AND, OR etc. to build up programs. The following is an example of a program listing.


0	LD	X000	16	ANI	X1FF
1	ORI	X005	17	OUT	Y07F
2	ANI	M103	18	LD	M100
3	ANI	M211	19	AND	M102
4	ANI	X02B	20	AND	M102
5	OUT	Y070	21	AND	M105
6	LD	M120	22	AND	M107
7	ANI	M121	23	ANI	X1FE
8	LD	X001	24	OUT	Y13F
9	AND	M23	25	LD	X005
10	ORB		26	MC	K1
11	LDI	X3FF	27	LDI	M69
12	ANI	M112	28	ANI	M169
13	ORB		29	ANI	M269
14	ANI	M165	30	OUT	Y069
15	ANI	M177	31	OUT	M69

For full details on programming, see the relevant programming manual.

5.2 List Mode Functions

In list mode, the program writing, correction, reading, monitoring, and other operations are performed with the list instruction keys.

The list mode functions include the following.



5. LIST MODE

MELSEC-A


5.3 Write of Program List

5.3.1 All clear of memory (Continuous write of NOP)

To clear the program memory in list mode (i.e. write NOP to all step numbers).

**LIST
WRITE**


BASIC OPERATION



OPERATION PROCEDURE

```

0  NOP
1  NOP
2  NOP
3  NOP
4  NOP
5  NOP
6  NOP
7  NOP
8  NOP
9  NOP
10 NOP
11 NOP
12 NOP
13 NOP
14 NOP
15 NOP
16 NOP
17 NOP
18 NOP
19 NOP
20 NOP
21 NOP
22 NOP
  
```



(Example: Continuous NOP write from step numbers 0 to 4095)


EXPLANATION

- (1) If auto-write has been selected (see Section 2.3 and 7.11) then by pressing **LST** **WR** the system name setting screen described in Section 7.11 is displayed. If the auto-write function is not required press the **CR** key instead of entering a system name. Otherwise follow the procedure described in Section 7.11. This procedure is only required for the first time that the **LST** **WR** keys are pressed after auto-write has been selected.
- (2) By pressing the **LST**, **WR**, **SSN**, **Step number**, and **GO** keys, read the first step number to which the NOP instruction will be written. By pressing the **NOP**, **K**, **Step number**, and **GO** keys, the last step number is specified and the NOP write operation is performed.
- (3) The all clear operation may also be performed by pressing the **LDR**, **WR**, **Auto-write Setting**, **NOP**, and **GO** keys. However, in the all clear operation in ladder mode, the END instruction is automatically written at step 0.
- (4) When FD automatic write mode has been set and the **MELSAP** key is pressed, continuous NOPs are written to the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)


5. LIST MODE

5.3.2 Write of program list

In list mode, a program is written or corrected.



BASIC OPERATION




OPERATION PROCEDURE

```

0 LD X001
1 NOP
2 NOP
3 NOP
4 NOP
5 NOP
6 NOP
7 NOP
8 NOP
9 NOP
10 NOP
11 NOP
12 NOP
13 NOP
14 NOP
15 NOP
16 NOP
17 NOP
18 NOP
19 NOP
20 NOP
21 NOP
22 NOP
  
```

LD X001 is inserted into step 0 and the cursor moves to step 1.




(Example: Write of LD X1 to step number 0)

EXPLANATION

- (1) If auto-write has been selected (see Section 2.3 and 7.11) then by pressing **LST** **WR** the system name setting screen described in Section 7.11 is displayed. If the auto-write function is not required press the **CR** key instead of entering a system name. Otherwise follow the procedure described in Section 7.11. This procedure is only required for the first time that the **LST** **WR** keys are pressed after auto-write has been selected.
- (2) By pressing the **LST**, **WR**, **SSN**, **Step number**, and **GO** keys, read the write step number and write the instruction by performing the instruction input operation. After reading the required step number, it is possible to move the cursor by use of the **↑** and **↓** keys and then write the instruction to the line at which the cursor is located, or make correction. (After writing the instruction, the cursor automatically moves to the next step number.)

- (3) Note that certain instructions, (for example data handling) require more than one step. Hence, care must be taken when a program line is being overwritten. Note the following example:



The instruction OUT TO K100 is two steps long and is being written over OUT Y10 which is one step long. The constant, K100 is therefore written over the first part of the data handling instruction MOV D1 D2. This will cause "COMMAND ERROR" to be displayed at steps 3 and 4.

When the opposite case applies and an instruction with fewer steps is written over one with several steps, the remaining steps should be overwritten with NOP instructions.

- (4) To write NOP in the range of specified step numbers, press the **[LST]**, **[WR]**, **[SSN]**, **[Step number]**, and **[GO]** keys, thereby reading the head step number of NOP write. By pressing the **[NOP]**, **[K]**, **[Step number]**, and **[GO]** keys, the last step number is specified and the NOP write operation is performed.
- (5) When FD automatic write mode has been set and the **[MELSAP]** key is pressed, all the programs in the work area are written to the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)
- (6) If a coil with the same device number is used twice during the creation of program, "COIL ALREADY USED ERROR STEP = " is displayed in the message column. Therefore, check the error step and make correction. (When the **[GO]** key is pressed, write operation is performed even if the same coil is used twice.)

5. LIST MODE

MELSEC-A

Instruction Input Procedures

This section explains the input procedures for instructions in list mode. The instruction input procedures in list mode are classified into three types.

- (1) LD, LDI, AND, ANI, OR, ORI, OUT (except OUT T, C), MC, MCR, SET, RST, SFT, CJ, and PLS instructions (sequence instructions)

Instruction [SP] Device Device number GO

Example: LD X00 ⇒ LD [SP] X 0 GO

- (2) OUT T and C instructions (sequence instructions)

Instruction [SP] Device Device number [SP] K Set value GO

Example: OUT T0 K10 ⇒ OUT [SP] T 0 [SP] K 1 0 GO

- (3) =, <, >, +, -, MOV, BIN, and BCD instructions (data instructions)

Instruction [SP] Source data [SP] Destination GO

Example: MOV K255 D0 ⇒ MOV [SP] K 2 5 5 [SP] D 0 GO

REMARKS

In the above instruction input, the key input of [SP] can be omitted.


5. LIST MODE

MELSEC-A


5.4 Read of Program List

5.4.1 Read of list by step number

By specifying a step number, a program list containing the specified step number is displayed on the CRT.




BASIC OPERATION



OPERATION PROCEDURE

```
19 AND Y070
20 AND Y0AF
21 ORB
22 OUT F102
23 LD X2A0
24 AND X31F
25 AND X000
26 AND X07F
27 LD Y2A0
28 AND Y2DF
29 AND Y000
30 AND Y02F
31 ORB
32 OUT F103
33 LD X340
34 AND X3BF
35 AND X000
36 AND X04F
37 LD Y390
38 AND Y3BF
39 AND Y050
40 AND Y07F
41 ORB
```



Specification of step number 30.

(Example: Read of program at step number 30)

EXPLANATION

- (1) A list of 23 lines is displayed on the CRT with the specified step number located at the center.
- (2) After performing the basic operation, press the **GO** key and the next 23 lines are displayed.
By use of the **↑** and **↓** keys instead of the **GO** key, the preceding screen and the succeeding screen can be displayed, respectively.
 - 1) By pressing the **↓** key when the cursor is located at the last line, the screen is scrolled one line upward and the first line of the succeeding list is added.
 - 2) By pressing the **↑** key when the cursor is located at the top line, the screen is scrolled one line downward and the last line of the preceding list is displayed.

5. LIST MODE


MELSEC-A

5.4.2 Read of list by device

By specifying a device number, the program list containing the specified device number is displayed on the CRT.


LIST
READ

BASIC OPERATION



OPERATION PROCEDURE

```
39 AND Y050
40 AND Y077
41 ORB
42 OUT F104
43 LD X3E0
44 AND X42F
45 AND X000
46 AND X04F
47 LD Y430
48 AND Y45F
49 AND Y050
■ 50 AND Y07F
51 ORB
52 OUT F105
53 LD X460
54 AND X4AF
55 AND X000
56 AND X04F
57 LD Y480
58 AND Y4DF
59 AND Y050
60 AND Y07B
61 ORB
```



Specification of device Y7F.

(Example: Read of device Y7F)

EXPLANATION

- (1) A list of 23 lines is displayed on the CRT with the specified device number located at the center.
When the device number is used more than once in the program, the lowest step number is displayed. Then, by pressing the **GO** key, the next occurrence is displayed.
- (2) After all occurrences have been displayed, "NOT FOUND" is displayed in the message column.

5. LIST MODE


MELSEC-A

5.4.3 Read of list by instruction

By specifying an instruction, the program list containing the specified instruction is displayed on the CRT.


LIST
READ

BASIC OPERATION



OPERATION PROCEDURE

```
59 AND Y050
60 AND Y07F
61 ORB
62 OUT F106
63 LD X500
64 AND X52F
65 AND X000
66 AND X02F
67 LD Y530
68 AND Y55F
69 AND Y030
■ 70 AND Y05F
71 ORB
72 OUT F107
73 LD X570
74 AND X59F
75 AND X000
76 AND X02F
77 LD Y5A0
78 AND Y50F
79 AND Y030
80 AND Y05F
81 ORB
```



Specification of AND Y5F.

(Example: Read of instruction AND Y5F)

EXPLANATION

- (1) A list of 23 lines is displayed on the CRT with the specified instruction located at the center.
When the specified instruction is used more than once, the occurrence with the lowest step number is displayed. By pressing the **GO** key, the next occurrence is displayed.
- (2) The following instructions may be read in this way. LD, LDI, OR, ORI, AND, ANI, OUT, PLS, SFT, SET, RST, MC, and MCR.
- (3) After all occurrences have been displayed, "NOT FOUND" is displayed in the message column.

5. LIST MODE

MELSEC-A

5.4.4 Read of list with comments

The read program list is displayed on the CRT, with comments.


**LIST
READ**

BASIC OPERATION



OPERATION PROCEDURE

119	LDI	X107	START
120	ORI	X108	STOP
121	ORI	X109	STANDBY
122	OUT	M385	AUTO
123	LDI	X743	MOVABLE
124	OUT	M325	SEMI-AUTO
125	LDI	X744	BACKWORD
126	OUT	M326	FORWORD
127	LDI	X745	RESET
128	OUT	M327	AUTO
129	LDI	X743	SEMI-AUTO
130	ORI	X744	FORWORD
131	ORI	X745	ERROR
132	OUT	M392	FAILURE
133	LDI	X136	LEFT
134	OUT	M329	POSITIONING
135	LDI	X137	RIGHT
136	OUT	M330	COMPLETION
137	LDI	X138	READY
138	OUT	M331	FAILURE
139	LDI	X136	
140	ORI	X137	
141	ORI	M332	



Read of step number 130.

(Example: Read of list with comment at step number 130)

EXPLANATION

- (1) By pressing the **VER/COM** key after reading the list, the comments of devices are displayed to the right of the list display.
The comment of one device is displayed per line. (Not for the CJ instruction.)
(When the destination data of data instruction or the set value of OUT T/C instruction is data register D, the comment of T/C is displayed.)
- (2) To return the list with comments to the normal list, press the **VER/COM** key again.
Each time the **VER/COM** key is pressed, the screen repeats displaying the "normal list" and the "list with comments" alternately.
- (3) Operations such as write, insertion, and deletion cannot be performed to the list with comments. To perform such operations, therefore, return the display to the normal list.

5. LIST MODE


MELSEC-A

5.4.5 Read of device used list

The device used status in the program is displayed per specified device.



BASIC OPERATION




OPERATION PROCEDURE

DEVICE USED LIST

(-| |> = USED) (BLANK = UNUSED) (E = ERROR)

0							
Y 000	- >	1	Y 010	Y 020	Y 030	- >	1
Y 001	- >		Y 011	Y 021	Y 031		
Y 002		E	Y 012	Y 022	Y 032		2
Y 003		1E	Y 013	Y 023	Y 033		
Y 004			Y 014	Y 024	Y 034		
Y 005			Y 015	Y 025	Y 035	- >	1
Y 006			Y 016	Y 026	Y 036		
Y 007			Y 017	Y 027	Y 037		
Y 008			Y 018	Y 028	Y 038		
Y 009			Y 019	Y 029	Y 039		
Y 00A			Y 01A	Y 02A	Y 03A		
Y 00B			Y 01B	Y 02B	Y 03B		
Y 00C	- >	1	Y 01C	Y 02C	Y 03C		
Y 00D			Y 01D	Y 02D	Y 03D	- >	4
Y 00E			Y 01E	Y 02E	Y 03E		
Y 00F			Y 01F	Y 02F	Y 03F	- >	1



Specification of output Y.

(Example: Reading of devices used from output Y000 to Y03F)

EXPLANATION

- When **Device** and **Device** number are specified, a list of 64 points are displayed, beginning with the specified device number. In this case, be sure to press the or key and then press the keys in order of **Device** and **Device number**, as shown in Basic Operation. To display the specified device list of 64 points beginning with number 0, it is not required to specify the device number. (Refer to Operation Procedure.) The device used list of 64 points is displayed beginning with the head of specified devices.
- When the **GO** key is pressed after performing the Basic Operation, the device used list of the next 64 points is displayed.
- Devices which may be searched are X, Y, M, F, T, C, D, and K (for MC and MCR). (When the number of digits is specified, e.g. "K4X0", in a data instruction, a list is displayed assuming that X000 to X00F have been used.)
- In the device used list, the number of coils used () is displayed up to a maximum of 9. When the number of coils is 10 or more, "*" is displayed.
- To stop the display of device used list, press the **CLEAR** key. To resume the display, press the **GO** key. To complete the display, press the **END** and **GO** keys.
- In the device used list, displays indicated in the column, column, and Error column are as shown in the following table.

5. LIST MODE



	— — Column Display	<> Column Display	Error Condition *															
X		None																
Y M T C	LD, LDI, OR, ORI, AND, ANI Source of data instruction	OUT, SET (except T, C), RST SFT (only M), PLS (only M) Destination of data instruction	<table border="1"> <thead> <tr> <th>— —</th> <th><></th> <th>Error</th> </tr> </thead> <tbody> <tr> <td>Unused</td> <td>Unused</td> <td></td> </tr> <tr> <td>Unused</td> <td>Used</td> <td>Error</td> </tr> <tr> <td>Used</td> <td>Unused</td> <td>Error</td> </tr> <tr> <td>Used</td> <td>Used</td> <td></td> </tr> </tbody> </table>	— —	<>	Error	Unused	Unused		Unused	Used	Error	Used	Unused	Error	Used	Used	
— —	<>	Error																
Unused	Unused																	
Unused	Used	Error																
Used	Unused	Error																
Used	Used																	
K	MC	MCR																
F	LD, LDI, OR, ORI, AND, ANI	OUT, SET, RST																
D	Source of data instruction	Destination of data instruction Set value of OUT T, C																

For comparison instructions, >, = and <, both the second word and third word are treated as source and displayed in the —|— column. For other data instructions, the second word is treated as source and the third word as destination.

- There is no error display for X.
- When M254 or M255 is used for the K1 or K2 or when MA23 or MA24 is used for the K3, error is displayed.

*: Although "ERROR" may be indicated, this simply means that only coils or contacts for a given device have been used. This may not necessarily be a true error.

5. LIST MODE


MELSEC-A

5.4.6 Read of contact and coil list

The device use status in the program is displayed per specified device number.

**LIST
READ**


BASIC OPERATION



OPERATION PROCEDURE

CONTACT AND COIL LIST Y 000

STEP:LADDER SYMBOL	STEP:LADDER SYMBOL	STEP:LADDER SYMBOL	STEP:LADDER SYMBOL
0 -	13 -	30 -	50 -
100 <->	150 -[]- SET	1250 -[]- MOV	1300 -[]- MOV



Specification of output Y0.

(Example: Read of contact and coil list of output Y0)


EXPLANATION

- When the contact and coil list cannot be displayed on one screen, "DISPLAY OVERFLOW" is displayed. In this case, by pressing the **GO** key, the reset of the contact and coil list can be displayed. (A maximum of 40 pieces are displayed on one screen.)
When the display of contact and coil list has been completed, "COMPLETED" is displayed.
Then, by pressing the **GO** key, the first contact and coil list is displayed again.
- When **Device number** is omitted, the device number is regarded as zero (0).
- Devices which may be searched are X, Y, M, F, T, C, D, and K (for MC and MCR).
(When the number of digits is specified, e.g. "K4X0", in a data instruction, a list is displayed assuming that X000 to X00F have been used.)
- To stop the display of the contact and coil list, press the **CLEAR** key. To resume the display, press the **GO** key. To complete the display, press the **END** and **GO** keys.

5. LIST MODE

5.4.7 Read of T/C setting value list

The set values of timers and counters used in the program are displayed.



OPERATION PROCEDURE

T.C SETTING LIST

T	0	K 100	TC	16	TC	32	TC	48
TC	1		TC	17	TC	33	TC	49
T	2	D90	TC	18	TC	34	T	50
TC	3		C	19	K9999	TC	51	K 100
TC	4		TC	20		TC	52	
TC	5		TC	21		TC	53	
TC	6		TC	22		TC	54	
TC	7		TC	23		TC	55	
TC	8		TC	24		TC	56	K 40
T	9	K 100	TC	25		TC	57	
TC	10		TC	26		TC	58	
TC	11		TC	27		TC	59	
TC	12		T	28	K 55	TC	60	
TC	13		TC	29		TC	61	
TC	14		TC	30		TC	62	
TC	15		C	31	K 10	TC	63	K 500
						TC	64	

(Example: Read of setting value list which begins with T0 or C0)

EXPLANATION

- (1) The T/C set value list of 64 points is displayed.
- (2) By pressing the **GO** key after performing the Basic Operation, the T/C setting value list of the next 64 points is displayed.
- (3) When **T** and **Device number** are specified instead of **T** alone, the T/C setting value list of 64 points is displayed, beginning with the specified device number.

5. LIST MODE

MELSEC-A


5.5 Insertion and Deletion of Program List

5.5.1 Insertion of program list

An instruction is inserted into the program in list mode.

**LIST
INSERTION**


BASIC OPERATION




OPERATION PROCEDURE

```

19 AND Y070
20 AND Y0AF
21 ORB
22 OUT F102
23 LD X2A0
24 AND X31F
25 AND X000
26 AND X07F
27 LD Y2A0
28 AND Y2DF
29 AND Y000
30 AND Y02F
31 ORB
32 OUT F103
33 LD X340
34 AND X38F
35 AND X000
36 AND X04F
37 LD Y390
38 AND Y38F
39 AND Y050
40 AND Y07F
41 ORB
  
```



Specification of step number 29



Insertion of AND Y0

(Example: Insertion of AND /0 between step numbers 28 and 29)

EXPLANATION

- (1) By pressing the **LST**, **INS**, **SSN**, **Step number**, and **GO** keys, read the step number where the instruction will be inserted. Then by performing the instruction input operation, insert the instruction. After the step number is read, the instruction can be inserted into the line of step number, where the cursor is located, by moving the cursor by use of the **↑** and/or **↓** key. (After the instruction is inserted, the cursor automatically moves to the next step number.)
- (2) The step numbers of program located below the insertion position are shifted downward in due order. (The jump destination step number of CJ instruction is also changed automatically.)
- (3) When FD automatic write mode has been set and the **MELSAP** key is pressed, all the programs in the work area are written to the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)

5. LIST MODE


MELSEC-A

5.5.2 Deletion of program list

The specified instruction is deleted from the program.

**LIST
DELETION**


BASIC OPERATION



OPERATION PROCEDURE

```

39 AND Y050
40 AND Y07F
41 ORB
42 OUT F104
43 LD X3E0
44 AND X42F
45 AND X000
46 AND X04F
47 LD Y430
48 AND Y45F
49 AND Y050
50 AND Y07F
51 ORB
52 OUT F105
53 LD X460
54 AND X4AF
55 AND X000
56 AND X04F
57 LD Y4B0
58 AND Y4DF
59 AND Y050
60 AND Y07F
61 ORB
  
```



The line of step number 50 is deleted and the succeeding instructions are shifted upward.

(Example: Deletion of program at step number 50)

EXPLANATION


- (1) By pressing the **LST**, **DEL**, **SSN**, **Step number**, and **GO** keys, the step number to be deleted is read. Then, by pressing the **GO** key, that line is deleted. After the step number to be deleted is read, the cursor may be moved by use of the **↑** and/or **↓** key and the line, where the cursor is located, can be deleted.
- (2) The step numbers of program located below the deletion position are shifted upward in due order.
(The jump destination step number of CJ instruction is also changed automatically.)
- (3) To delete NOPs in the program in blocks, press the **LST**, **DEL**, **NOP**, and **GO** keys to delete all the NOPs from step 0 to END, thereby shifting the program upward.
- (4) When FD automatic write mode has been set and the **MELSAP** key is pressed, all the programs in the work area are written to the FD. (For automatic write to the FD, refer to Sections 2.3 and 7.11.)

5. LIST MODE


5.6 Conversion of Devices

5.6.1 Batch change of devices

Changes the device types and numbers for a specified series of elements.



OPERATION PROCEDURE



EXPLANATION

- (1) By pressing the **LST** and **CNV** keys, the screen shown above is displayed on the CRT. By use of the **↑** and/or **↓** key, move the cursor to "BATCH DEVICE CONVERSION" and then perform the Basic Operation. This changes the device numbers for the specified elements. (If a device number outside the range is specified, "DEVICE NUMBER ERROR" is displayed.)
- (2) When **K** and **Quantity** are specified during the Basic Operation, the quantity is specified in decimal. When **H** and **Quantity** are specified, the quantity is specified in hexadecimal.
- (3) When the batch change of devices is made, the comments are also changed at the same time provided the comments are within the new set range. (In the Operation Procedure example, 16 comments of X000 to X00F are changed to the comments of M30 to M45 and the comments of X000 to X00F remain unchanged.)
- (4) The step range, in which the batch change of devices will be made, can be specified. The specifying method is as shown below:

LST **CNV** **Device** **Device number** **SP** **Device** **Device number** **SP**

K **Quantity** **SP** **Start step number** **SP** **Final step number** **GO**

Step range specification

(When the **END** key is pressed instead of the final step number, change is made from the start step number to the END instruction.)

- (5) When FD automatic write mode has been set and the **MELSAP** key is pressed, all the programs in the work area are written to the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)

5. LIST MODE

(6) Convertible device list

(Meanings of symbols)

1. ○ : Convertible
2. × : Not convertible
3. △ : The third word is not convertible.
4. For instance, in regards to LD among the instructions in the first line, LD X can be converted into LD Y, LD M, LD F, LD T, or LD C. However, it cannot be converted into LD D.
5. All columns of OUT instruction in the second line are provided with the X marks because the device X does not have the OUT X instruction.

Device before conversion: X

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	○	○	○	○	○	○	×
OUT	×	×	×	×	×	×	×
SET	×	×	×	×	×	×	×
RST	×	×	×	×	×	×	×
SFT, PLS	×	×	×	×	×	×	×
MOV, BCD, BIN, +, -	○	○	○	×	×	×	×
=, >, <	○	○	○	×	×	×	×
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	×

Device before conversion: Y

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	○	○	○	○	○	○	×
OUT	×	○	○	○	×	×	×
SET	×	○	○	○	×	×	×
RST	×	○	○	○	×	×	×
SFT, PLS	×	×	×	×	×	×	×
MOV, BCD, BIN, +, -	△	○	○	×	×	×	×
=, >, <	○	○	○	×	×	×	×
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	×

Device before conversion: M

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	○	○	○	○	○	○	×
OUT	×	○	○	○	×	×	×
SET	×	○	○	○	×	×	×
RST	×	○	○	○	×	×	×
SFT, PLS	×	×	○	×	×	×	×
MOV, BCD, BIN, +, -	△	○	○	×	×	×	×
=, >, <	○	○	○	×	×	×	×
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	×

5. LIST MODE



Device before conversion: F

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	○	○	○	○	○	○	×
OUT	×	○	○	○	×	×	×
SET	×	○	○	○	×	×	×
RST	×	○	○	○	×	×	×
SFT, PLS	×	×	×	×	×	×	×
MOV, BCD, BIN, +, -	×	×	×	×	×	×	×
=, >, <	×	×	×	×	×	×	×
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	×

Device before conversion: T

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	○	○	○	○	○	○	×
OUT	×	×	×	×	○	×	×
SET	×	×	×	×	×	×	×
RST	×	×	×	×	×	×	×
SFT, PLS	×	×	×	×	×	×	×
MOV, BCD, BIN, +, -	×	×	×	×	○	○	○
=, >, <	×	×	×	×	○	○	○
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	×

Device before conversion: C

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	○	○	○	○	○	○	×
OUT	×	×	×	×	×	○	×
SET	×	×	×	×	×	×	×
RST	×	×	×	×	×	○	×
SFT, PLS	×	×	×	×	×	×	×
MOV, BCD, BIN, +, -	×	×	×	×	○	○	○
=, >, <	×	×	×	×	○	○	○
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	×



Device before conversion: D

Instruction	Devices after conversion						
	X	Y	M	F	T	C	D
LD, LDI, OR, ORI, AND, ANI	×	×	×	×	×	×	×
OUT	×	×	×	×	×	×	×
SET	×	×	×	×	×	×	×
RST	×	×	×	×	×	×	×
SFT, PLS	×	×	×	×	×	×	×
MOV, BCD, BIN, +, -	×	×	×	×	○	○	○
=, >, <	×	×	×	×	○	○	○
Set value of OUT T/C (indirect specification)	×	×	×	×	×	×	○

5. LIST MODE

5.6.2 Batch conversion of "N/O" and "N/C" contacts

This function allows the logic of contacts to be reversed, i.e. Normally open (N/O) contacts become normally closed (N/C) and vice versa.



EXPLANATION

- (1) By pressing the **LST** and **CNV** keys, the screen shown in the Operation Procedure is displayed on the CRT. By use of the **↑** and/or **↓** key, move the cursor to "BATCH N/O, N/C CONVERSION" and then perform the Basic Operation. This reverses the state of the device contact, i.e.:
 LD, OR, and AND are changed to LDI, ORI, and ANI, respectively.
 LDI, ORI, and ANI are changed to LD, OR, and AND, respectively.
- (2) The step range, in which the batch change of "N/O" "N/C" contacts will be made, can be specified. The specifying method is as shown below:

LST **CNV** **↓** **Device** **Device number**

SP **Start step number** **SP** **Final step number** **GO**

Step range specification

(When the **END** key is pressed instead of the final step number, change is made from the start step number to the END instruction.)

- (3) When FD automatic write mode has been set and the **MELSAP** key is pressed, all the programs in the work area are written to the FD. (For the automatic write operation to the FD, refer to Sections 2.3 and 7.11.)

5. LIST MODE


5.7 List Monitor

5.7.1 Batch monitor of devices

In list mode, a batch of devices (X, Y, M, F, K for MC, MCR, T, C, or D) may be monitored.




BASIC OPERATION



OPERATION PROCEDURE

* BATCH MONITORING LIST *

D 0	1234	D 8	0	D 16	0	D 24	0	D 32	0
D 1	0	D 9	0	D 17	10	D 25	0	D 33	0
D 2	0	D 10	0	D 18	12	D 26	1000	D 34	0
D 3	0	D 11	0	D 19	13	D 27	999	D 35	10
D 4	32000	D 12	10	D 20	14	D 28	11	D 36	15
D 5	0	D 13	11	D 21	0	D 29	23	D 37	10000
D 6	0	D 14	100	D 22	0	D 30	100	D 38	60000
D 7	0	D 15	0	D 23	0	D 31	11	D 39	0



(Example: Batch monitor of devices from D0 to D39)

EXPLANATION

POINT

Any elements (X, Y, T, C, etc.) monitored will not be in real-time.

- (1) For X, Y, M, F, and K, 112 points are displayed on one screen with their respective ON/OFF states. (Refer to Fig. 5.1.)
For T and C, 16 points are displayed on one screen with the ON/OFF states of contacts and coils and the set values and present values. (Refer to Fig. 5.3.)
For D, 40 points are displayed on one screen with the data register values. (Refer to Fig. 5.2.)
- (2) The present values of device D and the set values and present values of T/C are displayed in decimal. By pressing the **[H]** and **[GO]** keys, these values are displayed in hexadecimal. By pressing the **[BIN]** and **[GO]** keys, these values are displayed in binary. To return the values to decimal numbers, press the **[K]** and **[GO]** keys.
- (3) Device T/C is displayed as T or C when used for OUT T or OUT C, respectively. Otherwise, it is displayed as TC.
- (4) During batch monitoring of devices, the verify operation is not performed.
- (5) Batch monitoring is stopped by pressing the **[CLEAR]** key.




Fig. 5.1 Batch List Monitor of Y




Fig. 5.2 Batch List Monitor of D




Fig. 5.3 Batch List Monitor of T(C)


5. LIST MODE

5.7.2. Display of device memory contents in GPP/PHP

Allows the device memory contents of the PC to be stored in the GPP/PHP. Hence the states and/or data of all devices may be read from the PC to the GPP/PHP and these values will remain in their read state (i.e. they are not monitored.)




BASIC OPERATION



OPERATION PROCEDURE

* BATCH MONITORING LIST *

D 0	1234	D 8	0	D 16	0	D 24	0	D 32	0
D 1	0	D 9	0	D 17	10	D 25	0	D 33	0
D 2	0	D 10	0	D 18	12	D 26	1000	D 34	0
D 3	0	D 11	0	D 19	13	D 27	999	D 35	10
D 4	32000	D 12	10	D 20	14	D 28	11	D 36	15
D 5	0	D 13	11	D 21	0	D 29	23	D 37	10000
D 6	0	D 14	100	D 22	0	D 30	100	D 38	60000
D 7	12	D 15	0	D 23	0	D 31	11	D 39	0



Example: Display of the contents of device memory inside GPP/PHP from D0 to D39

EXPLANATION

- Applicable devices are Y, M, F, K (for MC, MCR), T, C, and D as described below.
For Y, M, F, and K, 112 points are displayed on one screen with the relevant ON/OFF states. (Refer to Fig. 5.1.)
For T and C, 16 points are displayed on one screen with the relevant ON/OFF states of contacts and coils and the set values and present values. (Refer to Fig. 5.3.)
For D, 40 points are displayed on one screen with the relevant data register values. (Refer to Fig. 5.2.)
- The present values of device D and the set values and present values of T/C are displayed in decimal. By pressing the **[H]** and **[GO]** keys, these values are displayed in hexadecimal. By pressing the **[BIN]** and **[GO]** keys, these values are displayed in binary. To return the values to decimal numbers, press the **[K]** and **[GO]** keys.
- Device T/C is displayed as T or C when used for OUT T or OUT C. In other cases, it is displayed as TC.
- If it is necessary to store the data in the GPP/PHP memory, this may be done using the FD.


6. PC MODE

6. PC MODE

PC mode allows communication between the GPP/PHP and programmable controller (GPP/PHP connected to the programmable controller).

6.1 Functions in PC Mode

The functions in PC mode are indicated below:



6.2 Menu Selection in Write, Read, and Verify




Fig. 6.1

- (1) By pressing the **PC** and function (**WR**, **RD**, or **VER**) keys, the screen shown in Fig. 6.1 is displayed. By use of the **↑**, **↓**, **→**, and/or **←** key, move the cursor to the item required and press the **GO** key. "*" is displayed at the position of the item which is to be executed.

REMARKS

Menu selection items are as described below, and are classified into:—

- 1) Program, device (Y, M, T, C, F, D, K)Range setting required
- 2) All area of device memory, comment, file registerRange setting is not required

- (2) When "ALL AREA" is specified, "PRESS <GO>, WHEN []" ([] = "WRITE" "READ", or "VERIFY") is displayed above the mode column. By pressing the **GO** key, "EXECUTING" is displayed in the message column. During execution, "* * *....." is displayed (not for verify) above the mode column indicating execution progress. When execution is completed, "COMPLETED" is displayed.

REMARKS

The "*" indicates 512 steps. In the case of a 4K-step sequence program, eight are displayed, and each time 512 steps are completed, one mark disappears.




Fig. 6.2

- (3) If range setting is required, the screen shown in Fig. 6.2 is displayed. Using the and/or key, move the cursor to "ALL AREA" or "RANGE SETTING" as required and press the key. The "*" mark is displayed at the selected position.

When "RANGE SETTING" has been selected, move the cursor to "START" and "FINAL" by use of the and/or keys, set the required numbers, and press the key.


"PRESS (GO), WHEN " is then displayed above the mode column. Press the key and "EXECUTING" is displayed in the message column. During execution, "* * *....." is displayed above the mode column. When execution is completed, "COMPLETED" is displayed.

- (4) If it is necessary to make a correction, press the key after the completion of setting, "PRESS (GO), WHEN " is displayed. By using the and/or key, the cursor may be moved to the data to be corrected.


6. PC MODE

6.3 Write to Programmable Controller

The internal memory contents of the A6GPP are written to the programmable controller CPU.



BASIC OPERATION



OPERATION PROCEDURE

* MEMORY AREA SELECTION *

MEMORY	DEVICE MEMORY
* PROGRAM	ALL AREA(W/O.Y)
COMMENT	X, Y
FILE REGISTER	M
	T, C
	F
	D
	K

(PROGRAM) is selected. (RANGE SETTING) is selected.

Step 0 to step 4095 are set. Write is executed.

(Example: Key operation when the range setting of program has been selected)

EXPLANATION

- (1) This writes the internal memory contents of A6GPP to the programmable controller CPU. This includes program, comments, file register, and device memory. (Write of Y cannot be performed.)
- (2) Before performing the write operation to the programmable controller CPU, be sure to move the WRITE IN CPU switch to the PERMIT Position. If the switch is located at the FORBID position, "WRITE-IN FORBIDDEN" is displayed.
(There are other communication error messages, refer to the error message list in Section 15.)
- (3) When non-coincidence occurs during the write operation, "WRITE-IN ERROR" is displayed.
- (4) When the write operation to a PC which is in RUN mode is performed, "PRESS (Y) TO WRITE TO PC WHILE IT IS RUNNING, PRESS (N) TO STOP" is displayed. Pressing the **Y** key causes the write operation to be performed during run.

POINT

It is recommended to restrict this write operation in RUN mode to changing the set values of timers/counters. Write operations which do not involve changing step numbers, such as changing "N/O" and "N/C" contacts and X, Y, M, etc., can be performed. However, such operation may cause control trouble.


Write operations which do involve changing step numbers in RUN mode may cause a CPU error, which stops the execution of the program and causes the RUN lamp to flicker. If this should occur, set the CPU to "STOP" mode before performing the write operation.

- (5) When the verify operation is performed after writing the file register or device memory, perform the verify operation in STOP state.
(Reason: In RUN mode, the file register and device memory will change, giving a non-coincidence error.)


6. PC MODE

6.4 Read from Programmable Controller

The memory contents of programmable controller CPU are read to the internal memory of GPP/PHP.



BASIC OPERATION



OPERATION PROCEDURE

* MEMORY AREA SELECTION *

MEMORY	DEVICE MEMORY
* PROGRAM	ALL ARER
COMMENT	Y
FILE REGISTER	M T, C F D K

■ PRESS (GO). WHEN READ

(Example: Key operation when the range setting of program has been selected)


EXPLANATION

- (1) The memory contents of programmable controller CPU are read to the internal memory of GPP/PHP.
This includes the program, comments, file register, and device memory.
- (2) The programmable controller CPU can be in either RUN or STOP mode. However, when the device memory is read from the programmable controller CPU in STOP mode, the device memory for Y is read with all Ys OFF.
- (3) To perform the verify operation after reading the file register or device memory, set the CPU to STOP mode and then perform the read and verify operations.
(Reason: While in RUN mode, the file register and device memory will be changing, resulting in a non-coincidence error.)

6. PC MODE

6.5 Verify with Memory Contents of Programmable Controller

The memory contents of programmable controller CPU and GPP/PHP are verified.



BASIC OPERATION




OPERATION PROCEDURE

* MEMORY AREA SELECTION *

MEMORY	DEVICE MEMORY
* PROGRAM	ALL AREA(W/O.Y)
COMMENT	Y
FILE REGISTER	M
	T, C
	F
	D
	K

■ PRESS <GO> WHEN VERIFY



(Example: Key operation when the range setting of program has been selected)



EXPLANATION

- (1) The verify operation is performed between the memory contents of the programmable controller CPU and the internal memory contents of the GPP/PHP. This includes the program, comments, file register, and device memory.
- (2) Verifying of program and comment can be carried out with the PC in RUN mode. However, verification of file register of device memory with the PLC in RUN mode, may result in non-coincidence error because their values are constantly changing. Therefore, perform verification of file register and device memory in STOP mode.
- (3) When there are several non-coinciding portions after the verify operation, the non-coinciding ladder block with the lowest step number, the two pieces of non coincident data, and the number of remaining noncoinciding portions are displayed above the mode column. By pressing the **GO** key, the contents of the next non-coinciding portion is displayed.
A maximum of 32 non-coinciding portions may be displayed. If more than 32 non-coinciding portions are suspected, correct the first 32 non-coinciding portions and then perform the verify operation again.
- (4) When the set value of a device range does not coincide after verifying comments, only the contents of the non-coinciding portion (the head number of device and the number of points) are displayed and the verify operation of comment data is not performed.
When there are no non-coinciding portions in the device range set values of comments but the comment data does not coincide, the comment data of non-coinciding portions are displayed.
A maximum of 16 non-coinciding portions in the comment data may be displayed. If there are more than 16 non-coinciding portions, "NO. OF MISMATCHES" is displayed in the message column. By pressing the **GO** key, the succeeding non-coinciding portions are displayed.
- (5) If non-coincidence has occurred in the verify operation of file register and device memory, "NO. OF MISMATCHES" is displayed in the message column.


6. PC MODE

6.6 Test to Programmable Controller

The test operation to the programmable controller CPU is useful for checking wiring from output terminals, for debugging programs, and for fault finding should any errors occur in the PC.



OPERATION PROCEDURE



EXPLANATION

(1) The following five functions are available:

- Forced output of device Y
- Forced set of temporary memory M and failure number F
- Forced reset of temporary memory M, failure number F, timer T, counter C, and data register D
- Change of the present values of timer T and counter C and change of the contents of data register D
- Detection of error step and error number if an error has occurred in the programmable controller CPU.

REMARKS

For the meaning of error numbers, refer to the Instruction Manual of each CPU. Conventionally, the error number is indicated by four digits. When the A6GPP is used for the K3NCP, however, the error number may be indicated in five digits. For example, FA26 is indicated 16026.

The upper two digits of the above appear in hexadecimal as defined below:

A: 10, B: 11, C: 12, D: 13, E: 14, F: 15

POINT


- (1) When forcing outputs in RUN mode, the execution of the program has priority.
(When the **GO** key is pressed repeatedly after performing the Basic Operation, ON and OFF are repeated alternately.)
- (2) When the instruction is **-(SET:)-** and this device is forced, it remains on after the execution of the instruction and does not turn off unless it is reset.
- (3) If the present value is changed after a timer has timed up or a counter has counted up and the present value is smaller than the set value, the timer or counter does not start to re-count.
- (4) When error steps have been detected, performing the Basic Operation and then pressing the **GO** key displays the error steps in due order.
- (5) Up to 20 lines are displayed in the result column on the right hand side of the display. When the 21st is set, the contents of the first line are cleared and the screen scrolls up.
The RESULT display is deleted by pressing the **SSN** key.

7. FDD MODE

In FDD mode, communication is made between the FDs, which are loaded in two FDDs mounted to the GPP/PHP, and the internal memory of the GPP/PHP.

7.1 FDD Functions and File Names

7.1.1 FDD functions



REMARKS

For FDD operations the MELSAP (upper) Keyboard is used.

POINT

- (1) Data which can be written to the FD with the FDD operation, are the main program, comment, device memory, file register (only K3NCPU), and printer data.

The internal memory of A6GPP is not backed up by a battery. Therefore, when the power is turned off or reset is performed, the contents of internal memory are erased. Be sure to store the contents of internal memory of A6GPP into the FD after the creation or correction of program. More convenience is offered by setting the FD automatic write function.

The storage method of utilized circuits is not included in FDD mode. Refer to Section 4.6.

- (2) FD data storage capacity.

The usable memory area per FD is 640K bytes.

Main program1K step → 2K bytes
	Example: 16K steps → 32K bytes
Comment32K bytes (fixed)
Data memory8K bytes (variable)
File register8K bytes (fixed)
Utilized ladder80K bytes (fixed)

For example, when all data is stored on the FD for the K3NCPU, a total of 160K (32K + 32K + 8K + 8K + 80K) bytes are used. However, if a small amount of data is stored, a maximum of 128 file names can be used. More than 128 file names cannot be stored.

7.1.2 Structure and contents of file name

- (1) The file name is always necessary when data, such as program, is stored onto the FD. It is an index to the files on the FD.
- (2) Structure of file name ⇒ System name . Identifier
- (3) The system name is set by the user. Alphanumeric characters and the – (minus) key are effective and a maximum of eight characters can be entered. (Space cannot be used.) The first character should always be an alphabetic character.

(4) The identifier indicates the type of file contents. It is automatically added to the system name.

Identifier	Description
MPR	Main program
COT	Comment
ADM	File register
ADM	All area
ADM	Output
ADM	Temporary memory
ADM	Timer, counter
ADM	Failure number
ADM	Data register
ADM	K

POINT


When printer data entry is made, a file name "PRINTERK. DAT" is automatically written (fixed).

7. FDD MODE


MELSEC-A

7.2 Directory

The directory of file names of programs stored on the FD is read.



BASIC OPERATION



OPERATION PROCEDURE

* FILE DIRECTORY *

DRIVE B:

NO.	FILE NAME	SECTORS	COMMENT
1	TR1 .MPR	252	DEMO
2	TR2 .MPR	252	
3	TR3 .MPR	252	DEMO DATA 5
4	TR4 .MPR	252	DEMO SHIFT
5	TR5 .MPR	252	CLOCK

LINE 15

SHIFT

```


            graph LR
              FDD[FDD] --> CR1[CR]
              CR1 --> T[T]
              T --> R[R]
              R --> Asterisk[*]
              Asterisk --> Greater[.>]
              Greater --> Model[Model name]
              Model --> M[M]
              M --> P[P]
              P --> R2[R]
              R2 --> CR2[CR]
              CR2 --> Identifier[Identifier]
          
```

(Example: Directory of system name called TR)

EXPLANATION

- (1) Read the directory of file names of programs stored on the FD. 15 lines are displayed on the screen. When there are more than 15 file names, press the **CR** key again. The next 15 lines are displayed.
- (2) There are two types of directory reading procedures. One is to read all file names by performing the operation of **FDD** → **CR** → **CR** keys as shown in the Basic Operation. The other is to read only the specified file name by performing the operation of **FDD** → **CR** → **Specified file name** → **CR** keys.


(3) Flow of display screen



POINT


Reading procedures when you are uncertain of the file name

- (1) You are uncertain of the full system name (a maximum of eight characters) stored in the FD in drive B and you know only the first three characters and also that the identifier is the main program.



All the file names, of which first three characters of system name are X, Y, and Z and the identifier is the main program, are read.

- (2) The system name stored in the FD in drive B is unknown and the identifier is the main program.



All the file names, of which identifier is the main program, are read.

- (4) By pressing the [CAN] key, the "FUNCTION SETTING" screen is restored.


7. FDD MODE

7.3 Read from FD [I]

Required data is read from the FD to the internal memory of the A6GPP.

**FDD
READ[I]**

BASIC OPERATION




OPERATION PROCEDURE

* MEMORY AREA SELECTION *

MEMORY	DEVICE MEMORY
* PROGRAM	ALL AREA
COMMENT	Y
FILE REGISTER	M
	T, C
	F
	D
	K

■ PRESS <GO> .WHEN READ



(Example: Read of the data of system name called TR1)


EXPLANATION

- (1) If the power is turned off or reset is performed, the contents of internal memory of A6GPP will be cleared. Therefore, it is necessary to read required data (other than programs and comments) from the FD.
- (2) During the read operation, "EXECUTING" is displayed in the message column on the CRT. Upon completion, "COMPLETED" is displayed.
- (3) To return to the "SYSTEM NAME SETTING" screen after the completion of operation, press the **[CAN]** key.
- (4) To return to a function other than the FDD function, return the CRT to the "SYSTEM NAME SETTING" screen and then press the **[CAN]** key again. This returns the CRT to the "FUNCTION SETTING" screen.

When the PC type, which has been set in the initial screen during the write operation to the FD, and the PC type, which has been set during the read operation from the FD, do not coincide with each other, "PC SELECTION ERROR" message is displayed when the execution of read operation is initiated. To continue the read operation, press the **[CR]** key again.

7. FDD MODE


(5) The flow of display screen is as shown below.




7. FDD MODE

7.4 Read from FD [II] (For program)

Program is read from the memory area of FD to the internal memory of A6GPP.




BASIC OPERATION



OPERATION PROCEDURE

```

<RANGE SETTING> MAIN PROGRAM
ALL AREA
*RANGE SETTING
START      = 0
FINAL      = 1023
START FOR GPP = 0
    
```



Example: Store the program of system name TR1 from step 0 to step 1023 into the internal memory of A6GPP, starting at step 0.

EXPLANATION

(1) When "PROGRAM" has been selected on the "MEMORY AREA SELECTION" screen, the "RANGE SETTING" screen is displayed.

To read all programs of the specified system name from the FD and store them into the program area of A6GPP memory, starting at step 0.

To specify the program range of the specified system name and store it into the program area of A6GPP memory, starting at the specified step.

```

<RANGE SETTING> PROGRAM
ALL AREA
RANGE SETTING
START      = [ ]
FINAL      = [ ]
START FOR GPP = [ ]
    
```

Specified memory area display

Specification of read start step


Specification of read final step

Specification of start step where program will be stored (internal memory of A6GPP)

7. FDD MODE



(2) By read operation, it is possible to edit two or more programs stored on the FD.




As shown at left, it is possible to edit two programs on the FD into one.

- (1) If programs to be edited exceeded the memory capacity selected in the initial data setting, "OPERATOR ERROR" is displayed. Therefore, check the memory capacity. (In the example shown at left, since the programs to be edited have a total of 2024 steps, it is necessary to set the capacity to more than 2K steps.)
- (2) In FD read mode, execute read in order of 1 and 2.

*1: In the example shown at left, since END of main program 1 is at step 1023, step 0 of main program 2 is written, starting at step 1023, to merge two programs into one.

- (3) During the read operation, "EXECUTING" is displayed in the message column on the CRT. Upon completion, "COMPLETED" is displayed.
- (4) To return to the "SYSTEM NAME SETTING" screen during operation, press **CAN**.
- (5) To select a function other than FDD, return the CRT to the "SYSTEM NAME SETTING" screen and then press **CAN** again. This returns the CRT to the "FUNCTION SELECTION" screen.
- (6) The sequence of display screens is as shown below.






POINT

- (1) If the following operations are performed for range setting, "OPERATOR ERROR" is displayed. Input correct data again.
 - 1) Start step is larger than final step.
 - 2) Specified step number exceeds the program capacity as set in the initial data setting.
- (2) If range setting data has an error, move the cursor to the incorrect data and press **HOMECLR**.
- (3) When a program is read with the range specified, only the set values of timers and counters used in the specified range are read.

7. FDD MODE


7.5 Read from FD [III] (For comment)

Comment data is read from the memory area of FD to the internal memory of A6GPP.



EXPLANATION

(1) When "COMMENT" has been selected on the "MEMORY AREA SELECTION" screen, the "RANGE SETTING" screen is displayed.



- (2) Error messages displayed during range setting operation and their definitions are as described below.

Description	Error Message
Special M or D has been specified at "DEVICE." (Special M and D cannot be specified.)	OPERATOR ERROR
Comment range has not been set in A6GPP comment mode for that device.	DEVICE READOUT ERROR (When device has been specified) or DEVICE NOT FOUND
Comment range selected in FDD read does not match the range initially set in A6GPP comment mode.	DEVICE NO. ERROR (When device number has been specified)
Comment range (start number to final number), which does not exist on FD, has been specified.	COMMENT RANGE UNMATCHED (When CR has been pressed)

REMARKS

If range setting data has an error, move the cursor to the incorrect data and press **HOMECLR**.

- (3) If no comment ranges have been set in comment mode before the comment data is read from the FDD, "all area" must be selected on the range setting screen.


If "Range setting" is attempted for reading the comment data without having previously defined the usable comment range in comment mode, "DEVICE READOUT ERROR" or "DEVICE NOT FOUND" is displayed.

7. FDD MODE

MELSEC-A

7.6 Write to FD

The contents of the internal memory of the A6GPP are written to the FD.




BASIC OPERATION



OPERATION PROCEDURE

* MEMORY AREA SELECTION *	
MEMORY	DEVICE MEMORY
* PROGRAM	ALL AREA
COMMENT	Y
FILE REGISTER	M
	T, C
	F
	D
	K

■ PRESS (GO) WHEN WRITE



(Example: Storage of the main program inside A6GPP to the FD as system name TR1)


EXPLANATION

- (1) When the power is turned off or reset is performed, the contents of the internal memory of the A6GPP will be cleared. Therefore, be sure to write the contents to the FD. Data which may be written are the main program, comment, device memory, and file register.
- (2) To return to the "SYSTEM NAME SETTING" screen after the completion of operation, press the **CAN** key.
- (3) To return to a mode other than the FDD mode, return the CRT to the "SYSTEM NAME SETTING" screen and then press the **CAN** key again. This returns the CRT to the "FUNCTION SETTING" screen.
- (4) The following system names are reserved and should not be used for general program storage etc:
 KRUYO
 CPM
 PRINTERK

POINT

When "WRITE-IN ERROR" or "TOO LARGE FOR MEMORY CAPACITY" is displayed during the write operation to the FD, the remaining memory capacity of the FD is insufficient. In this case, check the directory, delete any unnecessary files, and perform the write operation again.

(4) The flow of display screen is as shown below.



REMARKS

- (1) Utilized circuits can also be written to the FD. However, this operation is not performed in FDD mode. Refer to Section 4.6.
- (2) In FDD mode, FD automatic write function is also available. Refer to Section 7.11 and 2.3.
- (3) The system name is made up of a maximum of 8 characters. (First character must be a letter)
- (4) The comment, which is displayed next to the system name in the directory listing, is made up of a maximum of 20 characters.

7. FDD MODE

7.7 Verify with FD

The contents of the internal memory of the A6GPP and the contents of the FD are verified.




BASIC OPERATION



OPERATION PROCEDURE

X MEMORY AREA SELECTION X	
MEMORY	DEVICE MEMORY
* PROGRAM	ALL AREA
COMMENT	Y
FILE RESISTER	M
	T, C
	F
	D
	K


■ PRESS (GO) WHEN VERIFY



EXPLANATION

- (1) When the contents coincide with each other as a result of the verify operation, "COMPLETED" is displayed. When they do not coincide, "DATA UNMATCHED" is displayed.
- (2) To return to the "SYSTEM NAME SETTING" screen during the operation, press the **CAN** key.
- (3) To return to a mode other than FDD mode, return the CRT to the "SYSTEM NAME SETTING" screen and then press the **CAN** key again. This returns the CRT to the "FUNCTION SETTING" screen.

(4) The flow of display screen is as shown below.




- (5) When the programs in the A6GPP and on the FD are not identical, a portion of ladder diagram is displayed corresponding to the part of the program which has not been verified. If the two programs have several differences, the message "NO. OF MISMATCHES [n]" is displayed (where n is the number of different instructions between the two programs.) and the first portion of non-verified ladder is displayed. Pressing the [CR] key will cause the remaining non-verified ladder portions to be displayed in order. The maximum number of non-verified instructions which may be recognized is 32, if more than this number are suspected, the first 32 should be corrected and the verify procedure repeated. The display for a non-verified command includes two columns headed GPP and FDD, the instructions under these represent the two respective pieces of non-coincident data.
- (6) When the set value of device range does not coincide when using comments, only the contents of non-coinciding portion setting between the GPP and FD (the head number of device and the number of points) are displayed and the verify operation of comment data is not performed. When there are no non-coinciding portion in the device range set values of comments but the comment data does not coincide, the comment data of non-coinciding portions between the GPP and FD are displayed. A maximum of 16 non-coinciding portions in the comment data are displayed. If more than 16 non-coinciding portions are suspected, pressing the [CR] key causes the succeeding non-coinciding portions to be displayed.
- (7) When the PC type, which has been set in the initial screen, and the PC type, which has been set during the read operation from the FD, do not coincide with each other, "PC SELECTION ERROR" error message is displayed when the execution of verify operation is initiated. To continue the read operation, press the [CR] key again.


7. FDD MODE



7.8 Detetion of File on FD Deletion of unnecessary files on the FD.



BASIC OPERATION



OPERATION PROCEDURE

* FILE NAME SETTING *

FILE NAME	TR15, MPR
-----------	-----------

■ PRESS (CR) WHEN DELETE

DRIVE B

```


            graph TD
              FDD --> A[↓]
              A --> B[↓]
              B --> C[↓]
              C --> D[↓]
              D --> CR1[CR]
              CR1 --> T[T]
              T --> R[R]
              R --> 1[1]
              1 --> 5[5]
              5 --> dot[.]
              dot --> CR2[CR]
              CR2 --> M[M]
              M --> P[P]
              P --> R2[R]
              R2 --> CR3[CR]
              CR3 --> CR4[CR]
          
```

Identifier is the program.

EXPLANATION

- (1) When all memory areas in the FD have been used and further memory is required, memory area may be freed by deleting unnecessary files.
- (2) If a file name has been selected and the **CR** key pressed, the deletion procedure may be aborted by pressing the **↑** key. This allows the file name to be changed as required.
- (3) When the **CAN** key is pressed during the operation, the CRT returns to the "FUNCTION SETTING" screen.

(4) The flow of display screen is as shown below.



POINT
To delete print data, specify file name "PRINTERK.DAT".

7. FDD MODE


MELSEC-A

7.9 File Copy

The file copy operation is used to copy the contents of the specified file from the specified FDD.

**FDD
COPY**

BASIC OPERATION 1 (GPP)




OPERATION PROCEDURE 1-1

* SYSTEM NAME SETTING *

	FROM	TO
DRIVE	A	B
SYSTEM NAME	TR 15	TR 15

■ PRESS (CR) WHEN COPY



EXPLANATION

(1) Combinations for copy operation are as follows:

Copy from FDD **A** to FDD **B**

Copy from FDD **B** to FDD **A**


Copy from FDD **A** to FDD **A** (Copy inside the same FD)

Copy from FDD **B** to FDD **B** (Copy inside the same FD)


(2) When the copy operation is performed between two FDDs, e.g. from FDD **A** to FDD **B** or FDD **B** to FDD **A**, the system name of copy destination (TO) may be different from that of copy source (FROM). However, in this case, it is recommended to use the same system name. However, when the copy operation is performed within the same FD, the system name of copy source (FROM) should always be different from that of copy destination (TO). If the system names are the same, "SYSTEM NAME ERROR" is displayed.

(3) When the **CAN** key is pressed after the completion of operation or during the operation, the CRT returns to the "FUNCTION SETTING" screen.

(4) If the original file has a comment associated with its system name, that comment is also copied to the new system name.



OPERATION PROCEDURE 1-2 (BATCH COPY)



EXPLANATION

- (1) It is possible to copy all the contents of a FD to a second FD for back-up. Set COPY on the "FUNCTION SELECTION" screen, enter CPM to the SYSTEM NAME columns of FROM and TO on the "SYSTEM NAME SETTING" screen, and then press the CR key.


REMARKS

CPM cannot be used as a general system name. This name is reserved as part of the operating system.

IMPORTANT

The FD containing the O.S. must only be copied for use as a back up by the user. It should not be passed on or copied for other purposes.

BASIC OPERATION 2 (PHP)



IMPORTANT

When the copy function is executed, all data (such as sequence programs and comments) in the PHP memory is lost. Before executing the copy function, store data from the PHP memory to the user FD (SW0-GPPU).

OPERATION PROCEDURE 2-1

* COPY *

* WHEN COPY IS EXECUTED, DATA SUCH AS PROGRAMS AND COMMENTS WILL BE LOST.

* COPY DESTINATION FD MUST HAVE BEEN FORMATTED.

TO EXECUTE COPY, INSERT SYSTEM DISK AND PRESS <CR>
TO CANCEL, PRESS <CAN>

EXPLANATION

- (1) Select "COPY" to copy FD contents in blocks.
- (2) To execute copy, insert the GPPK system disk into FDD and press **[CR]**. The GPPK system disk must be inserted into FDD if the system has been started up by the memory card. Pressing **[CR]** reads the copy function OS from the GPPK system disk and displays the screen shown in OPERATION PROCEDURE 2-2.
- (3) When copy is not to be executed, press **[CAN]** to return to the "FUNCTION SETTING" screen.

OPERATION PROCEDURE 2-2

* COPY *

TO READ DATA FROM COPY SOURCE FD IN FDD, PRESS <CR>

TO TERMINATE COPY, INSERT SYSTEM DISK AND PRESS <GPP>

POINT

The FD where data will be copied (copy destination FD) must have been formatted. Otherwise, copy cannot be executed.


EXPLANATION

- (1) Insert the FD from which data will be copied (copy source FD) into FDD and press **[CR]**. Data to be copied is read from the FD to the PHP memory.
- (2) Insert the copy destination FD into FDD and press **[CR]**. Data is written from the PHP memory to this FD.
- (3) After completion of copying or when stopping the copy function, insert the GPPK system disk into FDD and press **[GPP]**. The GPPK system data is read to the PHP and the "INITIAL MENU" screen is displayed.


7. FDD MODE

7.10 Formatting of FD

The formatting operation of unformatted floppy disk.



BASIC OPERATION 1 (GPP)



OPERATION PROCEDURE 1-1


* FORMAT *

INSERT SYSTEM DISK INTO DRIVE A, THEN PRESS <CR>

INSERT USER DISK INTO DRIVE B, THEN PRESS <CR>

TO FORMAT DISK IN DRIVE B, PRESS <CR>

FORMATTING TRACK = 0



BASIC OPERATION 2 (PHP)




OPERATION PROCEDURE 2-1

* FORMAT *

INSERT USER DISK INTO DRIVE, THEN PRESS <CR>
TO FORMAT DISK IN DRIVE, THEN PRESS <CR>

FORMATTING TRACK = 0



EXPLANATION

- (1) The FD cannot be used unless it has been formatted.
- (2) Before performing the formatting operation, be sure to insert the system start FD into drive **[A]** and the unformatted FD into drive **[B]**.
- (3) During execution, "Formatting TRACK" is displayed on the screen. The number of tracks changes from 0 to 159 in due order. When the number of tracks reaches 159, the formatting operation is completed and the CRT returns to the FORMAT initial screen.
- (4) By pressing the **[CAN]** key after the completion of the formatting operation, the CRT returns to the "FUNCTION SETTING" screen.

IMPORTANT


If an FD is already formatted and the format procedure is repeated, all data will be cleared. Therefore, caution should be exercised.

7. FDD MODE


MELSEC-A

7.11 Automatic Write to FD

Setting of automatic write to the FD in ladder, list, or comment mode.



BASIC OPERATION



REMARKS

After setting the initial screen, proceed to the Basic Operation.

OPERATION PROCEDURE

* FD AUTO-WRITE *

YES
 NO

PRESS (CR), WHEN OK
 SELECT "YES" FOR AUTOMATIC WRITE
 OF PROGRAM OR COMMENT TO FD

```

    graph TD
      FDD --> D1[↓]
      D1 --> D2[↓]
      D2 --> D3[↓]
      D3 --> D4[↓]
      D4 --> D5[↓]
      D5 --> CR1[CR]
      CR1 --> CR2[CR]
      CR2 --> A[A]
      A --> B[B]
      B --> C[C]
      C --> CR3[CR]
      CR3 --> D[D]
      D --> E[E]
      E --> M[M]
      M --> O[O]
      O --> CR4[CR]
      CR4 --> GPP[GPP]
  
```

EXPLANATION

- (1) Automatic write to the FD may be selected in two ways as follows:
 - (a) After selecting the PC type on the initial setting screen, the option to select FDD AUTO-WRITE is displayed. (see Section 2.3)
 - (b) By selecting AUTO-WRITE on the FDD menu. This section describes method (6).
- (2) Select AUTO-WRITE on the FDD selection screen by using the cursor and **[GO]** keys. Specify the system name and a comment (if required) as for FDD write mode. If auto-write has been set previously it may be cancelled by selecting "NO" on the auto-write menu or alternatively by pressing **[CR]** instead of specifying a system name.
- (3) When automatic write to the FD has been selected, be sure to insert the system FD into FDD**[A]** and the user FD into FDD**[B]**. If the user FD is not inserted into FDD**[B]**, "FLOPPY DISK ERROR" will be displayed.
- (4) During automatic write mode to the FD, **[AUTO]** is displayed at the bottom right of the screen. The initiation of automatic write to the FD in each mode is as described below:

Ladder Mode


- 1) When the **[CNV]** key is pressed during ladder writing or editing (write from the head step of conversion to END).
- 2) After NOP clear operation.
- 3) After the deletion of one ladder (write from the head step of deletion to END).

List Mode

- 1) After writing a program in list mode, the program is written onto the FD by pressing the **[MELSAP]** key.

Comment Mode

- 1) After the comment write operation, all comments are written onto the FD by pressing the **[F9]** key.
- (5) ○ AUTO-WRITE to a specified file name is cancelled by any of the following operations.
 - a) Press RESET button or turn power off.
 - b) Execute the PC READ operation.
 - c) Execute FDD READ, WRITE, DELETE, COPY or FORMAT.
 - d) Change the PC designation on the initial screen. (AUTO-WRITE is not cancelled if the initial data is read but not changed.)
 - e) Delete, the A6GPP memory contents by using the **[NOP]** **[GO]** operation prior to writing a ladder diagram.
 - f) Execute the ROM READ operation.
 - g) Specify a new file name for the AUTO-WRITE operation in FDD mode.
- After all of the above operations the AUTO-WRITE function is still selected, however the file name for the write operation must be re-defined.
- The following processes completely cancel the AUTO-WRITE option.
 - a) Select "NO" on the AUTO-WRITE option menu. (See section 2.3)
 - b) Any "WRITE-IN ERROR" occurs during AUTO-WRITE.
- (6) When FD automatic write has been selected, the flow of display screen is as shown below.



- (7) When an existing file name is specified, "SYSTEM NAME ALREADY USED" is displayed in the message column and then "PRESS [W] TO WRITE NEW PROGRAM PRESS [R] TO READ PROG. FROM DISK". To over-write the previous file, enter "W". To read the program from the specified file, enter "R".
- When the A6GPP is started or reset, the contents of the internal memory is cleared. Therefore, to execute automatic write mode after selecting an existing system name, be sure to enter "R", thereby reading the program from the FD.
- When R is pressed, program and comments are read (if the same system name has been specified).


7. FDD MODE

7.13 Save Printer Data

Enters data set in printer mode onto the FD (SW0-GPPU).




BASIC OPERATION



OPERATION PROCEDURE

```
* SAVE PRINTER DATA *  
DRIVE A  
* DRIVE B
```



(Example: Save printer data onto FD in FDD [B].)

EXPLANATION

- (1) Enters data (such as printer used, communication mode, paper length, and print starting position) set in printer mode onto the FD. Entered data is automatically read to the internal memory of GPP/PHP when printer mode is selected.
- (2) When the "SAVE PRINTER DATA" screen is read, the cursor is located at "DRIVE B." if the FD is in drive [A], move the cursor with [↑] and press [CR].
- (3) When printer data is entered, a file name "PRINTERK. DAT" is automatically written onto the FD.

8. COMMENT MODE




8. COMMENT MODE


In comment mode, a comment, such as a definition or application, may be written for each device, to give better understanding of the circuit on print-outs and CRT display.

8.1 Comment Mode Functions

The functions of comment mode are as indicated below.



Characters specified in the initial data setting are valid for comment entry.



	English	German	Swedish
①	^ ~	^ β	ü ü
②	./	ö ö	ö ö
③	@ /	s /	é é
④	[~	ä ä	ä ä
⑤]~	ü ü	ä ä
⑥	\$	\$	ö
⑦	£	#	#

8.2 Comment Mode - General Information

- (1) Usable characters for comments
Capital letters from A to Z (The key input of small alphabetic letter is regarded as that of a capital letter.)
 - (period), +, -, =, ?For other than the above keys, "WRONG KEY FOR COMMENT" is displayed in the message column.


- (2) Device ranges for use with more than one PLC (except K3NCPU)
When PC No. are 1,2, and 3, the device ranges are as shown below and the key input and device display are within these ranges.

Device	PC No. 1	PC No. 2	PC No. 3
K	0 to 63	300 to 363	600 to 663
X, Y	0 to 1FF	300 to 4FF	600 to 7FF
M	0 to 255	300 to 555	600 to 855
T, C	0 to 127	300 to 427	600 to 727
F	0 to 127	0 to 127	0 to 127
D	0 to 127	300 to 427	600 to 727

- (3) Comment data displayed is 16 characters for X and Y and 20 characters for the other devices.

- (4) By use of the GPP/PHP, comment data can be written, stored to the FD, and printed.

8.3 Comment Mode Selection and Range Setting Operation



- (1) When "NEW" is selected on the COMMENT screen, the previously set comment ranges and comment contents are deleted (in the internal memory of A6GPP).

When "NEW" is selected, the COMMENT RANGE SETTING screen is displayed. Set the ranges by performing key input operation. First, the cursor is displayed at device K. For instance, to set 0 to 10, press the **0**, **→**, **1**, **0**, and **GO** keys. Then, the cursor moves to the next device. Perform the setting operation in due order. (By moving the cursor to the next device by use of the **↑**, **↓**, **→**, and/or **←** key instead of the **GO** key, setting is also completed.)

When all the devices have been set and the **END** key is pressed, the cursor is displayed at "END".

By pressing the **GO** key, the setting of comment ranges is completed and entered into the internal memory of A6GPP.

- (2) When "CONTINUE" is selected on the COMMENT screen, the current comment range can be corrected or continued.

When "CONTINUE" is selected, the COMMENT RANGE SETTING screen, showing the set ranges, is displayed and the cursor is located at "END". If required, move the cursor to the position of any device to be corrected, and make correction.

After that, proceed with the same operation as "NEW". (When correction is not required, simply press the **GO** key.) When comment ranges have been changed and another screen is displayed, entered comments outside the set comment ranges are deleted.

- (3) When the number of comments exceeds 2048 in the comment range setting, "COMMENT MEMORY EXCEEDED" is displayed.


8. COMMENT MODE

8.4 Write of New Comment Data


To write new comment data or clear existing comment data and comment ranges.

**COMMENT
WRITE**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) To write new comment data, select "NEW" on the "COMMENT" screen. After "NEW" is selected, the CRT screen changes to the COMMENT RANGE SETTING screen. Perform the range setting of devices, for which comment data will be written, as described in Section 8.3.

REMARKS

- 1) If, at power-on, comments are not read from the FD or "NEW" is not selected, "COMMENT MEMORY EXCEEDED" is displayed.
- 2) Perform setting so that the total number of comments in the comment range setting does not exceed 2048.
- (2) After setting the comment range, read the device where comment data will be written by pressing the **RD** and **Device** keys, then press the **WR** key. If FD auto-write has been specified the Auto write system name setting screen is displayed. In this case follow the procedure given in Section 7.11. The cursor flickers at the head device column of displayed comment data write table and the key input of comment data is valid at the cursor position. (Perform key input with the keys on the **MELSAP** keyboard.) A maximum of 15 characters can be used for one device as comment data. When the **CR** key is pressed after the completion of comment data input, the cursor moves to the next device.
- (3) To change the device where comment data will be written, press the **GPP**, **RD**, and **Device** keys and then proceed to the write operation.
- (4) For other than the creation of new comment data, "NEW" on the "COMMENT" screen is also selected to clear the existing comment data and comment ranges in blocks. Therefore, for the correction of comment data, be sure to select "CONTINUE".

- (5) When FD automatic write mode has been set, entering **[F9]** allows all comment data to be stored into the FD. However, this is valid only when "WRITE" is displayed in the "FUNCTION" column on the screen. (For the automatic write to FD, refer to Section 7.11.)

REMARKS

- 1) When the key input of one comment has been completed and the **[CR]** key pressed, the cursor moves to the next device.
The same function is also provided when the cursor is moved to the head position of comment entry column of the next device number by use of the cursor keys.
- 2) When the comment ranges are set in hexadecimal (device X, Y) 16 elements are displayed on one screen. When the comment ranges are set in decimal (device K, M, T, C, F, D), 20 elements are displayed on one screen.
- 3) For the movement of cursor
 - [↓]** **[↑]** The cursor is moved from line 1 to line 16 (20). When the **[↑]** key is pressed with the cursor located at line 1, the screen scrolls down. When the **[↓]** key is pressed with the cursor located at line 16 (20), the screen scrolls up.
 - [←]** **[→]** The cursor is moved in the horizontal direction. When the cursor is located at the first character, pressing the **[←]** key moves the cursor to the 15th character in the preceding line. When the cursor is located at the 15th character, pressing the **[→]** key moves the cursor to the first character in the next line. When the **[←]** key is pressed with the cursor located at the first character in line 1, the screen scrolls down and the cursor moves to the 15th character in the top line. When the **[→]** key is pressed with the cursor located at the 15th character in line 16 (20), the screen scrolls up and the cursor moves to the first character in the bottom line.
- 4) If comments for devices are to be input consecutively, devices appear in the following order within their specified ranges K, X (Y), M, T (C), F and D.
- 5) A comment can be written with a maximum of 15 characters for one device number. When the comment is displayed in the ladder diagram, 15 characters are displayed in three stages of five characters.
- 6) If a comment with more than 15 characters is written, those after the 15 characters are written in the next device number. Therefore, be sure to write a comment with a maximum of 15 characters for one device number.
- 7) If **[F3]** is pressed during write, the screen is scrolled down 8 to 10 comments (depending on devices), starting at the cursor position. By pressing **[F4]**, the screen is scrolled up 8 to 10 comments.
- 8) To make insertion during write, press **[INS]**. This puts the GPP in insert mode and allows a keyed-in character to be inserted at the cursor position. Each time the character is inserted, the character string on the right of the cursor is shifted one character. In this case, note that the character forced out of the line will be invalid.
- 9) To make deletion during write, press **[DEL]** or **[BS]**. Pressing **[DEL]** deletes the character at the cursor position and shifts the character string on the right of the cursor one character to the left. Pressing **[BS]** deletes the character at the cursor position but does not shift the character string on the right of the cursor.

8. COMMENT MODE


MELSEC-A

8.5 Write of Comment Data (Select "CONTINUE" on COMMENT screen)


The correction of comment data and comment range data of each device.

**COMMENT
WRITE**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) To correct the existing comment data and comment range data, be sure to select "CONTINUE" on the "COMMENT" screen. If "NEW" is selected by mistake, all the existing comment data will be cleared.
- (2) To correct the comment range data, move the cursor to the device column to be corrected on the "COMMENT RANGE SETTING" screen and then correct the range. On the initial screen, the cursor is located at bottom right of the comment range setting table. By moving the cursor to the portion to be corrected and then pressing the **CLEAR** key, the comment range data is blanked out. Enter new comment range data. (Correction can also be made by rewriting the data without pressing the **CLEAR** key.)
- (3) To correct the comment data, read the device to be corrected in the procedure of **RD** → **Device** → **Device number**, then press the **WR** key, and make correction with the keys on the **MELSAP** keyboard. By moving the cursor to the portion to be corrected and then pressing the **CAN** key, the comment data is blanked out. Enter new comment data. (Correction can also be made by rewriting the data without pressing the **CAN** key.)

OPERATION PROCEDURE 2 (Utilization of comment)

	12345*6789*12345	(COMMENT RANGE)																																													
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>X.Y 000</td><td>START MOTOR 1</td></tr> <tr><td>X.Y 001</td><td>START MOTOR 1</td></tr> <tr><td>X.Y 002</td><td></td></tr> <tr><td>X.Y 003</td><td></td></tr> <tr><td>X.Y 004</td><td></td></tr> <tr><td>X.Y 005</td><td></td></tr> <tr><td>X.Y 006</td><td></td></tr> <tr><td>X.Y 007</td><td></td></tr> <tr><td>X.Y 008</td><td></td></tr> <tr><td>X.Y 009</td><td></td></tr> <tr><td>X.Y 00A</td><td></td></tr> <tr><td>X.Y 00B</td><td></td></tr> <tr><td>X.Y 00C</td><td></td></tr> <tr><td>X.Y 00D</td><td></td></tr> <tr><td>X.Y 00E</td><td></td></tr> <tr><td>X.Y 00F</td><td></td></tr> </table>	X.Y 000	START MOTOR 1	X.Y 001	START MOTOR 1	X.Y 002		X.Y 003		X.Y 004		X.Y 005		X.Y 006		X.Y 007		X.Y 008		X.Y 009		X.Y 00A		X.Y 00B		X.Y 00C		X.Y 00D		X.Y 00E		X.Y 00F		<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>K</td><td>-</td></tr> <tr><td>X.Y</td><td>0- 1FF</td></tr> <tr><td>M</td><td>-</td></tr> <tr><td>T.C</td><td>-</td></tr> <tr><td>F</td><td>-</td></tr> <tr><td>D</td><td>-</td></tr> </table>	K	-	X.Y	0- 1FF	M	-	T.C	-	F	-	D	-	<div style="text-align: center;"> </div>	<p style="text-align: center;">(Example: Utilize the comment data of X00 for X01)</p>
X.Y 000	START MOTOR 1																																														
X.Y 001	START MOTOR 1																																														
X.Y 002																																															
X.Y 003																																															
X.Y 004																																															
X.Y 005																																															
X.Y 006																																															
X.Y 007																																															
X.Y 008																																															
X.Y 009																																															
X.Y 00A																																															
X.Y 00B																																															
X.Y 00C																																															
X.Y 00D																																															
X.Y 00E																																															
X.Y 00F																																															
K	-																																														
X.Y	0- 1FF																																														
M	-																																														
T.C	-																																														
F	-																																														
D	-																																														

EXPLANATION

- (1) To utilize comment data, select write mode, move the cursor to the comment device to be utilized, and press **F1**. By pressing **F1**, the comment data is transferred to the internal buffer of the A6GPP. Then, move the cursor to the line of device for which the data will be utilized, and press **F2**.
When **F2** is pressed, the comment data stored in the internal buffer is written to the device at which the cursor is located.
- (2) A comment may be cleared from a device by pressing the **CAN** key.
- (3) Comment can also be utilized for other than the same device. (For instance, the comment of X0 may be utilized for M0.)

POINT

Comment data transferred to the internal buffer of A6GPP by pressing **F1** is cleared when comment mode is left.


- (4) When FD automatic write mode has been set in advance, entering **F9** allows all comment data to be written to the FD. However, this is valid only when "WRITE" is displayed in the "FUNCTION" column on the screen. (For FD automatic write, refer to Sections 2.3 and 7.11.)

8. COMMENT MODE




8.6 Read of Comment Data

Read operation of the contents of comment data and comment range data of each device.



BASIC OPERATION



OPERATION PROCEDURE

12345*67890*12345 < COMMENT RANGE >

X.Y 000	ABCDE FGHIJ KLMNO	X -
X.Y 001	PQRST UVWXY Z	X.Y 0- 1FF
X.Y 002	12345 67890	M -
X.Y 003	STOP SW	T.C -
X.Y 004	START SW	F -
X.Y 005		D -
X.Y 006		
X.Y 007		
X.Y 008		
X.Y 009		
X.Y 00A		
X.Y 00B		
X.Y 00C		
X.Y 00D		
X.Y 00E		
X.Y 00F		

EXPLANATION

- (1) Among the specified device numbers, the comment data of 20 devices (16 devices for X, Y) are displayed. When only the device has been specified without specifying the device numbers, the comment data is displayed, beginning with the head number of device setting range. If a device number outside the device range setting has been specified, "DEVICE NUMBER ERROR" is displayed in the message column.
- (2) By pressing **GO** after the Basic Operation, the next 20 comments are displayed.
By pressing **↑**, **↓**, **←**, and **→** instead of **GO**, the preceding and next screens can be displayed.
 - ↓** with cursor in bottom line . . . The screen is scrolled up one line and the next comment is added.
 - ↑** with cursor in top line The screen is scrolled down one line and the preceding comment is added.
 - ←** The screen is scrolled down 8 or 10 lines (depending on devices).
 - The screen is scrolled up 8 or 10 lines (depending on devices).
- (3) To change the device to be read, first enter the device.
However, when the entered device and device number are wrong, press the **CLEAR** key before pressing the **GO** key. This clears the entered device and device number. Enter correct device and device number again.

REMARKS

When the device number is outside the specified range or when the start number is larger than or equal to the final number in the range setting, "DEVICE NUMBER ERROR" is displayed in the message column.

8. COMMENT MODE


MELSEC-A

8.7 Deletion of Comment Data and Comment Range Data


The deletion of existing comment data or comment range data.

**COMMENT
DELETION**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION


- (1) To delete the existing comment range data, select "CONTINUE" on the "COMMENT" screen, read the "COMMENT RANGE SETTING" screen, move the cursor to the device to be deleted, and press the **CLR** key. After the completion of deletion, press the **END** and **GO** keys.
- (2) To delete existing comment data, read the relevant device and its comment data, then proceed to write mode, move the cursor to the column of device number to be deleted, and press the **CAN** key.
- (3) The selection of "NEW" on the "COMMENT" screen deletes all data.
- (4) When FD automatic write mode has been set, entering **F9** allows all comment data to be stored into the FD. However, this is valid only when "WRITE" is displayed in the "FUNCTION" column on the screen. (For FD automatic write, refer to Sections 2.3 and 7.11.)

9. ROM MODE

The ROM mode refers to the operations of write (GPP/PHP → EP-ROM), read (GPP/PHP ← EP-ROM), verify (GPP/PHP ↔ EP-ROM), and erase check (GPP/PHP → EP-ROM) between the EP-ROM loaded to the ROM socket and the internal memory of the GPP/PHP. Only programmable controller programs may be written onto the ROM.

9.1 ROM Mode Functions

9.1.1 A6GPP




9.1.2 PHP


(1) The A6WU allows the following functions to be executed:

- 1) Read The contents of EP-ROM are read to the PHP memory.
- 2) Write The contents of the PHP memory are written to EP-ROM.
- 3) Verify The contents of the PHP memory and those of EP-ROM are verified.
- 4) Erase check Check is made that nothing is written on the EP-ROM.

(2) Set and reset ROM mode in the following procedure:



(3) Sequence of the display screen is as shown below:



REMARKS

The A6WU may be kept operated if "AOJ2" is displayed in the CPU type column during operation.

9.2 Usable EP-ROMs and Memory Capacities

According to the memory capacity, use the appropriate EP-ROM as indicated below.

Type	Equivalent	Memory Capacity (Step numbers)
1KROM	2716	0 to 1023
2KROM	2732	0 to 2047
	2732A	
4KROM	2764	0 to 4095
8KROM	27128	0 to 8191
16KROM	27256	0 to 16383

9.3 Setting of Memory Capacity

For ROM operation, the memory capacity must be set. There are two types of setting methods; setting by step number and setting in units of K (1024 steps)

- (1) If setting by step number, set the memory capacity in the range from 0 to 16383.
- (2) If setting in units of K (1024 steps), set the memory capacity as shown below:



K	Step Numbers
1	0 to 1023
2	0 to 2047
3	0 to 3071
4	0 to 4095
5	0 to 5119
6	0 to 6143
7	0 to 7167
8	0 to 8191
9	0 to 9215
10	0 to 10239
11	0 to 11263
12	0 to 12287
13	0 to 13311
14	0 to 14335
15	0 to 15359
16	0 to 16383

9. ROM MODE



9.4 Read from ROM

The read operation from the ROM to the internal memory of GPP/PHP.



OPERATION PROCEDURE

* ROM SETTING *

TYPE	STEP NO.
2716	START STEP = 0
* 2732	FINAL STEP = 2047
2732A	
2764	
27128	
27256	

PRESS (GO) WHEN READ

(1) Step number setting

```

      [GO] → [↓] → [GO] → [0] → [↓]
      Read selection 2732 selection Starting step 0
    
```

```

      [2] → [0] → [4] → [7] → [GO] → [GO]
      Last step 2047
    
```

(2) K unit setting

```

      [GO] → [↓] → [GO] → [0] → [K]
    
```

```

      [↓] → [2] → [K] → [GO] → [GO]
    
```

EXPLANATION

- (1) The contents of the ROM are read to the internal memory of the GPP/PHP within the set memory range.
- (2) During execution, a series of "*" are displayed below the "ROM SETTING" screen to represent execution. One "*" mark represents a unit of 256 steps. During execution, one "*" disappears per processing of 256 steps. (For example, when the memory range is 4096 steps, 16 "*" marks are displayed.)
- (3) To change the setting after selecting the final step number, press the [] and [GO] keys. The cursor returns to the position of set ROM type and re-setting can be performed.
- (4) When the [GO] key is pressed after setting the final step number, a step number check is performed. Possible errors are as follows:


Error Contents	Error Message
1) 16384 or more, or 17K or more steps have been selected.	STEP NUMBER ERROR
2) When memory capacity is set in units of K, the K should be written after the number, e.g. 2K.	
3) The start step number is larger than the final step number.	
4) Set memory capacity (start step number - final step number) is larger than ROM capacity.	MEMORY OVERFLOW

If an error has occurred, press the [CLEAR] key, then press the [] and [GO] keys, and re-set.

9. ROM MODE



- (5) If it is necessary to change the setting while setting the step number, press the **CLEAR** key and then change the step number.
- (6) The flow of display screen is as shown below.




9. ROM MODE




9.5 Write to ROM

The write operation of the internal memory contents of GPP/PHP to the ROM.



BASIC OPERATION



OPERATION PROCEDURE

* ROM SETTING *

TYPE	STEP NO.
2716	START STEP = 0
* 2732	FINAL STEP = 2047
2732A	
2764	
27128	
27256	

PRESS (GO), WHEN READ

(1) Step number setting

Final step 0

(2) K unit setting

EXPLANATION

- (1) This is the write operation from the internal memory of GPP/PHP to the ROM within the set memory range. (After the write operation, automatic verification is executed.)
- (2) During execution, a series of "*" are displayed below the "ROM SETTING" screen to represent execution. One "*" mark represents a unit of 256 steps. During execution, one "*" disappears per processing of 256 steps. (For example, when the memory range is 4096 steps, 16 "*" marks are displayed.)
- (3) To change the setting after selecting the final step number, press the and keys. The cursor returns to the position of set ROM type and re-setting can be performed.
- (4) When the key is pressed after setting the final step number, a step number check is performed. Possible errors are as follows:


Error Contents	Error Message
1) 16384 or more, or 17K or more steps have been selected.	STEP NUMBER ERROR
2) When memory capacity is set in units of K, the K should be written after the number, e.g. 2K.	
3) The start step number is larger than the final step number.	
4) Set memory capacity (start step number - final step number) is larger than ROM capacity.	MEMORY OVERFLOW

If an error has occurred, press the key, then press the and keys, and re-set.

9. ROM MODE



- (5) If it is necessary to change the setting while setting the step number, press the **CLEAR** key and then change the step number.
- (6) The flow of display screen is as shown below.



- (7) The message "WRITE-IN ERROR" appears if the EPROM is faulty or is inserted incorrectly.

9. ROM MODE

9.6 Verify with ROM

To verify contents of GPP/PHP memory with ROM.



BASIC OPERATION



OPERATION PROCEDURE

* ROM SETTING *

TYPE	STEP NO.
2716	START STEP = 0
* 2732	FINAL STEP = 2047
2732A	
2764	
27128	
27256	

PRESS (GO) WHEN VERIFY

(1) Step number setting

Final step 2047

(2) K unit setting

EXPLANATION

- (1) This is the verify operation between the contents of GPP/PHP internal memory and the ROM.
- (2) During execution, a series of "*" are displayed below the "ROM SETTING" screen to represent execution. One "*" mark represents a unit of 256 steps. During execution, one "*" disappears per processing of 256 steps. (For example, when the memory range is 4096 steps, 16 "*" marks are displayed.)
- (3) To change the setting after selecting the final step number, press the and keys. The cursor returns to the position of set ROM type and re-setting can be performed.
- (4) When the key is pressed after setting the final step number, a step number check is performed. Possible errors are as follows:


Error Contents	Error Message
1) 16384 or more, or 17K or more steps have been selected.	STEP NUMBER ERROR
2) When memory capacity is set in units of K, the K should be written after the number, e.g. 2K.	
3) The start step number is larger than the final step number.	
4) Set memory capacity (start step number – final step number) is larger than ROM capacity.	MEMORY OVERFLOW

If an error has occurred, press the key, then press the and keys, and re-set.

9. ROM MODE



- (5) If it is necessary to change the setting while setting the step number, press the **[CLEAR]** key and then change the step number.
- (6) If the contents of the internal memory of the GPP/PHP do not coincide with those of the ROM, "VERIFY ERROR" is displayed in the message column. In this case, check contents of both and correct the non-coinciding portions.
- (7) The flow of display screen is as shown below.





9. ROM MODE




9.7 ROM Erasure Check

For checking whether the ROM has been erased or not.



EXPLANATION


- (1) This operation is used to check that no data is written on the ROM. Make the erasure check before ROM writing.
- (2) During execution, the status is displayed by the "X" marks as in the read operation, etc.
- (3) If "ROM NOT ERASED" is displayed in the message column after the check, the write operation cannot be performed with that ROM. Erase or replace the ROM.
- (4) A damaged ROM may appear normal after an erasure check, however if the write operation is attempted, "WRITE-IN ERROR" is displayed.
- (5) The flow of display screen is as shown below.



10. PRINTER MODE

The printer mode refers to the following operations: Ladder print, command list print, contact and coil list print, device used list print, comment list print, utilized ladder print, multiple print, screen copy using an external printer with RS232C interface.

10.1 Printer Mode and Functions



REMARKS

To prevent electric shock, ensure that the printer is grounded.

Before printing begins, the above selection procedure is required. Explanations are given in due order from Section 10.2 to Section 10.8, beginning with the setting of printer used.

POINT




- (1) When "PRINTER" is selected on the mode selection screen, the GPP/PHP accesses FDD **[B]**. If printer data exists on the FD in FDD **[B]**, data is read and the CRT proceeds to the "PRINTER SETTING" screen. If printer data does not exist on the FD, search is made in order of FDD **[B]** and **[A]**, and then the CRT proceeds to the "PRINTER SETTING" screen. (Refer to Section 7.13.)
- (2) Check the GPP/PHP for the following points, 1) to 3), before starting the printer. Any of these will cause "PRINTER CHECK" to appear in the message column.
 - 1) The printer power is off.
 - 2) The cable is not connected properly.
 - 3) The printer is "off line."

When the **[GO]** key is pressed again after the above has been checked and corrected, printing starts.

- (3) To stop the execution of printing
 - 1) Press the **[CLEAR]** key. The printing operation is stopped (when the printer buffer is empty) and "STOP. PRESS [GO] TO RESTART. PRESS [END] [GO] TO END" is displayed. This is not applicable to screen copy.
 - 2) To proceed to another mode after stopping the printing operation, press the **[END]** and **[GO]** keys to complete the printing. After that, press the required mode key. (Except screen copy)
- (4) Before starting to print, ensure that the data to be printed, such as the sequence program and comment data, is stored in the internal memory of the GPP/PHP.
- (5) If the printer is of a grounding type, be sure to ground the printer.

10. PRINTER MODE

10.2 Setting of Used Printer To set the printer required.



EXPLANATION


- (1) To set the printer, move the cursor with the key to the required printer and press the key. This sets the printer type.
- (2) The next screens, which differ depending on the printer setting, are explained in the following sections:
 - 1) For the K6PR, K6PR-K, GT-10A, and RX/LX-80 refer to Section 10.7.
 - 2) For the K7PR, refer to Section 10.3.
 - 3) For the general-purpose printer, refer to Section 10.4.
 - 4) For the A7PR, refer to Section 10.5.
- (3) To change the printer setting after the completion of setting, pressing the and keys returns the CRT to the initial "PRINTER SETTING" screen.

10. PRINTER MODE



10.3 Setting of Baud Rate (For K7PR)

The setting operation of baud rate.



BASIC OPERATION

REMARKS
Set K7PR by the printer setting operation.

OPERATION PROCEDURE

* BAUD RATE SETTING *	
300 600 1200 2400 4800 ■ 9600	PRINTER —K7PR BAUD RATE —9600 PARITY — DATE LENGTH — STOP BIT — PAPER LENGTH — START-POSITION — MODE — PAGE — PRINT MODE —

(Example: Setting of 9600 bauds)

EXPLANATION

- (1) When K7PR has been selected, it is necessary to set the baud rate. For the K7PR, the baud rate is 2400 or 9600 (the cursor cannot move to any other baud rate positions).
- (2) After setting the baud rate, NO PARITY, DATA LENGTH 8, and STOP BIT 2 are automatically displayed in the communication mode column.
- (3) After pressing the **GO** key in the baud rate setting, proceed to the operation described in Section 10.5.
- (4) When the **←** and **GO** keys are pressed during the operation, the CRT returns to the "PRINTER SETTING" screen. The cursor is displayed at the previously set position.

10. PRINTER MODE



10.4 Setting of Communication Mode (For general-purpose printer)

The setting operation of baud rate, parity check, data length, and stop bit.

**PRINTER
COMMUNICATION
MODE**

BASIC OPERATION

Printer setting operation

Baud rate setting

GO

Parity check setting

GO

Data length and stop bit setting

GO

REMARKS

Set the general-purpose printer by the printer setting operation.

OPERATION PROCEDURE

* DATA LENGTH & STOP BIT SETTING *

7&1	PRINTER	—OTHER
	BAUD RATE	—2400
7&2	PARITY	—ODD
	DATA LENGTH	—8
8&1	STOP BIT	—2
	PAPER LENGTH	—
8&2	START-POSITION	—
	MODE	—
	PAGE	—
	PRINT MODE	—

(Example: Setting of baud rate 2400, odd parity, data length 8 and stop bit 2)

EXPLANATION

- (1) When the general-purpose printer has been selected by moving the cursor to "OTHER" and pressing **GO** on the printer setting screen, set the communication mode according to the specific printer used. The communication mode setting includes the setting of baud rate, parity check, data length, and stop bit.
- (2) When the **←** and **GO** keys are pressed during any setting operation, the CRT returns to the preceding setting screen.
- (3) The flow of display screen is as shown below.

* BAUD RATE SETTING *

300	PRINTER	—OTHER
	BAUD RATE	—
600	PARITY	—
	DATA LENGTH	—
1200	STOP BIT	—
	PAPER LENGTH	—
2400	START-POSITION	—
	MODE	—
4800	PAGE	—
9600	PRINT MODE	—

Baud Rate Setting

* PARITY CHECK SETTING *

WITHOUT	PRINTER	—OTHER
	BAUD RATE	—2400
EVEN	PARITY	—
	DATA LENGTH	—
ODD	STOP BIT	—
	PAPER LENGTH	—
	START-POSITION	—
	MODE	—
	PAGE	—
	PRINT MODE	—

Parity Check Setting

* DATA LENGTH & STOP BIT SETTING *


7&1	PRINTER	—OTHER
	BAUD RATE	—2400
7&2	PARITY	—ODD
	DATA LENGTH	—8
8&1	STOP BIT	—2
	PAPER LENGTH	—
8&2	START-POSITION	—
	MODE	—
	PAGE	—
	PRINT MODE	—

Data Length and Stop Bit Setting

10. PRINTER MODE



10.5 Setting of Print Paper Length (For K7PR, A7PR, and general-purpose printer) Setting of print paper length.



<p>BASIC OPERATION</p> <p>[Normal mode setting operation] → [Paper length setting] → GO</p>	<p>REMARKS</p> <p>Set the K7PR, A7PR or general-purpose printer by the printer setting operation.</p>
---	--

OPERATION PROCEDURE

* PAPER LENGTH SETTING *

<ul style="list-style-type: none"> ■ 11 INCHES 12 INCHES 16 INCHES 	<table style="width: 100%; border-collapse: collapse;"> <tr><td>PRINTER</td><td>—OTHER</td></tr> <tr><td>BAUD RATE</td><td>—2400</td></tr> <tr><td>PARITY</td><td>—ODD</td></tr> <tr><td>DATA LENGTH</td><td>—8</td></tr> <tr><td>STOP BIT</td><td>—2</td></tr> <tr><td>PAPER LENGTH</td><td>—11</td></tr> <tr><td>START-POSITION</td><td>—</td></tr> <tr><td>MODE</td><td>—</td></tr> <tr><td>PAGE</td><td>—</td></tr> <tr><td>PRINT MODE</td><td>—</td></tr> </table>	PRINTER	—OTHER	BAUD RATE	—2400	PARITY	—ODD	DATA LENGTH	—8	STOP BIT	—2	PAPER LENGTH	—11	START-POSITION	—	MODE	—	PAGE	—	PRINT MODE	—
PRINTER	—OTHER																				
BAUD RATE	—2400																				
PARITY	—ODD																				
DATA LENGTH	—8																				
STOP BIT	—2																				
PAPER LENGTH	—11																				
START-POSITION	—																				
MODE	—																				
PAGE	—																				
PRINT MODE	—																				

GO

(Example: Setting of 11 inches)

EXPLANATION


- (1) When the K7PR, A7PR, or general-purpose printer has been selected, it is necessary to set the length of page used. Usable page lengths are; 11 inches, 12 inches, and 16 inches.
- (2) If the **[]** and **GO** keys are pressed during this operation, the display screen changes to the following setting screen:
 - K7PR → "BAUD RATE SETTING" (Section 10.3)
 - A7PR → "PRINTER SETTING" (Section 10.2)
 - General-purpose printer → "DATA LENGTH & STOP BIT SETTING" (Section 10.4)
- (3) For initial setting, the cursor is located at the "11 INCHES" position. Subsequently, the cursor is displayed at the previously set position.

POINT	
Paper feed of general-purpose printer	
Page changing conditions	
Paper Length	Print Lines
11 inches	66
12 inches	72
16 inches	96


10. PRINTER MODE



10.6 Setting of Print Starting Position (For K7PR, A7PR, and general-purpose printer) The setting operation of print starting position.



BASIC OPERATION



REMARKS


When the A7PR has been set, it is not required to perform the communication mode setting operation.

OPERATION PROCEDURE

* START POSITION FOR PRINT-OUT *

START POSITION = 10

PRINTER	—OTHER
BAUD RATE	—2400
PARITY	—ODD
DATA LENGTH	—8
STOP BIT	—2
PAPER LENGTH	—11
START-POSITION	—
MODE	—
PAGE	—
PRINT MODE	—



Print starting position

(Example: Setting of print starting position to 10)

EXPLANATION


- (1) When the K7PR, A7PR, or general-purpose printer has been selected, the print out starting address must be set. On the initial setting screen, "START-POSITION = 0" is displayed. When the print starting position is set to zero, printing starts from the left. By setting the print starting position, it is possible to move the printing position to the center of paper.
- (2) The effective set values of print starting position are 0 to 99.
- (3) Data output from the A6GPP is 80 characters per line. If, for example, 130 characters are effective per line on the printer and the print starting position is set to 60, 80 plus 60 equals 140 and the excess of 10 characters are printed in the same line or at the head of the next line. (132 characters in the case of K7PR paper)
- (4) On subsequent settings, the previously set value is displayed.
- (5) To change the set value, press the **CLEAR** key and enter the set value again.

10. PRINTER MODE



10.7 Mode Setting

Mode setting to single, single (page setting), and multiple modes.



BASIC OPERATION

[Mode setting] → GO

OPERATION PROCEDURE

* MODE SETTING *

SINGLE	PRINTER	—OTHER
	BAUD RATE	—2400
SINGLE(PAGE SETTING)	PARITY	—ODD
	DATA LENGTH	—8
MULTIPLE	STOP BIT	—2
	PAPER LENGTH	—11
	START-POSITION	—10
	MODE	—
	PAGE	—
	PRINT MODE	—

↓ → GO

(Example: Setting of single (page setting))

EXPLANATION

(1) There are three modes; single, single (page setting), and multiple.

- 1) Single settingSelect one mode from the print modes (LADDER, COMMAND LIST, CONTACT AND COIL LIST, DEVICE USED LIST, COMMENT LIST, UTILIZED CIRCUIT) and execute.

* MODE SETTING *

SINGLE	PRINTER	—OTHER
	BAUD RATE	—2400
SINGLE(PAGE SETTING)	PARITY	—ODD
	DATA LENGTH	—8
MULTIPLE	STOP BIT	—2
	PAPER LENGTH	—11
	START-POSITION	—10
	MODE	—
	PAGE	—
	PRINT MODE	—

⇒


* PRINT MODE SETTING *

LADDER	PRINTER	—OTHER
	BAUD RATE	—2400
COMMAND LIST	PARITY	—ODD
	DATA LENGTH	—8
CONTACT, COIL LIST	STOP BIT	—2
	PAPER LENGTH	—11
DEVICE USED LIST	START-POSITION	—10
	MODE	—SINGLE
COMMENT LIST	PAGE	—1
	PRINT MODE	—
UTILIZED CIRCUIT		


10. PRINTER MODE



2) Single (page setting) setting . . . This is the same as the single setting except that the print starting page can be specified as 0 to 99999 on the "PAGE SETTING" screen.




3) Multiple setting . . . Multiple print mode functions can be set at the same time. (See Section 10.16.)



(2) By pressing the and keys during the operation, the CRT returns to the preceding screen.

10. PRINTER MODE

10.8 Setting of Print Starting Page (For single (page setting) setting) To set the starting page of the print out.



BASIC OPERATION

{ Page number specification } → GO

REMARKS
Set single (page setting) by the mode setting.

OPERATION PROCEDURE

* START POSITION FOR PRINT-OUT *

START POSITION

PRINTER	—OTHER
BAUD RATE	—2400
PARITY	—ODD
DATA LENGTH	—8
STOP BIT	—2
PAPER LENGTH	—11
START-POSITION	—
MODE	—
PAGE	—
PRINT MODE	—

1 → 0 → GO

EXPLANATION

- (1) When "SINGLE (PAGE SETTING)" is selected, the starting page for the print out may be specified.
To specify the page, use the number keys. This must be within the range 0 to 99999.
- (2) In the initial setting, "1" is displayed as the page number. In subsequent settings, a value obtained by adding 1 to the last printing page in the previously set mode, is displayed.
- (3) By pressing the and keys during the operation, the CRT returns to the preceding screen.

10. PRINTER MODE


MELSEC-A

10.9 Setting of Printer Mode

Setting the print-out mode. (i.e. ladder, list etc.)

**PRINTER
MODE
SETTING**

BASIC OPERATION



OPERATION PROCEDURE

* PRINT MODE SETTING *

■ LADDER	PRINTER	--OTHER
COMMAND LIST	BAUD RATE	--2400
CONTACT, COIL LIST	PARITY	--ODD
DEVICE USED LIST	DATA LENGTH	--8
COMMENT LIST	STOP BIT	--2
UTILIZED LIST	PAPER LENGTH	--11
	START-POSITION	--10
	MODE	--SINGLE(PAGE)
	PAGE	--10
	PRINT MODE	--

GO

(Example: Setting of ladder)


EXPLANATION

- (1) When single or single (page setting) is selected, it is necessary to set the printer mode (LADDER, COMMAND LIST, CONTACT AND COIL LIST, DEVICE USED LIST, COMMENT LIST, UTILIZED CIRCUIT LIST). Move the cursor to the required mode and press the **GO** key to set.
- (2) By pressing the **←** and **GO** keys, the CRT returns to the preceding screen.
- (3) In the initial setting, the cursor is located at "LADDER". At subsequent settings, the cursor is displayed at the previously set position.

10. PRINTER MODE



(4) After the mode setting, the flow of display screen is as shown below.



10. PRINTER MODE



10.10 Ladder Print

Prints the program in ladder form.



OPERATION PROCEDURE


*** LADDER PRINT SETTING ***

<p>< COMMENT > WITHOUT * WITH < CROSSREF > * WITHOUT WITH</p>	<p>< RANGE SETTING > ALL AREA * RANGE SETTING < STEP NO > START STEP = 0 FINAL STEP = 100 < PRINT START > ■ YES NO</p>	<table border="1"> <tr><td>PRINTER</td><td>—OTHER</td></tr> <tr><td>BAUD RATE</td><td>—2400</td></tr> <tr><td>PARITY</td><td>—ODD</td></tr> <tr><td>DATA LENGTH</td><td>—8</td></tr> <tr><td>STOP BIT</td><td>—2</td></tr> <tr><td>PAPER LENGTH</td><td>—11</td></tr> <tr><td>START-POSITION</td><td>—10</td></tr> <tr><td>MODE</td><td>—SINGLE(PAGE)</td></tr> <tr><td>PAGE</td><td>—10</td></tr> <tr><td>PRINT MODE</td><td>—LADDER</td></tr> </table>	PRINTER	—OTHER	BAUD RATE	—2400	PARITY	—ODD	DATA LENGTH	—8	STOP BIT	—2	PAPER LENGTH	—11	START-POSITION	—10	MODE	—SINGLE(PAGE)	PAGE	—10	PRINT MODE	—LADDER
PRINTER	—OTHER																					
BAUD RATE	—2400																					
PARITY	—ODD																					
DATA LENGTH	—8																					
STOP BIT	—2																					
PAPER LENGTH	—11																					
START-POSITION	—10																					
MODE	—SINGLE(PAGE)																					
PAGE	—10																					
PRINT MODE	—LADDER																					


(Example: Printing of ladder with comment from step 0 to 100)

EXPLANATION

- (1) To obtain a ladder diagram print out, the following four items must be set; "COMMENT", "CROSS REF", "RANGE SETTING", and "START".
- 1) "COMMENT".....Select print out with or without comments.
 - 2) "CROSS REF".....Provides a cross reference between devices used in the program and where their relevant OUT or data instructions occur (see following example.)



(2) Data instruction



Note: CROSS REF setting cannot be selected if K6PR (pica), K6PR-K (pica), or GT-10A (old) has been selected.

If tried, "SETTING ERROR" is displayed.

- 3) "RANGE SETTING"... Sets the printing range. To print all steps, select "ALL AREA". To set the range, select "RANGE SETTING" and set the start step number and the final step number.
 - 4) "START"By pressing the **GO** key with the cursor located at YES, printing begins.
By pressing the **GO** key with the cursor located at NO, the CRT returns to the "MODE SETTING" screen.
- (2) By pressing the **←** and **GO** keys during selection, the CRT returns to the preceding parameter.
When the cursor is located at the YES or NO position, pressing the **←** and **GO** keys moves the cursor to the "RANGE SETTING" position.


10. PRINTER MODE



(3) Print out example

Ladder print out example (1)

Conditions
K6PR (Pica)
Single




10. PRINTER MODE



Ladder print out example (2)

Conditions
K6PR (Pica)
Single
With comments




10. PRINTER MODE



Ladder print out example (3)

Conditions


K6PR (Elite)
Single
With cross ref.



10. PRINTER MODE

10.11 Command List Print Setting

Prints the program in list mode.



OPERATION PROCEDURE

```

          * COMMAND LIST PRINT SETTING *
    < COMMENT >  < RANGE SETTING >  PRINTER  —OTHER
    WITHOUT    * ALL AREA          BAUD RATE —2400
    * WITH     RANGE SETTING       PARITY    —ODD
    < STEP NO >  PAPER LENGTH —8
    START STEP = 0                 STOP BIT  —2
    FINAL STEP = 1023              PAPER LENGTH —11
                                     START-POSITION —10
                                     MODE           —SINGLE(PAGE)
                                     PAGE           —10
                                     PRINT MODE    —COMMAND LIST
    < PRINT START >
    ■ YES
    NO
      
```

(Example: Printing of command list with comment)

EXPLANATION

- (1) To obtain a program list print out, the following three items must be set: "COMMENT", "RANGE SETTING", and "START".
 - 1) "COMMENT".Prints program list with comments.
 - 2) "RANGE SETTING". . . .Sets the printing range. To print the whole program, select "ALL AREA". To set the range, select "RANGE SETTING" and set the start step number and the final step number.
 - 3) "START"By pressing the **GO** key with the cursor located at YES, printing begins. By pressing the **GO** key with the cursor located at NO, the CRT returns to the "MODE SETTING" screen.
- (2) By pressing the **←** and **GO** keys during selection, the CRT returns to the preceding parameter.

10. PRINTER MODE

MELSEC-A

(3) Command list print out example

Print out example (1)

Conditions

K6PR (Pica)

Single

```
0 LD X000
1 OUT Y010
2 LDI X000
3 AND X001
4 ANI X002
5 AND M100
6 CJ K21
8 LD X013
9 AND X005
10 LD X009
11 AND Y024
12 ORB
13 LD X015
14 ANI Y029
15 LDI X004
16 AND M8
17 ORB
18 ORI X015
19 ANB
20 OUT Y024
21 LD X014
22 ANI Y031
23 LD X003
24 ANI M11
25 ORB
26 LD X009
27 ORI Y030
28 ANB
29 OUT T5 K100
31 AND X010
32 OUT Y025
33 LD Y100
```

10. PRINTER MODE



Print out example (2)

Conditions
K6PR (Pica)
Single
With comments


0	LD	X000		START
1	OUT	Y010		LIMIT2
2	LDI	X000		START
3	AND	X001		STOP
4	ANI	X002		EMERGENCY STOP
5	AND	M100		
6	CJ	K21		
8	LD	X013		LIMIT3
9	AND	X005		
10	LD	X009		LIMIT1
11	AND	Y024		MOTOR1
12	ORB			
13	LD	X015		AUTO
14	ANI	Y029		PC2 START
15	LDI	X004		
16	AND	M8		
17	ORB			
18	ORI	X015		AUTO
19	ANB			
20	OUT	Y024		MOTOR1
21	LD	X014		LIMIT4
22	ANI	Y031		
23	LD	X003		
24	ANI	M11		
25	ORB			
26	LD	X009		LIMIT1
27	ORI	Y030		
28	ANB			
29	OUT	T5	K100	
31	AND	X010		LIMIT2
32	OUT	Y025		PC1 START
33	LD	Y100		

10. PRINTER MODE



10.12 Contact and Coil List Print

Prints a list showing how and where each of the contacts and coils have been used.



OPERATION PROCEDURE

* CONTACT, COIL LIST RANGE SETTING *

K	-	PRINTER	-OTHER
X	000-00F	BAUD RATE	-2400
Y	010-01F	PARITY	-ODD
M	-	DATA LENGTH	-8
T	-	STOP BIT	-2
C	-	PAPER LENGTH	-11
F	-	START-POSITION	-10
D	-	MODE	-SINGLE(PAGE)
		PAGE	-10
		PRINT MODE	-CONTACT, COIL

< PRINT START >
YES
NO

* PRESS (END), WHEN SET *

```

      [↓] → [0] → [→] → [0] → [F] → [GO]
      X specification      X00 to X0F specification
    
```

```

      [1] → [0] → [→] → [1] → [F]
      Y10 to Y1F
    
```

```

      [GO] → [END] → [GO]
    
```

(Example: Specification of only X00 to X0F and Y10 to Y1F.)

REMARKS

For the keying of 0F, only F key need be pressed.

EXPLANATION

- (1) Set the ranges of K, X, Y, M, T, C, F, and D individually to print the ladder symbols against their relevant step numbers.
- (2) On the initial setting screen, the cursor is located at the K's start number column. After entering the starting number, press the **→** key to move the cursor to the final number column and then enter the number. After that, press the **GO** key to move the cursor to the next device position. If setting is not necessary for a device, move the cursor to the next device by pressing the **↓** key. After the completion of setting, press the **END** key and proceed to "START".
- (3) By pressing the **GO** key with the cursor located at YES, printing begins. By pressing the **GO** key with the cursor located at NO, the CRT returns to the "MODE SETTING" screen.

(4) Contact and coil list print out example

Conditions

K6PR (Pica)

Single

CONTACT COIL LIST

	STEP	LADDER
Y 100	11	—C—
Y 101	49	—□— -
Y 102	49	—□— -
Y 103	49	—□— -
Y 104	49	—□— -
Y 105	49	—□— -
Y 106	49	—□— -
Y 107	49	—□— -
Y 108	49	—□— -
Y 109	49	—□— -
Y 10A	49	—□— -
Y 10B	49	—□— -
Y 10C	49	—□— -
Y 10D	49	—□— -
Y 10E	49	—□— -
Y 10F	49	—□— -

STEP	LADDER
49	—□— -
65	—□— BCD



STEP	LADDER
65	—□— BCD

STEP LADDER

10. PRINTER MODE



10.13 Device Used List Print Prints a list of devices used.



OPERATION PROCEDURE

* DEVICE USED LIST RANGE SETTING *

K	-	PRINTER	-OTHER
X	000-00F	BAUD RATE	-2400
Y	010-01F	PARTY	-ODD
M	-	DATA LENGTH	-8
T	-	STOP BIT	-2
C	-	PAPER LENGTH	-11
F	-	START-POSITION	-10
D	-	MODE	-SINGLE(PAGE)
		PAGE	-10
		PRINT MODE	-DEVICE USED

< PRINT START >
YES
NO

* PRESS (END), WHEN SET *

X specification X00 to X0F specification

Y10 to Y1F

(Example: Specification of X00 to X0F and Y10 to Y1F.)

EXPLANATION

- (1) On the initial setting screen, the cursor is located at the K's start number column. After entering the start number, press the **[→]** key to move the cursor to the final number column and then enter the number. After that, press the **[GO]** key to move the cursor to the next device position. If setting is not necessary for a device, move the cursor to the next device by pressing the **[↓]** key. After the completion of setting, press the **[END]** key and proceed to "START".
- (2) By pressing the **[GO]** key with the cursor located at YES, printing begins. By pressing the **[GO]** key with the cursor located at NO, the CRT returns to the "MODE SETTING" screen.

10. PRINTER MODE



(3) Device used list print out example

Conditions
K6PR (Pica)
Single


DEVICE USE LIST			
(← → = USED) (BLANK = UNUSED) (E = ERROR)			
Y 060 ←	E	Y 070 ←	E
Y 061		Y 071	
Y 062		Y 072	
Y 063		Y 073	
Y 064 ← → 1 E		Y 074	
Y 065 ← → 1		Y 075	
Y 066 ← → 1 E		Y 076	
Y 067		Y 077	
Y 068 ← → 1 E		Y 078	
Y 069		Y 079	
Y 06A		Y 07A	
Y 06B		Y 07B	
Y 06C		Y 07C	
Y 06D		Y 07D	
Y 06E		Y 07E	
Y 06F		Y 07F	
Y 080		Y 080	
Y 081		Y 081	
Y 082		Y 082	
Y 083		Y 083	
Y 084		Y 084	
Y 085		Y 085	
Y 086		Y 086	
Y 087		Y 087	
Y 088		Y 088	
Y 089		Y 089	
Y 08A		Y 08A	
Y 08B		Y 08B	
Y 08C		Y 08C	
Y 08D		Y 08D	
Y 08E		Y 08E	
Y 08F		Y 08F	

10. PRINTER MODE




10.14 Comment List Print Setting

Prints a list of comments used.



BASIC OPERATION



OPERATION PROCEDURE

* COMMENT LIST RANGE SETTING *


K	—	PRINTER	—OTHER
X.Y	000—07F	BAUD RATE	—2400
M	0—100	PARITY	—ODD
T.C	0—20	DATA LENGTH	—8
F	—	STOP BIT	—2
D	0—15	PAPER LENGTH	—11
		START-POSITION	—10
		MODE	—SINGLE(PAGE)
		PAGE	—10
		PRINT MODE	—COMMENT LIST

< PRINT START >

YES

NO

* PRESS (END) , WHEN SET *



(Example: Specification of X/Y00 to X/Y7F, M0 to M100, T/C0 to T/C20, and D0 to D15)

EXPLANATION

- (1) On the initial setting screen, the cursor is located at the K's start number column. After entering the start number, press the **[→]** key to move the cursor to the final number column and then enter the number. After that, press the **[GO]** key to move the cursor to the next device position. If setting is not necessary for a device, move the cursor to the next device by pressing the **[↓]** key. After the completion of setting, press the **[END]** key and proceed to "START".
- (2) By pressing the **[GO]** key with the cursor located at YES, printing begins. By pressing the **[GO]** key with the cursor located at NO, the CRT returns to the "MODE SETTING" screen.

10. PRINTER MODE



(3) Comment list print out example

Conditions	
K6PR (Pica)	
Single	

COMMENT LIST					
DEVICE	COMMENT	DEVICE	COMMENT	DEVICE	COMMENT
	12345*67890*12345		12345*67890*12345		12345*67890*12345
X.Y000	START	X.Y010	LIMIT 2	X.Y020	
X.Y001	STOP	X.Y011		X.Y021	
X.Y002	EMERG ENCY STOP	X.Y012		X.Y022	
X.Y003		X.Y013	LIMIT 3	X.Y023	
X.Y004		X.Y014	LIMIT 4	X.Y024	MOTOR 1
X.Y005		X.Y015	AUTO	X.Y025	PC1 START
X.Y006		X.Y016		X.Y026	
X.Y007		X.Y017		X.Y027	
X.Y008		X.Y018		X.Y028	
X.Y009	LIMIT 1	X.Y019		X.Y029	PC2 START
X.Y00A		X.Y01A		X.Y02A	
X.Y00B		X.Y01B		X.Y02B	
X.Y00C		X.Y01C		X.Y02C	
X.Y00D		X.Y01D		X.Y02D	
X.Y00E		X.Y01E		X.Y02E	
X.Y00F		X.Y01F		X.Y02F	

10. PRINTER MODE

MELSEC-A

10.15 Utilized Circuit Print


Provides a circuit print out of the utilized circuit stored on the FD (which must be in drive B). See Section 4.6.

**PRINTER
UTILIZED
CIRCUIT**

BASIC OPERATION



OPERATION PROCEDURE



EXPLANATION

- (1) By pressing the **GO** key with the cursor located at YES, printing begins. By pressing the **GO** key with the cursor located at NO, the CRT returns to the "MODE SETTING" screen.


10. PRINTER MODE



(2) Utilized circuit print out example

Conditions
K6PR (Pica)
Single

UTILIZED CIRCUIT PATTERN = 0




10. PRINTER MODE



10.16 Multiple Mode Print

Allows all or some of the previous print out modes to be selected simultaneously.



BASIC OPERATION

Selection of multiple mode by the mode setting → Each mode range setting → END → GO

OPERATION PROCEDURE

* MULTIPLE MODE SETTING *				
* LADDER	INSTRUCTION LIST	* CONTACT, COIL	DEVICE USED	* COMMENT LIST
(COMMENT)	(COMMENT)	K -	K -	K -
* WITHOUT WITH (STEP NO. FOR CONTACT)	WITHOUT WITH	X 000- 00F	X -	X, Y 000- 01F
* WITHOUT WITH (RANGE SETTING)	(RANGE SETTING)	Y 010- 01F	Y -	M -
(RANGE SETTING)	ALL AREA RANGE SETTING	M -	M -	T, C -
* ALL AREA RANGE SETTING (STEP NO)	(STEP NO)	T -	T -	F -
(STEP NO)	START =	C -	C -	D -
START = 0	END =	F -	F -	-
END = 1023		D -	D -	-

■ PRINT-OUT START	PRINTER	-OTHER	DATA LENGTH -8	START-POSITION -10
NOT PRINT-OUT	BAUD RATE	-2400	STOP BIT -2	MODE -MULTIPLE
	PARITY	-ODD	PAPER LENGTH -11	PAGE -1

(Example: Printing of ladder, command list, contact and coil list, and comment)



EXPLANATION

- (1) In multiple mode setting, ladder, command list, contact and coil list, device used list, and/or comment list modes may be printed one after the other.
- (2) The setting procedure for each mode is the same as described in Section 10.10 to 10.14. When changing to the next mode, press the **→** key to move the cursor. After the final setting, press the **END** key.
- (3) When the **←** and **GO** keys are pressed during the selection of each mode, the CRT returns to the preceding mode setting.
- (4) After the **END** key has been pressed for the final setting and the cursor is located at "PRINT-OUT START", pressing the **GO** key starts printing. Pressing the **GO** key with the cursor located at "NOT PRINT-OUT" returns the CRT to the "MODE SETTING" screen.
- (5) If setting has been done previously for each type of print out, these settings are entered automatically for the multiple print out.


10. PRINTER MODE

10.17 Screen Copy

Prints the entire A6GPP screen.



OPERATION PROCEDURE



EXPLANATION

- (1) To obtain a print out of the display, press the **[COPY]** key. This "freezes" the display and starts printing. After the completion of printing, normal operation is automatically resumed. When the GT-10A (old), GT-10A (new), or general-purpose printer has been selected, screen copies cannot be made.
- (2) Set the printer required in advance using the printer setting procedure. Then, when a screen copy is required, press the **[COPY]** key on the MELSAP keyboard. (The copy key on the A6KB has a different function, always use the MELSAP keyboard COPY key to call off a screen copy.)
- (3) To proceed to another mode after the completion of screen copy, press the required mode key.
- (4) If a screen copy has been initiated, it cannot be aborted from the keyboard.
- (5) To copy the screen using the general-purpose printer, select the K7PR if the used printer specifications are the same as those shown below.

Baudrate	9600 or 2400	Data length	8
Parity	None	Stop bit	2


Description	ESC Sequence	Code
Paper feed setting	ESC A+n	[1B]H[41]H[n] OR [27]10[65]n[n]
Elite size setting	ESC M	[1B]H[4D]H OR [27]10[77]10
Pica size setting	ESC P	[1B]H[50]H OR [27]10[80]10
Bit image mode selection	ESC X+m+n1+n2	[1B]H[2A]H[m] [n1] [n2] OR [27]10[A2]10[m] [n1] [n2]

10. PRINTER MODE



Screen copy print out example

Conditions
K6PR (Pica)
Single



MEMORY USED	36	LEFT	2012		
TO	C10	D0	D60	D61	
64	101	257	255	100	
100	999				

MODE	LADDER	FUNCTION	TEST	GPP	SHIFT
KEY IN DATA			C10 K100		
MESSAGE	COMPLETED				

11. CONVERSION TO PROGRAM FOR K3


In order to use programs written for K0, K0J, K1, and K2 on the K3NCPU, it is necessary to convert them to K3NCPU programs.

Since the instruction codes used for the K3N are different from those of other CPUs, the existing programs (K0, K0J, K1, and K2) cannot be used on the K3NCPU without performing the following conversion operation.

POINT

- (1) After conversion into a K3 program, be sure to insert an END instruction in front of "OUT F100". ("OUT F100" is not automatically inserted by the program conversion procedure.)
- (2) Since the application instructions for the K0, K2, etc. are not converted into application instructions for K3NCPU, note the following points:
 - 1) After conversion to K3N program, change the application instruction numbers, data register numbers, etc. to those of K3N.
 - 2) Some of the application instructions for the K0J and K2 are not available on the K3NCPU.

For example, conversion of a program using F111 to K3N program (dissociation of 16-bit data to two 8-bit datas)



User must make changes shown below.

- 1) D110 → DA10
- 2) D111 → DA11
- 3) F111 → F157

(Conversion required by user)

- (3) The reverse conversion procedure: K3NCPU program to K0, K0J, K1, K2 program cannot be executed.

- (4) For full details on K3NCPU programs refer to the programming manual.

11. CONVERSION TO PROGRAM FOR K3



11.1 Conversion to K3 Program

Conversion of programs of K0, K0J, K1, and K2 to K3NCPU program.



BASIC OPERATION



OPERATION PROCEDURE

K1
K0, K0J1, K0J1H
K0J2, K0J2P → K3
K2, K2H, K2N, K2A

PROGRAM CONVERSION

PRESS (GO) WHEN OK

PRESS MODE KEY WHEN NO



Conversion execution

EXPLANATION

- (1) To convert a program, set the PC to K3N on the "INITIAL DATA" screen.
- (2) Read the program for K0, K0J, K1, and K2 from the FD or ROM, to the A6GPP and perform the conversion operation.
(After program conversion, the K3NCPU program is stored in the internal memory of the A6GPP and the program prior to the conversion no longer exists within the A6GPP memory.)

REMARKS


When K3N is selected in the initial setting and the program to be converted is read from the FD to the internal memory, "PC SELECTION ERROR" is displayed in the message column. However, when the **CR** key is pressed again, the read operation is initiated. (Refer to Section 7.3.)

- (3) When the **GO** key is pressed to execute program conversion, "EXECUTING" is displayed in the message column. Upon completion of the conversion up to the memory capacity selected on the initial data screen, "COMPLETED" is displayed.
- (4) If there are instruction codes which cannot be converted into instructions for the K3NCPU, these are converted to NOPs, "COMMAND ERROR, ERROR STEP = * * * *" is displayed, and "COMPLETED" is not displayed.
If "COMMAND ERROR" is displayed, read the indicated error step numbers and make corrections.
- (5) To cancel program conversion, select another mode key before pressing the **GO** key to start conversion.
When program conversion has been completed, select another mode key to proceed to the next operation.

11. CONVERSION TO PROGRAM FOR K3



- (6) To abort conversion, press the **CLEAR** key. To resume the conversion, press the **GO** key. To complete the conversion, press the **END** and **GO** keys.
- (7) The sequence of display screens is as shown below.




12. MICROCOMPUTER MODE



12. MICROCOMPUTER MODE

In microcomputer mode, the program stored in A6GPP memory can be read in hexadecimal. When connected to one of the following PCs: K2CPU-S1, S3, K2HCPU, K2NCP, or K3NCP(P2), a program can be written with microcomputer instructions. The write and read operations to and from the programmable controller are the same as those in PC mode.

12.1 Memory Map of Each CPU



*1: When a microcomputer program is written, the program area for each CPU is as indicated below:

K2CPU-S1, S3, K2HCPU, K2NCP:

4000H to 4FFFH = sequence program


5000H to 5FFFH = microcomputer program

K3NCP(P2):

8000H to 9FFFH = sequence program

A000H to FCFFH = microcomputer program

*2: The 6000H to 67FFH data memory area (K3NCP(P2)) is used as four memory areas: data register (D), input image (X), output image (Y), and data area (M, T, C, F). Since each area is managed as a subroutine, read and write operations for each area are done using the CALL instruction.



Subroutines for Read and Write of Data Memory Areas

Memory Area Name	Subroutine Name	Instruction Word	Machine Word
Data register (D)	CLD	PUSH PSW LD A. E0H LD 22F8H. A LD 2E00H. A POP PSW RET	F5 3E. E0 32. F8. 22 32. 00. 2E F1 C9
Input image (X)	CLX	PUSH PSW LD A. E8H LD 22F8H. A LD 2E00H. A POP PSW RET	F5 3E. E8 32. F8. 22 32. 00. 2E F1 C9
Output image (Y)	CLY	PUSH PSW LD A. F0H LD 22F8H. A LD 2E00H. A POP PSW RET	F5 3E. F0 32. F8. 22 32. 00. 2E F1 C9
Data area (M, T, C, F)	CLM	PUSH PSW LD A. 0CH LD 22F8H. A LD 2E00H. A POP PSW RET	F5 3E. 0C 32. F8. 22 32. 00. 2E F1 C9


12. MICROCOMPUTER MODE



12.2 Internal Configuration of Data Memory


Data register (D)

- The data register consists of 2 bytes.




Input image memory

- The input image memory consists of 1 byte.
- B0 contains ON/OFF data.
- Use the *marked B1 to B7 after masking them.




Output image memory

- The output image memory consists of 1 byte.
- B0 contains ON/OFF data.
- Use the * marked B1 to B7 after masking them.




M, F, MC

- M, F, and MC consist of 1 byte each.
- B0 contains ON/OFF data.
- Use the * marked B1 to B7 after masking them.




Contact and coil of timer and counter

- The contact and coil of timer and counter consist of 1 byte each.
- B0 contains ON/OFF data of contact.
- B7 contains ON/OFF data of coil.
- Use the * marked B1 to B6 after masking them.



Present value of timer and counter

- The present value of timer and counter consists of 2 bytes.




12. MICROCOMPUTER MODE


12.3 Microcomputer Program Call Example

Calling a microcomputer program during a sequence is as follows:

K2CPU-S1, S3, K2HCPU, K2NCPU



K3NCPU(P2)



POINT

If insertions or deletions are made to the sequence program after the creation of the microcomputer program, the addresses of the microcomputer program will change. Therefore, be sure to read the initial data setting screen and re-set the memory capacity to the sequence program capacity (the microcomputer program capacity excluded), and after completion of the insertion or deletion operation, set the memory to "sequence program + microcomputer program" capacity again.

12. MICROCOMPUTER MODE


MELSEC-A

12.4 Microcomputer Mode Read

Reads hexadecimal data representing the contents of specified program addresses.

**MICRO
MODE
READ**


BASIC OPERATION



OPERATION PROCEDURE

```

1000 =00 =00 =00 =00 =00 =00 =00 =00 =00 =00 =00 =00 =00 =00
1010 =00 =00 =00
    0  1  2  3  4  5  6  7  8  9  A  B  C  D  E  F
  
```



(Example: Read contents of address 1000)

EXPLANATION

- (1) By pressing the **OTHER** key, read the "MODE SELECTION" screen, select **MICROCOMPUTER**, and press the **RD** key. Then, specify the address number to be read and press the **GO** key. Each time the **GO** key is pressed, the contents of the next address number to the specified one is read.
- (2) The readable address range is 0000 to 7CFF (step 0 to step 15999). If an address outside of this range is specified, "OPERATOR ERROR" is displayed. In this case, press the **RD** key and set a valid address number.

12. MICROCOMPUTER MODE

MELSEC-A

12.5 Microcomputer Mode Write

Allows machine code programs to be written into the specified memory location.

**MICRO
MODE
WRITE**


BASIC OPERATION



OPERATION PROCEDURE

1000=30=01

0 1 2 3 4 5 6 7 8 9 A B C D E F



(Example: Write of machine language 30 to address 1000)

EXPLANATION

- (1) Specify the address, into which the data is to be written using the read function in microcomputer mode. After the read operation, press the **WR** key and write the code required.
- (2) After pressing the **GO** key, the display screen shows the next address (specified address + 1) and so the write operation can be performed continuously.

IMPORTANT



In microcomputer mode, the read and write operations can be performed for address 0 to 15999. However, since the sequence program is stored in the first half of these addresses, never perform the write operation to the sequence program area as the CPU may act unpredictably.

13. INITIAL DATA READING OR "SOFT RESTART"




13. INITIAL DATA READING OR "SOFT RESTART"

Re-read of initial setting data.



OPERATION PROCEDURE



EXPLANATION

- (1) The initial data setting screen is displayed when the power of A6GPP is turned on or the reset button is pressed. However, it is possible to read the initial screen again without clearing the contents of the internal memory. This function is useful for changing the PC type during conversions to K3 programs or for changing memory capacity during the creation of programs.


POINT

- 1) If a program has been written for a K3NCPU and the PC type is then changed using the initial screen, attempting to read a ladder will result in "LADDER ERROR" or "NO END Instruction" being displayed.
- 2) If a program has been written for a CPU other than K3NCPU and the PC type is then changed using the initial screen, attempting to read a ladder will result in "DEVICE NO. ERROR" being displayed.

13. INITIAL DATA READING OR "SOFT RESTART"




(2) The sequence of display screens is as shown below.




14. TROUBLESHOOTING


14.1 Troubleshooting when Loading the SW1-GPPK



14.2 Troubleshooting during Communication with Programmable Controller (PC)




14.3 Troubleshooting during FDD Operation



POINT

- (1) Insert the FD with care and in the right direction. Do not force the FD into the FDD.
- (2) If an FD, storing formatted data, is formatted again by mistake, all data will be cleared. Therefore, caution should be exercised.


14.4 Troubleshooting during ROM Operation



*1: Re-load correctly.


- 1) Is the loading direction correct?
- 2) Is the ROM securely inserted in the socket?
- 3) Is the ROM socket lever correctly set?
- 4) Has the ROM been damaged by being incorrectly loaded or used?

14.5 Troubleshooting during Printer Operation



*1: When a cable selected by user (other than the AC30R2) is used for the general-purpose printer, check the wiring of the cable. (Refer to Section 2.3.4 in the A6GPP user manual.)

14.6 Troubleshooting during Use of External CRT



15. MESSAGE LIST



15. MESSAGE LIST

This chapter describes error messages which are displayed in the message column on the screen. (Error messages displayed at the start of the system are not included see Section 14.1.)

15.1 Error Message List

When the error message is displayed, take corrective action and then proceed to the next operation.

Number	Display	Description	Corrective Action
1	CJ STEP NO. ERROR	The specified jump destination step number is lower than the step number of CJ instruction or it exceeds the memory capacity initially set.	Check the jump destination step number and change accordingly.
2	NO "END" COMMAND	The END instruction is not present in the program.	Select list mode and add the "END" instruction.
3	PC COMMUNI- CATION ERROR	The PC power is off.	Turn the PC power on.
		The ONLINE switch of K6HGPF is at "OFFLINE" position.	Set to "ONLINE".
		The cable is not connected or is defective.	Check the cable. Re-insert the cable. Check continuity of cable with a circuit tester, etc.
		The programmable controller CPU has been reset during communication.	Repeat the operation.
		RUN LED of programmable controller CPU has flickered during communication.	After correcting the cause of flickering, reset the programmable controller CPU and repeat the operation.
4	PRESS [Y] TO WRITE TO PC WHILE IT IS RUNNING PRESS [N] TO STOP	Write has been performed in PC mode when the programmable controller CPU is in RUN mode.	To execute write, press the "Y" key. To stop write, press the "N" key.
5	OPERATOR ERROR	An invalid key has been used An invalid operation has been attempted.	Use correct key. Check operating procedure.
6	PC SELECTION ERROR	The programmable controller selected on the initial screen is different from the PC connected to the A6GPP.	"Reset" the A6GPP and correct initial setting.
		Comment data has been written to a programmable controller CPU other than K3NCPUP2).	Comment data can only be written to the K3NCPUP2).
		The cable or K6HGPF is defective.	Re-connect the cable or K6HGPF. Check continuity of cable with a circuit tester, etc.
		Comment data has been read or verified with a programmable controller CPU other than K3NCPUP2).	Comment data can only be read from and verified with a K3NCPUP2).

15. MESSAGE LIST



Number	Display	Description	Corrective Action
7	DEVICE NUMBER ERROR	An invalid device has been specified. The PC number has been set to other than "1" in the initial setting and a device number matching the PC number has not been specified.	Check the device number and perform the operation again.
8	LADDER ERROR	Illogical or incomplete ladder diagram which cannot be converted.	Correct the ladder.
9	LADDER OVERFLOW (OR) LADDER DISPLAYED OVERFLOWS	Conversion of the following circuits has been attempted: Ladder block consists of 23 lines or more. Ladder which has 161 or more serial contacts. Ladder which has eight or more ANB and/or ORB instructions continuously. Ladder which has nine or more LD instructions.	Re-write ladder concerned.
10	WRITE-IN FORBIDDEN	Write has been performed in PC mode when WRITE IN CPU switch of A6GPP is at FORBID position.	Set the WRITE IN CPU switch to PERMIT position.
11	COMMENT MEMORY EXCEEDED	The capacity of the comment memory has been exceeded (2049).	Reduce the comment memory used to 2048 or less.
12	STEP NUMBER ERROR	A step number, which exceeds the memory capacity set in the initial setting, has been specified.	Re-select the initial setting or change the specified step number.
13	PROGRAM TOO LARGE	During ladder conversion, the memory capacity set in the initial setting has been exceeded.	Increase the memory capacity in the initial setting or reduce the number of steps.
14	DATA UNMATCHED	The memory capacity selected at the start is different from the memory capacity of PC.	Re-select memory capacity.
15	PRINTER ERROR (OR) CHECK "PRINTER"	The POWER or SEL switch of printer is at "OFF" position.	Set the POWER or SEL switch to "ON" position.
		The printer has run out of paper.	Load paper.
		The cable is not connected.	Connect the cable.
16	VERIFY ERROR	The contents of A6GPP and those of EP-ROM do not coincide with each other during ROM verify.	Correct non-coinciding program areas.
17	WRITE-IN ERROR	When in PC mode and writing to the programmable controller CPU, the memory for storing the sequence program in the programmable controller CPU is not loaded or the memory capacity is insufficient, or ROM is loaded. When comment data has been written, Type K3MB1 auxiliary memory card is not loaded in the K3NCPU(P2). The ROM is not suitable or wrongly inserted in the socket.	Load the RAM or K3MB1 to the programmable controller CPU. Check ROM.

15. MESSAGE LIST



Number	Display	Description	Corrective Action
18	COMMAND CODE ERROR	An error code, i.e. F device which cannot be converted into sequence instruction, has been used.	Change to normal instruction.
19	COMMAND ERROR	An invalid instruction has been used.	Rewrite the instruction.
20	MEMORY PROTECT	Write has been attempted in PC mode with the MEMORY PROTECT switch of K3NCPU turned on.	Set the MEMORY PROTECT switch to "OFF" position.
21	COIL ALREADY USED	The same coil has been specified twice or more.	Although the same coil can be written twice or more in certain situations, this should be avoided.
22	NOT FOUND	Specified parameter does not exist.	Proceed.
23	CIRCUIT CONTINUATION ERROR	Return fault has occurred during the creation of ladder.	Perform correct returning operation.
24	WRONG KEY FOR COMMENT	A key, which cannot be used for a comment, has been used.	Press a character which can be used for comments.
25	ROM NOT ERASED	The contents of ROM have not been erased.	Erase the contents of ROM or use a new ROM.
26	FLOPPY DISK ERROR	No FD in accessed drive. FD in write forbid state. FD is defective.	Insert FD or access correct drive. Set the write protect tab of FD to "OK" position. Change the FD.
27	SYSTEM NAME ALREADY USED	The same system name already exists on that FD. This may apply to a program name or to a utilized circuit designation. (i.e. S0, S1, S2, etc.)	Press CR key to overwrite on the same system name, or change the system name.
28	FILE MISSING	The specified file name is not on the FD.	Check the file name in the directory.
30	SYSTEM NAME ERROR	Same system name for source and/or destination.	Change the system name of copy destination.
31	TOO LARGE FOR MEMORY CAPACITY	The remaining FD memory capacity is too small to write.	Change to a new FD or delete unnecessary data.
		The set memory capacity is larger than the ROM capacity.	Re-set the memory capacity.

15. MESSAGE LIST



15.2 Message List

Number	Display	Description
1	DELETE 1-CIRCUIT	Indicates that a circuit block is to be deleted.
2	LADDER END	Ladder display has reached the program end.
3	DISPLAY OVERFLOW	A ladder which has a ladder block consisting of 13 or more lines has been read.
4	LADDER DISPLAYED OVERFLOWS	A ladder which has a ladder block consisting of 25 or more lines has been read. (Although a ladder display of 25 lines or more cannot be made, list display can be made.)
5	COMPLETED	Read, write, verify, or ladder conversion operation for PC, ROM, or FD has been completed. Printing is complete.
6	COMPLETED * STEP NOS. CHANGED	Step numbers have changed.
7	PRESS (CNV)?	The RD key or mode key has been pressed without making ladder conversion. Press [CNV] [GO] to write program to A6GPP internal memory.
8	SELECT READ	Press the RD key for the next operation.
9	EXECUTING	Read, write, verify, or ladder conversion operation for PC, ROM, or FD is being performed.
10	SELECT MODE	Select mode for the next operation.
11	SELECT FUNCTION	Select function for the next operation.
12	ON/OFF	Forced on or off of output Y has been performed in the ladder test.
13	VERIFYING	Verify is being performed.
14	MONITOR STOP	Trigger stop has been effected or the CLEAR key has been pressed during ladder monitor.
15	EXECUTING * PRESS (CR) TO STOP	Printing, device used list display, or contact and coil list display is being performed.
16	STOP * PRESS (GO) TO RESTART PRESS (END) (GO) TO END	The CLEAR key has been pressed during printing, device used list display, or contact and coil list display.

15. MESSAGE LIST

15.3 Error Messages and Messages Printed on Print Paper

One of the following error messages may be printed. When the error message has been printed, check the error contents and correct.









Error Message	Description	Corrective Action
ILLOGICAL DIAGRAM	Printing of illogical program has been performed in ladder mode.	Correct the illogical portion.
INSTRUCTION CODE ERROR	The sequence instructions have not been converted to normal internal code (during conversion).	Correct errors.
MISSING END INSTRUCTION	END instruction has been omitted.	Check the step number of END instruction. Write END at the last step of program.
NOT FOUND	The program is not in the internal memory or there is END instruction at step 0.	Create a correct program.
DEVICE OVER	If the device specified in cross ref. appears more than 500 times, this message appears.	This is not an error. However, the step number for contact of 500th device or devices with higher numbers cannot be printed.
DEVICE NO. ERROR	The PC type set during the creation of program is different from the PC type set for printing.	Check the PC type and correct.







Message	Description
LADDER END	Printing of the last ladder block is complete (printed at the bottom left of print paper).
LADDER CONTINUES	When one ladder block extends over two or more pages, the message is printed at the bottom left of print paper.

APPENDICES

APPENDIX 1 Illogical Ladder Examples


The following circuits are illogical.

Incorrect Ladder	Correct Ladder
<p>(1) Ladder which has no contact in front of data instruction.</p> 	 <p>M100 is unused dummy M.</p>
<p>(2) Ladder which has a branch coil in front of contact.</p> 	
<p>(3) Ladder which includes "OR".</p> 	
<p>(4) "Sneak" path</p> 	


Incorrect Ladder	Correct Ladder
<p>(5) Ladder which has improperly located return numbers</p> 	
<p>(6) Correction of return number setting.</p> 	
<p>(7) In the following ladder, X1 is ignored.</p> 	

(8)

1)




2)



The above circuits would contain more than 8 ANB or ORB instructions; this is invalid and must be corrected using auxiliary elements to split up the ladder.

3)




As MCR instructions are omitted during the conversion process, do not proceed them with a contact.

APPENDIX 2 Reading Data from K8GPP to GPP/PHP


Read programs and comments stored in K8GPP to the internal memory of GPP/PHP as described below.

(1) Required equipment


- 1) K8GPP
- 2) A6GPP
- 3) K6HGPF
- 4) AC30R4



(2) To read programs stored in K8GPP to the internal memory of GPP/PHP



(3) To read comments stored in K8GPP to the internal memory of A6GPP



REMARKS

Data other than programs and comments (file register and device memory) cannot be read. (If such data is read, "OPERATOR ERROR" is displayed.)

APPENDIX 3 Comparison of Functions between A6GPP (SW1-GPPK) and K8GPP

Item	K8GPP	A6GPP
ROM mode	The ROM mode functions are not provided. For the storage of internal program to ROM, K6WU or K6PRT is required.	The ROM socket is standard. Read, write, verify, and erase check functions are incorporated.
Printer mode	The printer mode functions are not provided. For printing, K6PRF or K6PRT is required.	<p>The RS232C interface is standard and direct connection to the printer is possible without the interface unit.</p> <p>Built-in functions</p> <ul style="list-style-type: none"> • Ladder print • Ladder print with comment • Ladder print with step number for contact (only A6GPP) • Command list print • Command list print with comment (only A6GPP) • Device used list print • Contact and coil list print (with T/C setting value) (only A6GPP) • Comment list print • Plural print (only A6GPP) • Print starting page specification (only A6GPP) • Print starting position specification (only A6GPP)
FDD mode	The FDD mode function are not provided.	<p>Two FDDs are standard-equipped.</p> <p>Built-in functions</p> <ul style="list-style-type: none"> • Directory • Read from FD • Write to FD • Verify with FD • File deletion • File copy • Formatting • Automatic write
PC mode	<p>Built-in fuctions</p> <ul style="list-style-type: none"> RD — Read of sequence program Read of comment data WR — Write of sequence program Write of comment data VER — Verify of sequence program Verify of comment data TEST — Forced output Forced set, reset Present value change Display of error step number 	<p>Built-in functions</p> <ul style="list-style-type: none"> RD — Read of sequence program Read of comment data Read of device memory data WR — Write of sequence program Write of comment data Write of device memory data VER — Verify of sequence program Verify of comment data Verify of device memory data TEST — Forced output Forced set, reset Present value change Display of error step number

Item	K8GPP	A6GPP
List mode	<p>Built-in functions</p> <ul style="list-style-type: none"> RD <ul style="list-style-type: none"> Read by step number Read by I/O number Read by instruction Display of device used list Display of contact and coil list WR <ul style="list-style-type: none"> Memory clear New/correction INS — Insertion by instruction DEL <ul style="list-style-type: none"> Deletion per instruction Batch NOP deletion 	<p>Built-in functions</p> <ul style="list-style-type: none"> RD <ul style="list-style-type: none"> Read by step number Read by I/O number Read by instruction Display of device used list Display of contact and coil list Display of command list with comments WR <ul style="list-style-type: none"> Memory clear New/correction INS — Insertion by instruction DEL <ul style="list-style-type: none"> Deletion per instruction Batch NOP deletion MNT <ul style="list-style-type: none"> Batch list monitor Display of device memory contents in GPP (Test) CNV <ul style="list-style-type: none"> Batch device conversion Batch "N/O" "N/C" contact conversion
Ladder mode	<p>Built-in functions</p> <ul style="list-style-type: none"> RD <ul style="list-style-type: none"> Read by step number Read by I/O number Read by contact or coil number Read by instruction Read by the last ladder block Read of preceding ladder block and succeeding ladder block Read of upper and lower ladder blocks outside the range of screen display Display of circuit with comment WR <ul style="list-style-type: none"> Creation of new ladder Correction of existing ladder Insertion/addition of ladder block Circuit utilization INS — Insertion in units of ladder symbols DEL <ul style="list-style-type: none"> Deletion of one ladder block Deletion in units of ladder symbols MNT <ul style="list-style-type: none"> Ladder monitor by step number Ladder monitor by I/O number Ladder monitor by contact or coil number Ladder monitor by instruction search Last ladder block monitor by END instruction Ladder monitor of preceding ladder block and succeeding ladder block Ladder monitor with comment Monitor screen stop TEST <ul style="list-style-type: none"> Step run for K3CPU Forced output Forced set, reset Present value change 	<p>Built-in functions</p> <ul style="list-style-type: none"> RD <ul style="list-style-type: none"> Read by step number Read by I/O number Read by contact or coil number Read by instruction Read by the last ladder block Read of preceding ladder block and succeeding ladder block Read of upper and lower ladder blocks outside the range of screen display Display of ladder with comment WR <ul style="list-style-type: none"> Creation of new ladder Correction of existing ladder Insertion/addition of ladder block (Addition to the front of ladder possible) Ladder utilization INS — Insertion in units of ladder symbols DEL <ul style="list-style-type: none"> Deletion of one ladder block Deletion in units of ladder symbols MNT <ul style="list-style-type: none"> Ladder monitor by step number Ladder monitor by I/O number Ladder monitor by contact or coil number Ladder monitor by instruction search Last ladder block monitor by END instruction Ladder monitor of preceding ladder block and succeeding ladder block Ladder monitor with comment Monitor screen stop Entry monitor Monitor of present value of data register, timer and counter in hexadecimal

Item	K8GPP	A6GPP
Ladder mode		<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">TEST</div> <div style="margin-left: 5px;"> <ul style="list-style-type: none"> — Step run for K3NCPU — Forced output — Forced set, reset — Present value change </div> </div> <p>(Monitor)</p>
Parameter mode	The parameter mode functions are not provided. The automatic verify of sequence program is always performed before ladder monitor operation.	The parameter mode functions are incorporated. The execution or non-execution of automatic verify can be selected before ladder monitor operation.
CRT display	Ladder read: 11 lines List read: 20 lines	Ladder read: 12 lines List read: 23 lines
External CRT display	The external CRT display function is not provided.	Composite video interface is standard. An external CRT can be connected.
CRT	9 inches	7 inches
Internal memory	32K bytes. Backed up by battery.	960K bytes. No battery backup. Remarks: Save to FD is required.
Key depression	Continuous depression of the same key cannot be made.	Continuous depression of the same key can be made.
Operating ambient temperature	0°C to 65°C	10°C to 45°C
Storage ambient temperature	-10°C to 65°C	-10°C to 45°C

APPENDIX 4 Processing Time List

This chapter describes the processing time of programmable controller CPU, FD, ROM, and printer, for operations with the GPP/PHP.

4.1 Programmable Controller CPU

Memory Capacity	Processing Time (Second)		
	Read	Write	Verify
2K bytes	6	12	6
4K bytes	10	25	12
8K bytes	20	44	23
16K bytes	40	69	45
32K bytes	79	109	83

4.2 Floppy Disk

Memory Capacity	Processing Time (Second)				
	Read	Write	Verify	Copy	Format
2K bytes	1	3	7	11	
4K bytes	2	4	16	12	
8K bytes	3	5	33	14	67
16K bytes	4	7	65	18	
32K bytes	5	10	130	24	

(The processing time in the above table applies also to the "automatic write to FD" function in the FDD mode.)

4.3 ROM

Memory Capacity (Type)	Processing Time (Second)		
	Read	Write	Verify
2K bytes (2716)	0.05	99	0.05
4K bytes (2732)	0.1	198	0.1
8K bytes (2764)	0.2	43	0.2
16 bytes (27128)	0.6	85	0.6
32K bytes (27256)	1.5	133	1.5

(Since high-speed write can be performed for ROM types 2764, 27128, and 27256, write time is shorter than the above in regards to the above indicated ROM types.)

4.4 Printer

Processing Mode		Processing Time (Second)
Circuit	Pica	3/line
	Elite	5/line
List	Pica	47/page
	Elite	63/page

(By use of K6PRE printer)

APPENDIX 5 Printer Output Codes

1. Printer Output Codes

The codes of alphanumeric characters output from the GPP/PHP to the printer conform to the *1 JIS code specifications (excluding the GT-10A).

Line Col. min	HEX															
	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0			SP	0	@	P	r	p			SP	-				
1			l	1	A	Q	a	q			o					
2			"	2	B	R	b	r								
3			#	3	C	S	c	s								
4			\$	4	D	T	d	t								
5			%	5	E	U	e	u								
6			&	6	F	V	f	v								
7			.	7	G	W	g	w								
8	BS		(8	H	X	h	x								
9	HT)	9	I	Y	i	y								
A	LF		*	:	J	Z	j	z								
B		ESC	+	:	K	[k	}								
C			.	<	L	Y	l									
D	CR		-	=	M]	m	}								
E	SO		o	>	N	v	n	-								
F	SI		/	?	O	-	o	DEL								

JIS Code Specifications

For required symbols, such as contacts and coils, the following codes are output.

Display of A6GPP	Output Code to Printer (Hexadecimal)	
	K6PRE	K6PRE general-purpose printer
	80, 81	5D, 5B
	82, 83	5D, 2F, 5B
	84, 85	28, 29
	86, 87	5B, 5D
 (horizontal line)	99	2D
 (vertical line)	9A	7C
	9E	2D, 3E

*1 : JIS : Japanese Industrial Standard

2. GT-10A Printer Output Codes

Codes output from the GPP/PHP to the GT-10A are as indicated in the following table.

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	≡	P	SP	0			▸	■	NUL		!	←	SP	p	□	▬
1	A	Q	▬	1			▬				#		a	q	□	SP
2	B	R	▬	2			▬			DC2	\$	SP	b	r	□	SP
3	C	S	▬	3			▬				%	SP	c	s	□	SP
4	D	T	▬	4			▬			DC4	&	SP	d	t	□	SP
5	E	U	▬	5			▬				{	SP	e	u	□	SP
6	F	V	▬	6							}	SP	f	v	□	SP
7	G	W	▬	7			■		BEL		*	SP	g	w	□	SP
8	H	X	▬	8					BS		~	SP	h	x	□	SP
9	I	Y	▬	9							/	SP	i	y	▬	SP
A	J	Z	▬						LF		<	SP	j	z	▬	SP
B	K		+						VT	ESC)	SP	k	{	▬	SP
C	L		▬						FF		=	SP	l		▬	SP
D	M		▬						CR		:	SP	m	}	▬	SP
E	N		▬						SO		;	SP	n	▬	▬	SP
F	O		▬	?		□			SI		→	SP	o	SP	▬	SP

GT-10A Code Specifications

REMARKS

In the above table, the "shaded" codes cannot be used when the GT-10A (old) is employed. Among symbols printed by the GT-10A (old), the symbols shown in the following table are different from those of the GT-10A (new).

GT-10A (NEW)	GT-10A (OLD)
*	X
/	
>]
<	[
▸ ▬	▬

REMARKS

To identify the GT-10A (old) and the GT-10A (new), check the name plate located at the rear of GT-10A printer. "GT-10A" is indicated on the name plate of old type GT-10A. "GT-10A 1" is indicated on the name plate of new type.

APPENDIX 6 PC Availably

○ indicates that these K-series models may be available in the following countries.

MODEL \ COUNTRY		COUNTRY						
		JAPAN	U.S.A	U.K	EUROPE	AUSTRALIA	TAIWAN	KOREA
CPU	K0CPU	○			○	○		
	K0J1CPU	○						
	K0J1HCPU	○						
	K0J2CPU	○	○	○	○	○	○	○
	K0J2PCPU	○	○	○	○	○	○	○
	K1CPU	○						
	K1CPU-S1	○						
	K2CPU	○						
	K2CPU-S1	○						
	K2CPU-S2	○						
	K2CPU-S3	○	○	○	○	○	○	○
	K2HCPU	○	○	○	○	○	○	○
	K2NCPUP	○	○	○	○	○	○	○
	K2ACPU	○						
	K3NCPUP	○	○	○	○	○	○	○
	K3NCPUP2	○	○	○	○	○	○	○
I/F	K6HGPF / K6HGPF	○ / ○	○ / ○	○ / ○	○ / ○	○ / ○	○ / ○	○ / ○
CBL	AC30R4	○	○	○	○	○	○	○
GPP	A6GPPE / A6GPP	○ / ○	○ / ○	○ / ○	○ / ○	○ / ○	○ / ○	○ / ○
FD	SW1-GPPKEE	○	○	○		○	○	○
	SW1-GPPKEG				○			
	SW0-GPPU	○	○	○	○	○	○	○
	SW0-FDC	○	○	○	○	○	○	○

MODEL \ COUNTRY		COUNTRY						
		JAPAN	U.S.A	U.K	EUROPE	AUSTRALIA	TAIWAN	KOREA
ROM	1KROM	○	○	○	○	○	○	○
	2KROM	○	○	○	○	○	○	○
	4KROM	○	○	○	○	○	○	○
	8KROM	○	○	○	○	○	○	○
	16KROM	○	○	○	○	○	○	○
CBL	AC30R2	○	○	○	○	○	○	○
PRINTER	K6PRE	○	○	○	○	○	○	○
	K6PR	○						
	K6PR-K	○						
	K7PRE	○	○	○	○	○	○	○
	K7PR	○						
	A7PR	○						
	GT-10A (OLD)	○		○	○			
GT-10A (NEW)	○		○	○				
CBL	AC10MD	○	○	○	○	○	○	○

APPENDIX 7 Quick Reference Summary

Mode	Function Selection	Function	Basic Operation
LDR or CIRCUIT	Write	Creation of new circuit	LDR → WR → NOP → GO → [Command input] → CNV → GO
		Correction of existing circuit	[Circuit read operation] → WR → [+] → [-] → [Command input operation] → CNV → GO
		Insertion/addition of circuit block	[Circuit read operation] → WR → [+] → [-] → GO → [Command input operation] → CNV → GO
	Read	Circuit read by step number	LDR → RD → SSN → Step number → GO
		Circuit read by contact or coil number	LDR → RD → Circuit symbol key → Device → Device number → GO
		Circuit read by I/O number	LDR → RD → Device → Device number → GO
		Circuit read by instruction	LDR → RD → Circuit symbol key → Command key → Device → Device number → GO
		The last circuit read by END instruction	LDR → RD → END → GO
		Display of circuit with comment	[Circuit read operation] → VER/COM
	Insertion	Insertion/addition of circuit symbols	[Circuit read operation] → INS → [↑] → [↓] → [→] → [←] → [Command input operation] → CNV → GO
			[Circuit read operation] → DEL → [○] → GO
	Deletion	Deletion of circuit symbols	[Circuit read operation] → DEL → [↑] → [↓] → [→] → [←] → GO → [Circuit write operation] → CNV → GO
			[Circuit read operation] → DEL → [○] → GO

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 X : PC communication modes, care must be taken not to accidentally change the pc program.

Mode	Function Selection	Function	Basic Operation
<div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">LDR</div> <div style="margin-bottom: 5px;">or</div> <div style="border: 1px solid black; padding: 2px;">CIRCUIT</div> </div>	Conversion	Entry of utilized circuit	
	Write	Utilization of entered circuit	
	Monitor	Circuit monitor	
	Monitor	Stop of monitor screen	
	Monitor	Screen stop by monitor stop point setting	
	Monitor	Entry monitor	
	Monitor	Decimal-hexadecimal present value monitor	

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 × : PC communication modes, care must be taken not to accidentally change the pc program.

Mode	Function Selection	Function	Basic Operation
CIRCUIT	Monitor	Forced output to programmable controller CPU	
		Step run of K3NCPU	
LIST	Write	All clear of memory (Continuous write of NOP)	
		Write of program list	
	Read	List read by step number	
		List read by device	
		List read by command	
		Read of list with comment	
		Display of device used list	

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 × : PC communication modes, care must be taken not to accidentally change the pc program.

Mode	Function Selection	Function	Basic Operation	
LST or LST	Read	Display of contact, coil list		
		Display of T/C setting value list		
	Insertion	Insertion of program list		
	Deletion	Deletion of program list		
	Conversion	Batch conversion of devices		
		Batch conversion of "N/O" and "N/C" contacts		
	Monitor	Batch monitor of device		
	Test	Display of device memory contents in GPP		
	PC	Write	Write to programmable controller	

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 × : PC communication modes, care must be taken not to accidentally change the pc program.

Mode	Function Selection	Function	Basic Operation
PC	Read	Read from programmable controller	PC → RD → { Menu selection operation }
	Verify	Verify with programmable controller memory contents	PC → VER/COM → { Menu selection operation }
	Test	Test to programmable controller	
FDD	Directory	Directory	FDD → CR → { Specified file name } → CR
	Read	Read from FD	FDD → ↓ → CR → { System name specification } → CR → { Memory area selection } → CR → CR
	Write	Write to FD	FDD → ↓ → ↓ → CR → { System name specification } → CR { Memory area selection } → CR → CR → CR
	Verify	Verify with FD	FDD → ↓ → ↓ → ↓ → CR → { System name specification } → CR { Memory area selection } → CR → CR → CR
	Deletion	Deletion of file on FD	FDD → ↓ → ↓ → ↓ → ↓ → CR { File name specification } → CR
	Copy	File copy	FDD → ↓ → ↓ → ↓ → ↓ → ↓ → CR { Copy source system name specification } → CR → { Copy destination system name specification } → CR
	Format	Formatting of FD	FDD → ↓ → ↓ → ↓ → ↓ → ↓ → ↓ → CR CR → CR → CR → CR

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 × : PC communication modes, care must be taken not to accidentally change the pc program.

Mode	Function Selection	Function	Basic Operation
FDD	Automatic write	Automatic write to FD	
	Cleaning	Cleaning disk	
COMMENT (OTHER)	Write	Write of comment data	
	Read	Read of comment data	
	Deletion	Deletion of comment data	
ROM (OTHER)	Read	Read from ROM	
	Write	Write to ROM	
	Verify	Verify with ROM	
	Erase check	Check of ROM erasure	

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 × : PC communication modes, care must be taken not to accidentally change the pc program.


Mode	Function Selection	Function	Basic Operation
PRINTER (OTHER)	Setting	Used printer setting	[Printer mode selection operation] → [Printer setting] → GO
	Baud rate	Baud rate setting	[Printer setting operation] → [↓] → GO
	Communication mode	Communication mode setting	[Printer setting operation] → [Baud rate setting] → GO [Parity check setting] → GO → [Data length and stop bit setting] → GO
	Paper length	Print paper length setting	[Normal mode setting operation] → [Paper length setting] → GO
	Print starting position	Print starting position setting	[Communication mode setting operation] → [Paper length setting operation] → [Setting of print starting position] → GO
	Mode	Mode setting	[Mode setting] → GO
	Page setting	Print starting page setting	[Page number specification] → GO
	Mode setting	Print mode setting	[Printer mode setting] → GO
	Ladder	Circuit print setting	[Printer mode setting] → [Circuit print setting] → GO
	Command list	Command list print setting	[Printer mode setting] → [Command list print setting] → GO → GO
	Contact, coil list	Contact, coil list print setting	[Printer mode setting] → [Contact/coil range setting] → END → GO
	Device used list	Device used list print setting	[Printer mode setting] → [Device used list range setting] → END → GO
	Comment list	Comment list print setting	[Printer mode setting] → [Comment list print range setting] → END → GO

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 X : PC communication modes, care must be taken not to accidentally change the pc program.


Mode	Function Selection	Function	Basic Operation
PRINTER (OTHER)	Utilized circuit	Utilized circuit print setting	[Printer mode selection] → GO
	Plural mode	Setting of plural mode	[Selection of plural mode by the mode setting] [Each mode range setting] → END → GO
	Screen copy	Screen copy	[Printer setting operation] → COPY
CONVERSION (OTHER)	Conversion	Conversion to program for K3	OTHER → ↓ → ↓ → ↓ → GO → GO
MICRO COMPUTER (OTHER)	Read	Read in microcomputer mode	OTHER → Microcomputer selection → RD → Address number → GO
	Write	Write in microcomputer mode	OTHER → [Microcomputer selection] → RD → Address number → GO → WR → Machine language → GO
INITIAL (OTHER)	Reread	Re-read initial data setting screen	OTHER → ↓ → ↓ → ↓ → ↓ → ↓ → ↓ → GO

○ : Must be (or recommended to be) selected to perform this operation.
 △ : Not applicable to the function concerned.
 × : PC communication modes, care must be taken not to accidentally change the pc program.


APPENDIX 8 Floppy Disk Using Instructions




Do not place the FD in a place where temperature and/or humidity is high. If adversely affected by high temperature and/or humidity, the FD may be warped. Also, if temperature and/or humidity change considerably, dew condensation may occur, resulting in error. Therefore, do not immediately use a FD, which has been mailed or brought into a room from outside, but use it after adjusting the FD to the operating environment for 30 to 60 minutes.




Do not expose the FD to the direct rays of the sun. The FD may be warped.




Do not touch the recording surface. The grease of fingers will stick to the magnetic head, resulting not only in error but also in the damage of magnetic disk. Also, fingerprints will lead to the reduction of output, the adhesion of dirt and dust, and the growth of mold.




Do not bend or break the FD. If bent or broken, the FD will be deformed, resulting in uneven rotation, error, etc.




Do not use thinners, alcohol, freon, and the like to clean a FD.




Do not place objects on the FD.
If a heavy object is placed on the FD, the FD may be deformed.




Do not bring the FD near to a magnet.
If the FD is brought near to an object which generates strong magnetism, stored data will be corrupted depending on the presence and direction of magnetism.




Do not clip the FD.
If a memorandum or the like is clipped to the FD, the FD may be damaged.




Do not write directly on the jacket.
Be sure to make an entry in the index label before applying the label to the jacket. If it is necessary to make an entry after the application of index label or make an entry on a permanent label, use a soft-tipped pen. Direct entry in the jacket results in damage and deformation.




Do not leave the FD uncovered.
Be sure to put the FD in the envelope and store it vertically. Also, during use, place the envelope in the plastic box.



Do not use an eraser.
If the waste rubber of an eraser attaches to the magnetic disk, error may result. Do not use an eraser near the FD.



Do not handle the FD roughly.
Insert the FD into the FDD carefully and gently, being careful not to damage the FD. Rough handling also damages the magnetic head of the drive.



Do not eat, drink, or smoke near the FD.
Cigarette smoke will also result in error. Especially, never use a FD which is wet.

IMPORTANT

The components on the printed circuit boards will be damaged by static electricity, so avoid handling them directly. If it is necessary to handle them take the following precautions.

- (1) Ground human body and work bench.**
- (2) Do not touch the conductive areas of the printed circuit board and its electrical parts with any non-grounded tools etc.**

Under no circumstances will Mitsubishi Electric be liable or responsible for any consequential damage that may arise as a result of the installation or use of this equipment.

All examples and diagrams shown in this manual are intended only as an aid to understanding the text, not to guarantee operation. Mitsubishi Electric will accept no responsibility for actual use of the product based on these illustrative examples.

Owing to the very great variety in possible applications of this equipment, you must satisfy yourself as to its suitability for your specific application.

type A6GPP/A6PHP(SW1GP-GPPK)

Operating Manual

MODEL	SW1GP-GPPK-O-E
MODEL CODE	13J758
IB(NA)66192-A(8901)MEE	

 **MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE : MITSUBISHI DENKI BLDG MARUNOUCHI TOKYO 100-0005 TELEX : J24532 CABLE MELCO TOKYO
NAGOYA WORKS : 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of International Trade and Industry for service transaction permission.

Specifications subject to change without notice.