





INSTRUCTION MANUAL (BASIC) FR-F740-00023 to 12120-EC

Thank you for choosing this Mitsubishi Inverter.

This Instruction Manual (basic) is intended for users who "just want to run the inverter".

If you are going to utilize functions and performance, refer to the *Instruction Manual (applied)* [IB-0600193ENG]. Please read the provided CD-ROM for the instruction manual (applied).

CONTENTS

1 PROD	OUCT CHECKING AND PARTS IDENTIFICATION	1	
2 INSTA	ALLATION AND WIRING	2	
2.1	Peripheral devices		
2.1	Method of removal and reinstallation of the front cover		
2.3	Installation of the inverter and instructions		
2.4	Wiring		
2.5	Power-off and magnetic contactor (MC)		_
2.6	Precautions for use of the inverter		
	THE MOTOR		
3.1	Step of operation		
3.2	Operation panel (FR-DU07)		
3.3	Overheat protection of the motor by the inverter (Pr. 9)		
3.4	Start/stop from the operation panel (PU operation mode)		
3.5	Make a start and stop with terminals (external operation)		
	STMENT		
4.1	Simple mode parameter list		
4.2	Increase the starting torque (Pr. 0)		
4.3	Limit the maximum and minimum output frequency (Pr. 1, Pr. 2)		_
4.4	When the rated motor frequency is 60Hz (Pr. 3)		
4.5	Change acceleration and deceleration time (Pr. 7, Pr. 8)		
4.6	Energy saving operation (Pr. 60)		
4.7	Selection of the operation command and frequency command locations (P		
4.8	Parameter clear, all parameter clear		
4.9	Parameter copy and parameter verification		
4.10	Parameter list		
4.11	Extended parameters		
4.12	Parameter list		
5 TROU	IBLESHOOTING	89	
 5.1	Reset method of protective function	89	_
5.2	List of alarm display	90	
5.3	Causes and corrective actions		
5.4	Correspondences between digital and actual characters		
5.5	Check and clear of the alarm history	103	
5.6	Check first when you have troubles	105	
6 PREC	AUTIONS FOR MAINTENANCE AND INSPECTION	108	
6.1	Inspection item	108	
7 SPEC	IFICATIONS	116	
 7.1	Rating	116	
7.2	Common specifications		
7.3	Outline dimension drawings		_
7.4	Heatsink protrusion attachment procedure		

This instruction manual (basic) provides handling information and precautions for use of the equipment. Please forward this instruction manual (basic) to the end user.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through this instruction manual (basic) and appended documents carefully and can use the equipment correctly. Do not use the inverter until you have a full knowledge of the equipment, safety information and instructions. In this instruction manual (basic), the safety instruction levels are classified into "WARNING" and "CAUTION".

MARNING Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

⚠CAUTION

Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the **ACAUTION** level may lead to a serious consequence according to conditions. Please follow strictly the instructions of both levels because they are important to personnel safety.

1. Electric Shock Prevention

AWARNING

- WHILE power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.m

 Do not run the inverter with the front cover or wiring cover removed.

 Otherwise, you may access the exposed high-voltage terminals or the charging part of the circuitry and get an electric shock.

 Even if power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.

 Before starting wiring, inspection or switching EMC filter on/off connector, switch off the inverter power, check to make sure that the operation panel indicator is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- switched off, and check that the like. The capacitor is charged with high voltage for some time and it is dangerous.

 This inverter must be earthed. Earthing must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)

 Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.

 Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.

- Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.

 Perform setting dial and key operations with dry hands to prevent an electric shock. Otherwise you may get an electric shock between the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.

 Do not replace the cooling fan while power is on. It is dangerous to replace the cooling fan while power is on.

 Do not touch the printed circuit board with wet hands. You may get an electric shock.

ACAUTION 2. Fire Prevention

- Mount the inverter on an incombustible wall without holes, etc. Mounting it to or near combustible material can cause a fire. If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire. Do not connect a resistor directly to the DC terminals P/+, N/-. This could cause a fire.

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur. Ensure that the cables are connected to the correct terminals. Otherwise,
- burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage, etc. may occur.

 While power is on or for some time after power-off, do not touch the inverter
- as it is hot and you may get burnt.

4. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric

(1) Transportation and installation

⚠CAUTION

- When carrying products, use correct lifting gear to prevent injury.

 Do not stack the inverter boxes higher than the number recommended
- Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the instruction manual. Do not install or operate the inverter if it is damaged or has parts missing. This
- can result in breakdowns.
 When carrying the inverter, do not hold it by the front cover or setting dial; it may fall off or fail.
- may fall off or fail.

 Do not stand or rest heavy objects on the product.
 Check the inverter mounting orientation is correct.
 Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.
 As the inverter is a precision instrument, do not drop or subject it to impact.
 Use the inverter under the following environmental conditions. Otherwise, the inverter may be damaged.

	Ambient	LD	-10°C to +50°C (non-freezing)		
	temperature	SLD (initial setting)	-10°C to +40°C (non-freezing)		
en	Ambient hu	midity	90% RH or less (non-condensing)		
E	Storage ten	nperature	-20°C to +65°C *1		
Environment	Atmosphere	9	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)		
	Altitude, vib	ration	Maximum 1000m above sea level for standard operation. After that derate by 3% for every		
	Ailitude, Vib	iation	extra 500m up to 2500m (92%) 5.9m/s ² or les		

- Temperature applicable for a short time, e.g. in transit.
- *2 2.9m/s² or less for the 04320 or more

(2) Wiring

⚠CAUTION

- Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the inverter output side.
- The connection orientation of the output cables U, V, W to the motor will affect the direction of rotation of the moto

(3) Test operation and adjustment

⚠CAUTION

Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

(4) Operation

riangle WARNING

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after an alarm stop.
 - The (STOP) key is valid only when the appropriate function setting(refer to page
 - 71) has been made. Prepare an emergency stop circuit (power off, mechanical brake operation for an emergency stop, etc.) and switch
- Make sure that the start signal is off before resetting the inverter alarm. A The load used should be a three-phase induction motor only. Connection of any
- other electrical equipment to the inverter output may damage the inverter as well as equipment
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

- The electronic thermal relay function does not guarantee protection of the motor from overheating.

 Do not use a magnetic contactor on the inverter input for frequent starting.
- stopping of the inverter.
 Use a noise filter to reduce the effect of electromagnetic interference
- Otherwise nearby electronic equipment may be affected.

 Take measures to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/damage the power factor correction capacitor and
- generator.
 When a 400V class motor is inverter-driven, please use an insulationenhanced motor or measures taken to suppress surge voltages. Surge voltages attributable to the wiring constants may occur at the motor terminals,
- deteriorating the insulation of the motor.

 When parameter clear or all clear is performed, reset the required parameters before starting operations. Each parameter returns to the initial
- The inverter can be easily set for high-speed operation. Before changing its setting, fully examine the performances of the motor and machine. In addition to the inverter's holding function, install a holding device to ensure
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.

 For prevention of damage due to static electricity, touch nearby metal before
- touching this product to eliminate static electricity from your body

(5) Emergency stop **ACAUTION**

- Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.
- When the breaker on the inverter input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause
- of the trip, then remove the cause and power on the breaker When the protective function is activated, take the corresponding corrective action, then reset the inverter, and resume operation.

(6) Maintenance, inspection and parts replacement $oldsymbol{\Lambda}$ CAUTION

Do not carry out a megger (insulation resistance) test on the control circuit of

(7) Disposing of the inverter

⚠CAUTION

Treat as industrial waste

General instructions

Many of the diagrams and drawings in this instruction manual (basic) show the inverter without a cover, or partially open. Never run the inverter in this status. Always replace the cover and follow this instruction manual (basic) when operating the inverter.

- CONTENTS -

PRODUCT CHECKING AND PARTS IDENTIFICATION

2 INSTALLATION AND WIRING	2
2.1 Peripheral devices	
2.2 Method of removal and reinstallation of the front cover	
2.3 Installation of the inverter and instructions	
2.4 Wiring	7
2.4.1 Terminal connection diagram	
2.4.2 EMC filter	
2.4.3 Specification of main circuit terminal2.4.4 Terminal arrangement of the main circuit terminal, power supply and the motor wiring	
2.4.5 Control circuit terminals	
2.4.6 Changing the control logic	
2.4.7 Wiring of control circuit	
2.4.8 When connecting the operation panel using a connection cable	22
2.4.9 RS-485 terminal block	
2.4.10 Communication operation	
2.5 Power-off and magnetic contactor (MC)	24
2.6 Precautions for use of the inverter	25
3 DRIVE THE MOTOR	27
3.1 Step of operation	27
3.2 Operation panel (FR-DU07)	28
3.2.1 Parts of the operation panel (FR-DU07)	28
3.2.2 Basic operation (factory setting)	
3.2.3 Operation lock (Press [MODE] for an extended time (2s))	
3.2.4 Monitoring of output current and output voltage	
3.2.5 First priority monitor	
3.2.7 Change the parameter setting value	
3.3 Overheat protection of the motor by the inverter (Pr. 9)	
3.4 Start/stop from the operation panel (PU operation mode)	
3.4.1 Set the set frequency to operate (example: performing operation at 30Hz)	
3.4.2 Use the setting dial like a potentiometer to perform operation	
3.4.3 Use switches to give a start command and a frequency setting (multi-speed setting)	
3.4.4 Perform frequency setting by analog (voltage input)	
3.4.5 Perform frequency setting by analog (current input)	40
3.5 Make a start and stop with terminals (external operation)	42
3.5.1 Use the set frequency set by the operation panel (Pr. 79 = 3)	
3.5.2 Use switches to give a start command and a frequency setting	
(multi-speed setting) (Pr. 4 to Pr. 6)	
3.5.3 Perform frequency setting by analog (voltage input)	
3.5.4 Change the frequency (50Hz) of the maximum value of potentiometer (at 5V)	
a a a - i EUOUU UEOUEUGA AEUUG DA AUAGOU GUUEU HUUUU	4 0

1

4	ADJUSTMENT	50
4.1	Simple mode parameter list	50
4.2	Increase the starting torque (Pr. 0)	51
4.3	Limit the maximum and minimum output frequency (Pr. 1, Pr. 2)	52
4.4	When the rated motor frequency is 60Hz (Pr. 3)	
4.5	Change acceleration and deceleration time (Pr. 7, Pr. 8)	
4.6	Energy saving operation (Pr. 60)	
4.6		
4.6	Optimum excitation control mode (setting "9")	
4.7	Selection of the operation command and frequency command locations (Pr. 79)57
4.8	Parameter clear, all parameter clear	
4.9	Parameter copy and parameter verification	59
4.9		
	9.2 Parameter verification	
4.10	Parameter list	61
4.1	10.1 List of parameters classified by purpose of use	61
4.11	Extended parameters	63
	11.1 Used to display the extended parameters	
	Parameter list	
5	TROUBLESHOOTING	89
5	TROUBLESHOOTING	89
5	TROUBLESHOOTING Reset method of protective function	
	Reset method of protective function	89
5.1 5.2	Reset method of protective functionList of alarm display	89 90
5.1 5.2 5.3	Reset method of protective function List of alarm display Causes and corrective actions	89 90
5.1 5.2 5.3 5.4	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters	89 90 91 102
5.1 5.2 5.3 5.4 5.5	Reset method of protective function. List of alarm display Causes and corrective actions Correspondences between digital and actual characters. Check and clear of the alarm history	89 90 91 102
5.1 5.2 5.3 5.4 5.5 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles	89 90 91 102 103
5.1 5.2 5.3 5.4 5.5 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles	89 90 91 102 103 105
5.1 5.2 5.3 5.4 5.5 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start Motor generates abnormal noise	89 91 102 103 105 105
5.1 5.2 5.3 5.4 5.5 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start Motor generates abnormal noise	89 90 91 103 105 105 105
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start 3.2 Motor generates abnormal noise 3.3 Motor generates heat abnormally 3.4 Motor rotates in opposite direction 3.5 Speed greatly differs from the setting	89 90 102 103 105 105 105 106 106
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start 3.2 Motor generates abnormal noise 3.3 Motor generates heat abnormally 3.4 Motor rotates in opposite direction 3.5 Speed greatly differs from the setting 3.6 Acceleration/deceleration is not smooth	89 90 91 103 105 105 105 106 106
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6 5.6 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start 3.2 Motor generates abnormal noise 3.3 Motor generates heat abnormally 3.4 Motor rotates in opposite direction 3.5 Speed greatly differs from the setting 3.6 Acceleration/deceleration is not smooth 3.7 Motor current is large	89 90 102 103 105 105 105 106 106 106
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6 5.6 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start 3.2 Motor generates abnormal noise 3.3 Motor generates heat abnormally 3.4 Motor rotates in opposite direction 3.5 Speed greatly differs from the setting 3.6 Acceleration/deceleration is not smooth 3.7 Motor current is large 3.8 Speed does not increase	89 91 102 103 105 105 106 106 106 106
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6 5.6 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start 3.2 Motor generates abnormal noise 3.3 Motor generates heat abnormally 3.4 Motor rotates in opposite direction 3.5 Speed greatly differs from the setting 3.6 Acceleration/deceleration is not smooth 3.7 Motor current is large 3.8 Speed does not increase 3.9 Speed varies during operation	89 91 102 103 105 105 106 106 106 106 106
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6 5.6 5.6 5.6 5.6	Reset method of protective function List of alarm display Causes and corrective actions Correspondences between digital and actual characters Check and clear of the alarm history Check first when you have troubles 3.1 Motor does not start 3.2 Motor generates abnormal noise 3.3 Motor generates heat abnormally 3.4 Motor rotates in opposite direction 3.5 Speed greatly differs from the setting 3.6 Acceleration/deceleration is not smooth 3.7 Motor current is large 3.8 Speed does not increase	89 90 102 103 105 105 105 106 106 106 106 106
5.1 5.2 5.3 5.4 5.5 5.6 5.6 5.6 5.6 5.6 5.6 5.6 5.6	Reset method of protective function. List of alarm display	89 90 102 103 105 105 106 106 106 106 106 107 107


Change the frequency (50Hz) of the maximum value of potentiometer (at 20mA)49

3.5.6

6 PRECAUTIONS FOR MAINTENANCE AND INSPECTION	N 108
	400
6.1 Inspection item	
6.1.1 Daily inspection	
6.1.3 Daily and periodic inspection	
6.1.4 Display of the life of the inverter parts	
6.1.5 Cleaning	
6.1.6 Replacement of parts	
6.1.7 Inverter replacement	115
7 SPECIFICATIONS	116
	4.40
7.1 Rating	
7.2 Common specifications	
7.3 Outline dimension drawings	119
7.3.1 Inverter outline dimension drawings	119
7.4 Heatsink protrusion attachment procedure	128
7.4.1 When using a heatsink protrusion attachment (FR-A7CN)	
7.4.2 Protrusion of heatsink of the FR-F740-04320 or more	128
APPENDICES	131
Appendix 1For customers who have replaced the older model with this	
inverter	131
Appendix 1-1Replacement of the FR-F500 series	
Appendix 1-2Replacement of the FR-A100 <excelent> series</excelent>	
Appendix 2 Instructions for UL and cUL Compliance	
Appendix 3 Instructions for Compliance with the European Directives	
<abbreviations></abbreviations>	
DU: Operation panel (FR-DU07) PU: Operation panel(FR-DU07) and parameter unit (FR-PU04/FR-PU07)	
Inverter: Mitsubishi inverter FR-F700 series	
FR-F700: Mitsubishi inverter FR-F700 series Pr.: Parameter Number	
PU operation: Operation using the PU (FR-DU07/FR-PU04/FR-PU07).	
External operation: Operation using the control circuit signals Combined operation: Combined operation using the PU (FR-DU07/FR-PU04/FR-PU07) and external	operation
Standard motor: SF-JR	opolation.
Constant-torque motor: SF-HRCA	
<trademarks></trademarks>	
LONWORKS® is registered trademarks of Echelon Corporation in the U.S.A. and other countries.	
DeviceNet is a registered trademark of ODVA (Open DeviceNet Vender Association, Inc.). Company and product names herein are the trademarks and registered trademarks of their respective	e owners.

PRODUCT CHECKING AND PARTS IDENTIFICATION

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.



(Refer to page 135)

Capacity	Screw Size (mm)	Number
00083, 00126	M3 × 35	1
00170 to 00380	M4 × 40	2
00470, 00620	M4 × 50	1


- · DC reactor supplied (01800 or more)
- · Eyebolt for hanging the inverter (00770 to 06830) M8 × two pieces



REMARKS

For removal and reinstallation of covers, refer to page 4.

INSTALLATION AND WIRING



Three-phase AC power supply

Use within the permissible power supply specifications of the inverter (Refer to page 116)

Moulded case circuit breaker (MCCB) or earth leakage current breaker (ELB), fuse

The breaker must be selected carefully since an in-rush current flows in the inverter at

(Refer to page 3)

Magnetic contactor(MC)

Install the magnetic contactor to ensure safety. Do not use this magnetic contactor to start and stop the inverter.

Doing so will cause the inverter life to be shorten. (Refer to page 3)


Reactor (FR-HAL, FR-HEL)

Reactors (option) should be used when power harmonics measures are taken, the power factor is to be improved or the inverter is installed near a large power supply system (1000kVA or more). The inverter may be damaged if you do not use reactors.

Select the reactor according to the model. For the 01160 or less, remove the jumpers across terminals P/+-P1 to connect to the DC reactor. (Refer to the Instruction Manual (applied).)

DC reactor


(FR-HEL)





Noise filter (FR-BLF) The 01160 or less

has a built-in comm mode core.



PI C

The inverter can be

connected with computers such as PLC.

It supports Mitsubishi inverter protocol and Modbus-RTU (binary) protocol.

Inverter (FR-F700)

The life of the inverter is influenced by ambient temperature. The ambient temperature should be as low as possible within the permissible range. Especially when mounting the inverter inside an enclosure, take cautions of the ambient temperature. (Refer to page 6) Wrong wiring might lead to damage of the inverter. The


control signal lines must be kept fully away from the main circuit to protect them from noise.(Refer to page 7) Refer to page 8 for the built-in EMC filter.



Noise filter (FR-BSF01, FR-BLF)

Install a noise filter to reduce the electromagnetic noise generated from the inverter. Effective in the range from about 1MHz to 10MHz. A wire should be wound four

turns at a maximum.



Devices connected to the output

Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the output side of the inverter.

When installing a moulded case circuit breaker on the output side of the inverter, contact each manufacturer for selection of the moulded case circuit breaker.

Earth

To prevent an electric shock, always earth the motor and inverter.



High power factor converter (FR-HC*1, MT-HC*2)

Power supply harmonics can be greatly suppressed. Install this as required. Power regeneration

common converter (FR-CV*1) Power regeneration converter (MT-RC*2)

Greater braking capability is obtained Install this as required.

*1 Compatible with the 01160 or less.
*2 Compatible with the 01800 or more

CAUTION :

Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the inverter output side. This will cause the inverter to trip or the capacitor, and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.

Brake unit (FR-BU*1, MT-BU5*2)

P/+

(FR-BR*1, MT-BR5*2)

The regenerative braking

Install this as required.

capability of the inverter can be

Resistor unit

exhibited fully.

Electromagnetic wave interference

The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, set the EMC filter valid to minimize interference.

(Refer to Instruction Manual (applied).)
Refer to the instruction manual of each option and peripheral devices for details of peripheral devices.


2.1 Peripheral devices

Check the motor capacity of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity. Refer to the following list and prepare appropriate peripheral devices:

400V class

Motor Output	A	В	reaker Selection	Input Side Magnetic Contactor*3		
(kW)	Applicable Inverter Type	Reactor	connection	with commercial	Reactor	connection
*1		without	with	power-supply operation	without	with
0.75	FR-F740-00023-EC	30AF 5A	30AF 5A	30AF 5A	S-N10	S-N10
1.5	FR-F740-00038-EC	30AF 10A	30AF 10A	30AF 10A	S-N10	S-N10
2.2	FR-F740-00052-EC	30AF 10A	30AF 10A	30AF 15A	S-N10	S-N10
3.7	FR-F740-00083-EC	30AF 20A	30AF 15A	30AF 20A	S-N10	S-N10
5.5	FR-F740-00126-EC	30AF 30A	30AF 20A	30AF 30A	S-N20	S-N11, N12
7.5	FR-F740-00170-EC	30AF 30A	30AF 30A	30AF 30A	S-N20	S-N20
11	FR-F740-00250-EC	50AF 50A	50AF 40A	50AF 50A	S-N20	S-N20
15	FR-F740-00310-EC	100AF 60A	50AF 50A	100AF 60A	S-N25	S-N20
18.5	FR-F740-00380-EC	100AF 75A	100AF 60A	100AF 75A	S-N25	S-N25
22	FR-F740-00470-EC	100AF 100A	100AF 75A	100AF 100A	S-N35	S-N25
30	FR-F740-00620-EC	225AF 125A	100AF 100A	225AF 125A	S-N50	S-N50
37	FR-F740-00770-EC	225AF 150A	225AF 125A	225AF 150A	S-N65	S-N50
45	FR-F740-00930-EC	225AF 175A	225AF 150A	225AF 175A	S-N80	S-N65
55	FR-F740-01160-EC	225AF 200A	225AF 175A	225AF 200A	S-N80	S-N80
75	FR-F740-01800-EC		225AF 225A	225AF 225A	_	S-N95
90	FR-F740-01800-EC	_	225AF 225A	400AF 300A	_	S-N150
110	FR-F740-02160-EC		225AF 225A	400AF 350A	_	S-N180
132	FR-F740-02600-EC	_	400AF 400A	400AF 400A		S-N220
160	FR-F740-03250-EC	_	400AF 400A	600AF 500A	_	S-N300
185	FR-F740-03610-EC	_	400AF 400A	600AF 500A		S-N300
220	FR-F740-04320-EC	_	600AF 500A	600AF 600A	_	S-N400
250	FR-F740-04810-EC	_	600AF 600A	600AF 600A		S-N600
280	FR-F740-05470-EC	_	600AF 600A	800AF 800A		S-N600
315	FR-F740-06100-EC	_	800AF 700A	800AF 800A		S-N600
355	FR-F740-06830-EC	_	800AF 800A	800AF 800A		S-N600
400	FR-F740-07700-EC	_	1000AF 900A	1000AF 1000A		S-N800
450	FR-F740-08660-EC	_	1000AF 1000A	1000AF 1000A		1000A Rated product
500	FR-F740-09620-EC	_	1200AF 1200A	1200AF 1200A	_	1000A Rated product
560	FR-F740-10940-EC	_	1600AF 1500A	1600AF 1600A	_	1200A Rated product
630	FR-F740-12120-EC	_	2000AF 2000A	2000AF 2000A	_	1400A Rated product

^{*1} Selections for use of the Mitsubishi 4-pole standard motor with power supply voltage of 400VAC 50Hz.



^{*3} Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.

When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.

^{*2} Select the MCCB according to the inverter power supply capacity. Install one MCCB per inverter. For installations in the United States or Canada, use the fuse certified by the UL and cUL. (Refer to page 133.)


^{*4} When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.




2.2 Method of removal and reinstallation of the front cover

•Removal of the operation panel


1) Loosen the two screws on the operation panel. (These screws cannot be removed.)



2) Push the left and right hooks of the operation panel and pull the operation panel toward you to remove.



When reinstalling the operation panel, insert it straight to reinstall securely and tighten the fixed screws of the operation panel.




•Removal 1) Remove installation screws on the front cover 1 to remove the front cover 1. 2) Loosen the installation screws of the front cover 2. screws of the front cover 2. 3) Pull the front cover 2 toward you to remove by pushing an installation hook on the right side using left fixed hooks as supports.


Front cover 2

Reinstallation

- 1) Insert the two fixed hooks on the left side of the front cover 2 into the sockets of the inverter.
- Using the fixed hooks as supports, securely press the front cover 2 against the inverter. (Although installation can be done with the operation panel mounted, make sure that a connector is securely fixed.)



- Fix the front cover 2 with the installation screws.
- 4) Fix the front cover 1 with the installation screws.



REMARKS

For the FR-F740-04320 or more, the front cover 1 is separated into two parts.

CALITION


- . Fully make sure that the front cover has been reinstalled securely. Always tighten the installation screws of the front cover.
- 2. The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Before reinstalling the front cover, check the serial numbers to ensure that the cover removed is reinstalled to the inverter from where it was removed.




2.3 Installation of the inverter and instructions

Installation of the Inverter

Installation on the enclosure 00620 or less




00770 or more




Fix six positions for the FR-F740-04320 to 08660 and fix eight positions for the FR-F740-09620 to 12120.


CAUTION =

- · When encasing multiple inverters, install them in parallel as a cooling measure.
- · Install the inverter vertically.




• Install the inverter under the following conditions.





Clearances (front)




Leave enough clearances and take cooling measures.

*1cm or more for 00083 or less


REMARKS

- For replacing the cooling fan of the 04320 or more, 30cm of space is necessary in front of the inverter.
 Refer to page 112 for fan replacement.
- The inverter consists of precision mechanical and electronic parts. Never install or handle it in any of the following conditions as doing so could cause an operation fault or failure.



2.4 Wiring

2.4.1 Terminal connection diagram



CAUTION

- · To prevent a malfunction due to noise, keep the signal cables more than 10cm away from the power cables.
- After wiring, wire offcuts must not be left in the inverter.
- Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
- When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- Set the voltage/current input switch in right position. Operation with a wrong setting may cause a fault, failure or malfunction.




2.4.2 EMC filter

This inverter is equipped with a built-in EMC filter (capacitive filter) and common mode core.

The EMC filter is effective for reduction of air-propagated noise on the input side of the inverter.


The EMC filter is factory-set to enable (ON). To disable it, fit the EMC filter ON/OFF connector to the OFF position.

The input side common mode core, built-in the FR-F740-01160 or less inverter, is always valid regardless of on/off of the EMC filter on/off connector.



<How to disconnect the connector>

- (1) Before removing a front cover, check to make sure that the indication of the inverter operation panel is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. (For the front cover removal method, refer to page 4.)
- (2) When disconnecting the connector, push the fixing tab and pull the connector straight without pulling the cable or forcibly pulling the connector with the tab fixed. When installing the connector, also engage the fixing tab securely. If it is difficult to disconnect the connector, use a pair of long-nose pliers, etc.



CAUTION

Fit the connector to either ON or OFF.

MARNING


While power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.

2.4.3 Specification of main circuit terminal


Terminal Symbol	Terminal Name	Description		
R/L1, S/L2, T/L3	AC power input	Connect to the commercial power supply. Keep these terminals open when using the high power factor converter (FR-HC, MT-HC) or power regeneration common converter (FR-CV).		
U, V, W	Inverter output	Connect a three-phase squirrel-cage motor.		
R1/L11, S1/L21	Power supply for control circuit	Connected to the AC power supply terminals R/L1 and S/L2. To retain the alarm display and alarm output or when using the high power factor converter (FR-HC, MT-HC) or power regeneration common converter (FR-CV), remove the jumpers from terminals R/L1-R1/L11 and S/L2-S1/L21 and apply external power to these terminals. Do not turn off the power supply for control circuit (R1/L11, S1/L21) with the main circuit power (R/L1, S/L2, T/L3) on. Doing so may damage the inverter. The circuit should be configured so that the main circuit power (R/L1, S/L2, T/L3) is also turned off when the power supply for control circuit (R1/L11, S1/L21) is off. 00380 or less: 60VA, 00470 or more: 80VA		
P/+, N/-	Brake unit connection	Connect the brake unit (FR-BU, BU and MT-BU5), power regeneration common converter (FR-CV), high power factor converter (FR-HC and MT-HC) or power regeneration converter (MT-RC).		
P/+, P1	DC reactor connection	For the 01160 or less, remove the jumper across terminals P/+ - P1 and connect the DC reactor. (Be sure to connect the DC reactor supplied with the 01800 or more.)		
PR, PX	Please do not remove o	or use terminals PR and PX or the jumper connected.		
	Earth	For earthing the inverter chassis. Must be earthed.		


2.4.4 Terminal arrangement of the main circuit terminal, power supply and the motor wiring.


400V class












CAUTION


- The power supply cables must be connected to R/L1, S/L2, T/L3. Never connect the power cable to the U, V, W of the inverter. Doing so will damage the inverter. (Phase sequence needs not to be matched.)
- Connect the motor to U, V, W. At this time, turning on the forward rotation switch (signal) rotates the motor in the counterclockwise direction when viewed from the motor shaft.
- · When wiring the inverter main circuit conductor of the 05470 or more, tighten a nut from the right side of the conductor. When wiring two wires, place wires on both sides of the conductor. (Refer to the drawing below.) For wiring, use bolts (nuts) provided with the inverter.




 Handling of the wiring cover (FR-F740-00470, 00620-EC)
 For the hook of the wiring cover, cut off the necessary parts using a pair of long-nose pliers etc.

CAUTION

Cut off the same number of lugs as wires. If parts where no wire is put through has been cut off (10mm or more), protective structure (JEM1030) becomes an open type (IP00).





(1) Cable sizes etc., of the main control circuit terminals and earth terminals

Select the recommended cable size to ensure that a voltage drop will be 2% max.

If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.

The following table indicates a selection example for the wiring length of 20m.

400V class (when input power supply is 440V based on the rated current for 110% overload for 1 minute)

			Crim	ping				Cable	Sizes						
Applicable Inverter	Terminal	Tightening	(Compression) HIV, etc. (mm2) *1 AWG/I					/ICM *2	PVC,	etc. (mn	m2) *3				
Туре	SCREW SIZE	Torque N·m	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	cable	R/L1, S/L2, T/L3	U, V, W	R/L1, S/L2, T/L3	U, V, W	cable			
FR-F740-00023 to 00083-EC	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5			
FR-F740-00126-EC	M4	1.5	2-4	2-4	2	2	3.5	12	14	2.5	2.5	4			
FR-F740-00170-EC	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	12	12	4	4	4			
FR-F740-00250-EC	M4	1.5	5.5-4	5.5-4	5.5	5.5	8	10	10	6	6	10			
FR-F740-00310-EC	M5	2.5	8-5	8-5	8	8	8	8	8	10	10	10			
FR-F740-00380-EC	M5	2.5	14-5	8-5	14	8	14	6	8	16	10	16			
FR-F740-00470-EC	M6	4.4	14-6	14-6	14	14	14	6	6	16	16	16			
FR-F740-00620-EC	M6	4.4	22-6	22-6	22	22	14	4	4	25	25	16			
FR-F740-00770-EC	M6	4.4	22-6	22-6	22	22	14	4	4	25	25	16			
FR-F740-00930-EC	M8	7.8	38-8	38-8	38	38	22	1	2	50	50	25			
FR-F740-01160-EC	M8	7.8	60-8	60-8	60	60	22	1/0	1/0	50	50	25			
FR-F740-01800-EC	M8	7.8	60-8	60-8	60	60	38	1/0	1/0	50	50	25			
FR-F740-02160-EC	M10	14.7	100-10	100-10	80	80	38	3/0	3/0	70	70	35			
FR-F740-02600-EC	M10	14.7	100-10	150-10	100	125	38	4/0	4/0	95	95	50			
FR-F740-03250-EC	M10	14.7	150-10	150-10	125	125	38	250	250	120	120	70			
FR-F740-03610-EC	M10	14.7	150-10	150-10	150	150	38	300	300	150	150	95			
FR-F740-04320-EC	M12-M10	24.5	100-12	100-12	2×100	2×100	38	2×4/0	2×4/0	2×95	2×95	95			
FR-F740-04810-EC	M12-M10	24.5	100-12	100-12	2×100	2×100	38	2×4/0	2×4/0	2×95	2×95	95			
FR-F740-05470-EC	M12-M10	24.5	150-12	150-12	2×125	2×125	38	2×250	2×250	2×120	2×120	120			
FR-F740-06100-EC	M12-M10	24.5	150-12	150-12	2×150	2×150	38	2×300	2×300	2×150	2×150	150			
FR-F740-06830-EC	M12-M10	24.5	200-12	200-12	2×200	2×200	60	2×350	2×350	2×185	2×185	2×95			
FR-F740-07700-EC	M12-M10	24.5	C2-200	C2-200	2×200	2×200	60	2×400	2×400	2×185	2×185	2×95			
FR-F740-08660-EC	M12-M10	24.5	C2-250	C2-250	2×250	2×250	60	2×500	2×500	2×240	2×240	2×120			
FR-F740-09620-EC	M12-M10	24.5	C2-250	C2-250	2×250	2×250	100	2×500	2×500	2×240	2×240	2×120			
FR-F740-10940-EC	M12-M10	24.5	C2-200	C2-200	3×200	3×200	100	3×350	3×350	3×185	3×185	2×150			
FR-F740-12120-EC	M12-M10	24.5	C2-200	C2-200	3×200	3×200	100	3×400	3×400	3×185	3×185	2×150			
*1 For the 01160 or less			-! !- 4			1.113.7	11 (000)				V '(I				

- *1 For the 01160 or less, the recommended cable size is that of the cable (e.g. HIV cable (600V class 2 vinyl-insulated cable)) with continuous maximum permissible temperature of 75°C. Assumes that the ambient temperature is 50°C or less and the wiring distance is 20m or less. For the 01800 or more, the recommended cable size is that of the cable (e.g. LMFC (heat resistant flexible cross-linked polyethylene insulated cable)) with continuous maximum permissible temperature of 90°C. Assumes that the ambient temperature is 50°C or less and wiring is performed in an enclosure.
- *2 For the 00930 or less, the recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C. Assumes that the ambient temperature is 40°C or less and the wiring distance is 20m or less.
 - For the 01160 or more, the recommended cable size is that of the cable (THHN cable) with continuous maximum permissible temperature of 90°C. Assumes that the ambient temperature is 40°C or less and wiring is performed in an enclosure.

 (Selection example for use mainly in the United States.)
- *3 For the 00930 or less, the recommended cable size is that of the cable (PVC cable) with continuous maximum permissible temperature of 70°C. Assumes that the ambient temperature is 40°C or less and the wiring distance is 20m or less.

 For the 01160 or more, the recommended cable size is that of the cable (XLPE cable) with continuous maximum permissible temperature of 90°C. Assumes that the ambient temperature is 40°C or less and wiring is performed in an enclosure.
- *4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, and a screw for earthing. For the 04320 or more, screw sizes are different. (<R/L1, S/L2, T/L3, U, V, W> <a screw for earthing>)

The line voltage drop can be calculated by the following formula:

line voltage drop [V]= $\frac{\sqrt{3} \times \text{wire resistance}[m\Omega/m] \times \text{wiring distance}[m] \times \text{current}[A]}{1000}$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.

CAUTION

· Tighten the terminal screw to the specified torque.

(Selection example for use mainly in the Europe.)

- A screw that has been tighten too loosely can cause a short circuit or malfunction.
- A screw that has been tighten too tightly can cause a short circuit or malfunction due to the unit breakage.
- · Use crimping terminals with insulation sleeve to wire the power supply and motor.

(2) Notes on earthing

- Leakage currents flow in the inverter. To prevent an electric shock, the inverter and motor must be earthed. This inverter
 must be earthed. Earthing must conform to the requirements of national and local safety regulations and electrical
 codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- Use the dedicated earth terminal to earth the inverter.
 (Do not use the screw in the casing, chassis, etc.)
- Use the thickest possible earth cable. Use the cable whose size is equal to or greater than that indicated in the above table, and minimize the cable length. The earthing point should be as near as possible to the inverter.




<u>To be compliant with the European Directive (Low Voltage Directive), earth the inverter according to</u> the instructions on page 135.

(3) Total wiring length

The overall wiring length for connection of a single motor or multiple motors should be within the value in the table below.

Pr. 72 PWM frequency selection Setting (carrier frequency) *	00023	00038	00052 or More	
2 (2kH) or less	300m	500m	500m	
3 (3kHz), 4 (4kHz)	200m	300m	500m	
5 (5kHz) to 9 (9kHz)		100m		
10 (10kHz) or more	50m			

^{*} For the 01800 or more, the setting range of Pr. 72 PWM frequency selection is "0 to 6".



When driving a 400V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.

Take the following measures in this case.

Connect the surge voltage suppression filter (FR-ASF-H) to the 01160 or less and the sine wave filter (MT-BSL/BSC) to the 01800 or more on the inverter output side

CAUTION

- · Especially for long-distance wiring, the inverter may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function or fast response current limit function or a malfunction or fault of the equipment connected on the inverter output side. If fast-response current limit function malfunctions, disable this function. (For *Pr.156 Stall prevention operation selection, refer to the Instruction Manual (applied).*)
- · For details of *Pr. 72 PWM frequency selection*, *refer to the Instruction Manual (applied)*. (When using an optional sine wave filter (MT-BSL/BSC) for the 01800 or more, set "25" in *Pr.72* (2.5kHz)).
- · For explanation of surge voltage suppression filter (FR-ASF-H) and sine wave filter (MT-BSL/BSC), refer to the manual of each option.

(4) Cable size of the control circuit power supply (terminal R1/L11, S1/L21)


· Terminal Screw Size: M4

· Cable size: 0.75mm² to 2mm²

· Tightening torque: 1.5N·m

(5) When connecting the control circuit and the main circuit separately to the power supply (separate power)


<Connection diagram>



When the protected circuit is activated, opening of the electromagnetic contactor (MC) on the inverter power supply side results in power loss in the control circuit, disabling the alarm output signal retention. Terminals R1/L11 and S1/L21 are provided to hold an alarm signal. In this case, connect the power supply terminals R1/L11 and S1/L21 of the control circuit to the primary side of the MC.


• FR-F740-00023 to 00126

- 1) Loosen the upper screws.
- 2) Remove the lower screws.
- 3) Remove the jumper
- 4) Connect the separate power supply cable for the control circuit to the lower terminals (R1/L11, S1/L21).




• FR-F740-00170, 00250

- 1) Remove the upper screws.
- 2) Remove the lower screws.
- 3) Remove the jumper.
- 4) Connect the separate power supply cable for the control circuit to the <u>upper terminals</u> (R1/L11, S1/L21).



• FR-F740-00310 or more

- 1) Remove the upper screws.
- 2) Remove the lower screws.
- 3) Pull the jumper toward you to remove.
- 4) Connect the separate power supply cable for the control circuit to the <u>upper terminals (R1/L11, S1/L21)</u>. Never connect the power cable to the terminals in the lower stand. Doing so will damage the inverter.



CAUTION =

- · Do not turn off the control power (terminals R1/L11 and S1/L21) with the main circuit power (R/L1, S/L2, T/L3) on. Doing so may damage the inverter.
- Be sure to use the inverter with the jumpers across terminals R/L1-R1/L11 and S/L2-S1/L21 removed when supplying power from other sources. The inverter may be damaged if you do not remove the jumper.
- · The voltage should be the same as that of the main control circuit when the control circuit power is supplied from other than the primary side of the MC.
- The power capacity should be 60VA or more for 00380 or less, 80VA or more for 00470 or more when separate power is supplied from R1/L11, S1/L21.
- When the power supply used with the control circuit is different from the one used with the main circuit, make up a circuit which will switch off the main circuit power supply terminals R/L1, S/L2, T/L3 when the control circuit power supply terminals R1/L11, S1/L21 are switched off
- If the main circuit power is switched off (for 0.1s or more) then on again, the inverter resets and an alarm output will not be held.



2.4.5 Control circuit terminals

indicates that terminal functions can be selected using *Pr. 178 to Pr. 196 (I/O terminal function selection) (Refer to Instruction Manual (applied).*)

(1) Input signals

Type	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to
	STF	Forward rotation start	Turn on the STF signal to start forward rotation and turn it off to stop.	When the STF and STR signals are turned		42
	STR	Reverse rotation start	Turn on the STR signal to start reverse rotation and turn it off to stop.	on simultaneously, the stop command is given.		
	STOP	Start self- holding selection	Turn on the STOP signal to self-hold the sta			Instruction Manual (applied)
	RH, RM, RL	Multi-speed selection	Multi-speed can be selected according to the RM and RL signals.	e combination of RH,		44
	JOG	Jog mode selection	Turn on the JOG signal to select Jog operation turn on the start signal (STF or STR) to start			Instruction Manual (applied)
	RT	Second function selection	Turn on the RT signal to select second funct When the second function such as "second "second V/F (base frequency)" are set, turni selects these functions.	torque boost" and ng on the RT signal	Input resistance 4.7 k Ω	Instruction Manual (applied)
	MRS	Output stop	Turn on the MRS signal (20ms or more) to soutput. Use to shut off the inverter output when stop electromagnetic brake.		Voltage at opening: 21 to 27VDC Contacts at	Instruction Manual (applied)
Contact input	RES	Reset	Used to reset alarm output provided when p activated. Turn on the RES signal for more than 0.1s, i Initial setting is for reset always. By setting P to enabled only at an inverter alarm occurred 1s after reset is cancelled.	short-circuited: 4 to 6mADC	101	
ပိ	AU	Terminal 4 input selection	Terminal 4 is made valid only when the AU sig frequency setting signal can be set between 0 Turning the AU signal on makes terminal 2 (vo	and 20mADC.) oltage input) invalid.		48
	A.G	PTC input	AU terminal is used as PTC input terminal (t the motor). When using it as PTC input term switch to PTC.			Instruction Manual (applied)
	CS	Selection of automatic restart after instantaneous power failure	When the CS signal is left on, the inverter rest power restoration. Note that restart setting is n operation. In the initial setting, a restart is disa (Refer to Pr. 57 Restart coasting time in Instruction)		Instruction Manual (applied)	
	SD	External transistor common, contact input common (sink)	Common terminal for contact input terminal (sink logic). Common output terminal for 24VDC 0.1A power supply (PC erminal). solated from terminals 5 and SE.			_
	PC	24VDC power supply, contact input common (source)	connect the external power supply common for transistor output to this terminal to prevent a malfunction caused by undesirable currents. Can be used as 24VDC 0.1A power supply.		Power supply voltage range 19.2 to 28.8VDC Current consumption 100mA	19

Type	Terminal Symbol	Terminal Name	Description	Rated Specifications	Refer to
	10E	Frequency setting power	When connecting the frequency setting potentiometer at an initial status, connect it to terminal 10. Change the input specifications of terminal 2 when connecting it	10VDC Permissible load current 10mA	Instruction Manual (applied)
	10	supply	to terminal 10E. (Refer to Pr. 73 Analog input selection in Instruction Manual (applied).)	5VDC Permissible load current 10mA	38, 46
ing	2	Frequency setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V, 0 to 20mA) provides the maximum output frequency at 5V (10V, 20mA) and makes input and output proportional. Use <i>Pr. 73</i> to switch from among input 0 to 5VDC (initial setting), 0 to 10VDC, and 0 to 20mA. Set the voltage/current input switch in the ON position to select current input (0 to 20mA).*1	Voltage input: Input resistance 10kΩ ± 1kΩ Maximum permissible	38, 46
Frequency setting	4	Frequency setting (current)	Inputting 4 to 20mADC (or 0 to 5V, 0 to 10V) provides the maximum output frequency at 20mA (5V, 10V) makes input and output proportional. This input signal is valid only when the AU signal is on (terminal 2 input is invalid). Use <i>Pr. 267</i> to switch from among input 4 to 20mA (initial setting), 0 to 5VDC, and 0 to 10VDC. Set the voltage/current input switch in the OFF position to select voltage input (0 to 5V/0 to 10V).·1 (Refer to Instruction Manual (applied).)	voltage 20VDC Current input: Input resistance 245Ω ± 5Ω Maximum permissible current 30mA	40, 48
	1	Frequency setting auxiliary	Inputting 0 to ± 5 VDC or 0 to ± 10 VDC adds this signal to terminal 2 or 4 frequency setting signal. Use $Pr.73$ to switch between the input 0 to ± 5 VDC and 0 to ± 10 VDC (initial setting).	Input resistance $10k\Omega \pm 1k\Omega$ Maximum permissible voltage ± 20 VDC	Instruction Manual (applied)
	5	Frequency setting common	Common terminal for frequency setting signal (terminal 2, 1 or 4) and analog output terminal AM and CA. Do not earth.		_

Set *Pr.73*, *Pr.267*, and a voltage/current input switch correctly, then input analog signals in accordance with the settings. Application of voltage with switch is on (current input specification) or current with switch is off (voltage input specification) could lead to damage to the inverter or analog circuit of external devices.

(2) Output signals

Туре	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to
Relay	A1, B1, C1	Relay output 1 (alarm output)	1 changeover contact output indicates that the inverter protective function has activated and the output stopped. Abnormal: No conduction across B-C (Across A-C Continuity), Normal: Across B-C Continuity (No conduction across A-C)		Contact capacity: 230VAC 0.3A (Power factor=0.4) 30VDC 0.3A	Instruction Manual (applied)
	A2, B2, C2	Relay output 2	1 changeover contact output			Instruction Manual (applied)
	RUN	Inverter running	Switched low when the inverter output frequency is equal to or higher than the starting frequency (initial value 0.5Hz). Switched high during stop or DC injection brake operation. 2			Instruction Manual (applied)
	SU	Up to frequency	Switched low when the output frequency reaches within the range of ±10% (initial value) of the set frequency. Switched high during acceleration/deceleration and at a stop. '2		Permissible load 24VDC 0.1A (A voltage drop is 3.4V maximum when the signal is on.)	Instruction Manual (applied)
Open collector	OL	Overload warning	Switched low when stall prevention is activated by the stall prevention function. Switched high when stall prevention is cancelled. *2	Alarm code (4bit) output		Instruction Manual (applied)
Oper	IPF	Instantaneous power failure	Switched low when an instantaneous power failure and under voltage protections are activated. ²			Instruction Manual (applied)
	FU	Frequency detection	Switched low when the inverter output frequency is equal to or higher than the preset detected frequency and high when less than the preset detected frequency. *2			Instruction Manual (applied)
	SE	Open collector output common	Common terminal for terminals RUN, SU, OL, IPF, FU			_



F	Terminal Symbol	Terminal Name	Description		Rated Specifications	Refer to
Analog	CA	Analog current output			Load impedance 200Ω to 450Ω Output signal 0 to 20mADC	Instruction Manual (applied)
	AM	Analog voltage output			Output signal 0 to 10VDC Permissible load current 1mA (load impedance 10kΩ or more) Resolution 8 bit	Instruction Manual (applied).

² Low indicates that the open collector output transistor is on (conducts). High indicates that the transistor is off (does not conduct).

(3) Communication


Type		erminal Symbol	Terminal Name	Description	
RS-485	_		PU connector	With the PU connector, communication can be made through RS-485. (for connection on a 1:1 basis only) . Conforming standard : EIA-485(RS-485) . Transmission format : Multidrop . Communication speed : 4800 to 38400bps . Overall length : 500m	22
	SG SG EXD+ RXD- RXD- TXD- TXD- TXD-	Inverter			
		TXD-	transmission terminal	With the RS-485 terminals, communication can be made through RS-485. Conforming standard : EIA-485(RS-485)	
		RXD+	Inverter reception terminal	Transmission format : Multidrop link Communication speed : 300 to 38400bps Overall length : 500m	23
		RXD-			
		SG	Earth		

2.4.6 Changing the control logic

The input signals are set to source logic (SOURCE) when shipped from the factory.

To change the control logic, the jumper connector on the control circuit terminal block must be moved to the other position.

(The output signals may be used in either the sink or source logic independently of the jumper connector position.)



CAUTION =


Turn off the inverter power before switching a jumper connector.

^{*3} Not output during inverter reset.

Sink logic and source logic

- · In sink logic, a signal switches on when a current flows from the corresponding signal input terminal.


 Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
- In source logic, a signal switches on when a current flows into the corresponding signal input terminal.
 Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.
 - Current flow concerning the input/output signal when sink logic is selected
- Current flow concerning the input/output signal when source logic is selected



• When using an external power supply for transistor output


Sink logic type

Use terminal PC as a common terminal to prevent a malfunction caused by undesirable current. (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install a power supply in parallel in the outside of the inverter. Doing so may cause a malfunction due to undesirable current.)



Source logic type


When using an external power supply for transistor output, use terminal SD as a common to prevent misoperation caused by undesirable current.





2.4.7 Wiring of control circuit

(1) Control circuit terminal layout



(2) Wiring method

Loosen the terminal screw and insert the cable into the terminal.

Screw Size: M3 Tightening Torque: 0.5N·m to 0.6N·m

Cable stripping size

(3) Wiring instructions

- 1) Terminals 5, PC and SE are common to the I/O signals and isolated from each other. Do not earth. Avoid connecting the terminal PC and 5 and the terminal SE and 5.
- 2) Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).
- Use two or more parallel micro-signal contacts or twin contacts to prevent a contact faults when using contact inputs since the control circuit input signals are micro-currents.






Micro signal contacts


Twin contacts

- 4) Do not apply a voltage to the contact input terminals (e.g. STF) of the control circuit.
- 5) Always apply a voltage to the alarm output terminals (A, B, C) via a relay coil, lamp, etc.
- 6) It is recommended to use the cables of 0.75mm² gauge for connection to the control circuit terminals.
 If the cable gauge used is 1.25mm² or more, the front cover may be lifted when there are many cables running or the cables are run improperly, resulting in an operation panel contact fault.
- 7) The wiring length should be 30m maximum.

• Wiring of the control circuit of the 01800 or more

For wiring of the control circuit of the 01800 or more, separate away from wiring of the main circuit. Make cuts in rubber bush of the inverter side and lead wires.








2.4.8 When connecting the operation panel using a connection cable

When connecting the operation panel (FR-DU07) to the inverter using a cable, the operation panel can be mounted on the enclosure surface and operationality improves.



CAUTION =


Do not connect the PU connector to the computer's LAN port, FAX modem socket or telephone connector. The inverter and machine could be damaged due to differences in electrical specifications.

REMARKS

- · Refer to page 4 for removal method of the operation panel.
- · When using a commercially available connector and cable as a parameter unit connection cable, refer to Instruction Manual (applied).
- $\cdot\;$ The inverter can be connected to the computer and FR-PU04/FR-PU07.

2.4.9 RS-485 terminal block

- · Conforming standard: EIA-485(RS-485)
- · Transmission format: Multidrop link
- · Communication speed: MAX 38400bps
- · Overall length: 500m
- Connection cable:Twisted pair cable (4 paires)




2.4.10 Communication operation

Using the PU connector or RS-485 terminal, you can perform communication operation from a personal computer etc. When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters. For the Mitsubishi inverter protocol (computer link

For the Mitsubishi inverter protocol (computer link operation), communication can be performed with the PU connector and RS-485 terminal.

For the Modbus RTU protocol, communication can be performed with the RS-485 terminal.

For further details, refer to Instruction Manual (applied).



2.5 Power-off and magnetic contactor (MC)

(1) Inverter input side magnetic contactor (MC)

On the inverter input side, it is recommended to provide an MC for the following purposes.


(Refer to page 3 for selection.)

- 1) To release the inverter from the power supply when the inverter's protective function is activated or when the drive is not functioning (e.g. emergency stop operation).
- 2) To prevent any accident due to an automatic restart at restoration of power after an inverter stop made by a power failure
- 3) The control power supply for inverter is always running and consumes a little power. When stopping the inverter for an extended period of time, powering off the inverter will save power slightly.
- 4) To separate the inverter from the power supply to ensure safe maintenance and inspection work

 The inverter's input side MC is used for the above purpose, select class JEM1038-AC3MC for the inverter input side current when making an emergency stop during normal operation.

REMARKS

Since repeated inrush current at powering on will shorten the life of the converter part (switching life is 100 million times), frequent on/off must be avoided. Turn on/off the inverter start controlling terminals (STF, STR) to run/stop the inverter.



Inverter start/stop circuit example

As shown on the left, always use the start signal To the (ON or OFF across terminals STF or STR-PC) to motor make a start or stop.

- *1 When the power supply is 400V class, install a step-down transformer.
- *2 Connect the power supply terminals R1/L11, S1/L21 of the control circuit to the primary side of the MC to hold an alarm signal when the inverter's protective circuit is activated. At this time, remove jumpers across terminals R/L1-R1/L11 and S/L2-S1/L21. (Refer to page 14 for removal of the jumper.)

(2) Handling of the inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned on while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided to switch to a commercial power supply, for example, it is recommended to use electronic bypass function *Pr. 135 to Pr. 139* (Instruction Manual (applied)).

2.6 Precautions for use of the inverter

The FR-F700 series is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following items.


- (1) Use crimping terminals with insulation sleeve to wire the power supply and motor.
- (2) Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.
- (3) After wiring, wire offcuts must not be left in the inverter.

 Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- (4) Use cables of the size to make a voltage drop 2% maximum. If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency. Refer to page 12 for the recommended cable sizes.
- (5) The overall wiring length should be 500m maximum.

 Especially for long distance wiring, the fast-response current limit function may decrease or the equipment connected to the secondary side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. (Refer to page 13.)
- (6) Electromagnetic wave interference
 The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, set the EMC filter valid to minimize interference. (Refer to page 8)
- (7) Do not install a power factor correction capacitor, surge suppressor or radio noise filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices is installed, immediately remove it.
- (8) Before starting wiring or other work after the inverter is operated, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- (9) A short circuit or earth fault on the inverter output side may damage the inverter modules.
 - Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by peripheral circuit inadequacy or an earth fault caused by wiring inadequacy or reduced motor insulation resistance may damage the inverter modules.
 - Fully check the to-earth insulation and inter-phase insulation of the inverter output side before power-on. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.
- (10) Do not use the inverter input side magnetic contactor to start/stop the inverter.

 Always use the start signal (ON/OFF of STF and STR signals) to start/stop the inverter. (Refer to page 7)
- (11) Do not apply a voltage higher than the permissible voltage to the inverter I/O signal circuits.

 Contact to the inverter I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10E-5.
- (12) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for bypass operation. When the wiring is incorrect or if there is an electronic bypass circuit as shown on the right, the inverter will be damaged by leakage current from the power supply due to arcs generated at the time of switch-over or chattering caused by a sequence error.






- (13) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's input side and also make up a sequence which will not switch on the start signal.
 If the start signal (start switch) remains on after a power failure, the inverter will automatically restart as soon as the power is restored.
- (14) Instructions for overload operation
 When performing an operation of frequent start/stop of the inverter, increase/decrease in the temperature of the transistor element of the inverter may repeat due to a continuous flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing bound current, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, increase the inverter capacity to have enough allowance for current.
- (15) Make sure that the specifications and rating match the system requirements.

3 DRIVE THE MOTOR

3.1 Step of operation

The inverter needs frequency command and start command. Turning the start command on start the motor rotating and the motor speed is determined by the frequency command (set frequency).

Refer to the flow chart below to perform setting.



= CAUTION

Check the following items before powering on the inverter.

- · Check that the inverter is installed correctly in a correct place. (Refer to page 6)
- · Check that wiring is correct. (Refer to page 7)
- · Check that no load is connected to the motor.




- ·When protecting the motor from overheat by the inverter, set Pr.9 Electronic thermal O/L relay (Refer to page 33)
- ·When the rated frequency of the motor is 60Hz, set Pr.3 Base frequency (Refer to page 53)




3.2 Operation panel (FR-DU07)

3.2.1 Parts of the operation panel (FR-DU07)



3.2.2 Basic operation (factory setting)



1

3.2.3 Operation lock (Press [MODE] for an extended time (2s))

Operation using the setting dial and key of the operation panel can be made invalid to prevent parameter change and unexpected start and stop.


- · Set "10 or 11" in Pr. 161, then press (MODE) for 2s to make the setting dial and key operation invalid.
- When the setting dial and key operation is made invalid, Hall appears on the operation panel.

 When the setting dial and key operation is invalid, Hall appears if the setting dial or key operation is performed. (When the setting dial or key operation is not performed for 2s, the monitor display appears.)
- To make the setting dial and key operation valid again, press (MODE) for 2s.

POINT

Set "0" (extended mode parameter valid) in Pr.160 User group read selection.

Set "10 or 11" (key lock mode valid) in Pr.161 Frequency setting/key lock operation selection.




Release the operation lock to release the PU stop by key operation.

3.2.4 Monitoring of output current and output voltage

POINT

Monitor display of output frequency, output current and output voltage can be changed by pushing (SET) during monitoring mode.



3.2.5 First priority monitor

Hold down (SET) for 1s to set monitor description to be appeared first in the monitor mode.

(To return to the output frequency monitor, hold down (SET) for 1s after displaying the output frequency monitor.)

3.2.6 Setting dial push

Push the setting dial () to display the set frequency currently set.



3.2.7 Change the parameter setting value

Changing example Change the Pr. 1 Maximum frequency.

Operation Display 1. Screen at powering on The monitor display appears. PU indication is lit 2. Press $\frac{PU}{EXT}$ to choose the PU operation mode. The parameter 3. Press (MODE) to choose the parameter number read setting mode. previously appears. 4. Turn () until P (Pr. 1) appears. **5.**Press (SET) to read the currently set value. " " (initial value) appears. 6. Turn () to change it to the set value of "S∏∏∏" 7.Press (SET) to set

- Flicker ··· Parameter setting complete!!
-), you can read another parameter. · By turning (
- · Press (SET) to show the setting again.
- · Press (SET) twice to show the next parameter.
- · Press (MODE) twice to return the monitor to frequency monitor.

? Er I to Er Y are displayed ... Why?

appears. Write disable error

appears. Write error during operation

appears. Calibration error

appears. Mode designation error

For details refer to page 91.

REMARKS

The number of digits displayed on the operation panel (FR-DU07) is four. Only the upper four digits of values can be displayed and set. If the values to be displayed have five digits or more including decimal places, the fifth or later numerals can not be displayed nor set.

(Example) When Pr.1

When 60Hz is set, 60.00 is displayed.

When 120Hz is set, 120.0 is displayed. The second decimal places can not be displayed nor set.


3.3 Overheat protection of the motor by the inverter (Pr. 9)

Set the rated motor current in Pr. 9 Electronic thermal O/L relay to protect the motor from overheat.

Parameter Number	Name	Initial Value	Setting Range *2		Description
٥	Electronic thermal O/L relay	Inverter rated	01160 or less	0 to 500A	Set the rated motor current.
9	Liectionic thermal O/L relay	current *1	01800 or more	0 to 3600A	Set the fated motor current.

¹ Refer to page 116 for the rated inverter current value.

Changing example Change the *Pr. 9 Electronic thermal O/L relay* setting to 2.0A according to the motor rated current. (FR-F740-00023)



CAUTION

- · Protective function by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-off.
- · When two or more motors are connected to the inverter, they cannot be protected by the electronic thermal relay function. Install an external thermal relay to each motor.
- · When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- · A special motor cannot be protected by the electronic thermal relay function. Use an external thermal relay.
- · PTC thermistor output built-in the motor can be input to the PTC signal (AU terminal). For details, refer to Instruction Manual (applied).

^{*2} The minimum setting increments are 0.01A for the 01160 or less and 0.1A for the 01800 or more.



3.4 Start/stop from the operation panel (PU operation mode)


[Connection diagram] Inverter **POINT** Three-phase R/L1 From where is the frequency command given? Motor AC power supply Operation at the frequency set in the frequency setting mode of the operation panel \rightarrow Refer to 3.4.1 (Refer to page 34) Operation using the setting dial as the volume FR-DU07 →Refer to 3.4.2 (Refer to page 35) Change of frequency with ON/OFF switches connected to **terminals** \rightarrow Refer to 3.4.3 (Refer to page 36) Frequency setting with a voltage output device \rightarrow Refer to 3.4.4 (Refer to page 38) Frequency setting with a current output device \rightarrow Refer to 3.4.5 (Refer to page 40) 3.4.1 Set the set frequency to operate (example: performing operation at 30Hz) Operation -Display 1. Screen at powering on The monitor display appears. PU indication is lit. 2. Press $\frac{PU}{EXT}$ to choose the PU operation mode. 3.Turn to show the frequency

The frequency flickers for about 5s. 4. While the value is flickering, press (SET) to set the frequency. Flicker ··· Frequency setting complete!! If you do not press (SET), the value flickers for about 5s and the display then returns to 0.00 (display) Hz. At this time, return to "Step 3" and set the frequency again. 5. After the value flickered for about 3s, the display returns to "[[[[[] " (monitor display) Press (FWD) (or (REV)) to start operation.

6.To change the set frequency, perform the operation in above steps 3 and 4. (Starts from the previously set frequency.)

7. Press (STOP) to stop.

you want to set.



Flickers for about 5s

? Operation cannot be performed at the set frequency ... Why?

Did you carry out step 4 within 5s after step 3? (Did you press (set) within 5s after turning ??)

? The frequency does not change by turning 🕥 ... Why?

Check to see if the operation mode selected is the external operation mode. (Press (PU) to change to the PU operation mode.)

? Operation does not change to the PU operation mode ... Why?

© Check that "0" (initial value) is set in Pr. 79 Operation mode selection.

P Check that the start command is not on.

Change acceleration time Pr. 7 (Refer to page 54)

Change deceleration time Pr. 8 (Refer to page 54)

 \P For example, limit the motor speed to 50Hz maximum. PSE Set "50Hz" in $Pr.\ 1.$ (Refer to page 52)

REMARKS

to show the set frequency. Press



can also be used like a potentiometer to perform operation. (Refer to page 35)


3.4.2 Use the setting dial like a potentiometer to perform operation.

POINT

Set "0" (extended mode parameter valid) in Pr. 160 User group read selection.

Set "1" (setting dial potentiometer mode) in Pr. 161 Frequency setting/key lock operation selection.

Operation example Change the frequency from 0Hz to 50Hz during operation



REMARKS

If flickering "50.00" turns to "0.0", the Pr. 161 Frequency setting/key lock operation selection setting may not be "1".

· Independently of whether the inverter is running or at a stop, the frequency can be set by merely turning






Use switches to give a start command and a frequency setting (multi-speed 3.4.3 setting)


POINT

- · Use (FWD)/(REV) to give a start command.
- Pr. 79 Operation mode selection must be set to "4" (external/PU combined operation mode 2) The initial values of the terminals RH, RM, RL are 50Hz, 30Hz, and 10Hz. (Refer to page 44 to change frequencies using Pr. 4, Pr. 5 and Pr. 6.)
- Operation at 7-speed can be performed by turning on two (or three) terminals simultaneously.

(Refer to Instruction Manual (applied).)

[Connection diagram]





The parameter number

read previously appears.

Operation

1. Screen at powering on The monitor display appears.

- 2. Press (MODE) to choose the parameter setting mode.
- until **P 79** (*Pr. 79*) appears.
- **4.** Press(SET) to read the currently set value. "[]"(initial value) appears.
-) to change it to the setting value " 4".
- 6. Press (SET) to set.
- 7. Mode/monitor check Press (MODE) twice to choose the monitor/frequency monitor.
- 8. Press the start switch (FWD) (or (REV)) FWD (or REV) flickers. When the frequency command is not given, it flickers.
















Flicker ··· Parameter setting complete!!





Flickering



- ? 50Hz for the RH, 30Hz for the RM and 10Hz for the RL are not output when they are turned on ... Why?
 - Check for the setting of Pr. 4, Pr. 5, and Pr. 6 once again.
 - © Check for the setting of Pr. 1 Maximum frequency and Pr. 2 Minimum frequency once again. (Refer to page 52.)
 - © Check that Pr. 180 RL terminal function selection = "0", Pr. 181 RM terminal function selection = "1", Pr. 182 RH terminal function selection = "2", and Pr. 59 Remote function selection = "0". (all are initial values)
- ? [FWD (or REV)] lamp is not lit ... Why?
 - Check that wiring is correct. Check the wiring once again.
 - Check for the *Pr.* 79 setting once again. (*Pr.* 79 must be set to "4".) (*Refer to page 57.*)
- $oldsymbol{?}$ Change the frequency of the terminal RL, RM, and RH. ... How?
 - Refer to page 44 to change the running frequency at each terminal in Pr. 4 Multi-speed setting (high speed), Pr. 5 Multi-speed setting (middle speed), and Pr. 6 Multi-speed setting (low speed).




3.4.4 Perform frequency setting by analog (voltage input)

POINT

- · Use (FWD)/(REV) to give a start command.
- · Pr. 79 Operation mode selection must be set to "4" (external/PU combined operation mode 2)


[Connection diagram]


(The inverter supplies 5V of power to the frequency setting potentiometer.(Terminal 10))



Operation

1. Screen at powering on The monitor display appears.





- 4. Press (SET) to read the currently set value.
 "[]"(initial value) appears.
- 5. Turn to change it to the setting value " 4".
- 6. Press (SET) to set.
- 7. Mode/monitor check
 Press (MODE) twice to choose the monitor/frequency monitor.
- 8. Start

Press the start switch (FWD) (or (REV)).

Operation status indication of FWD (or REV)

flickers

CAUTION

When both the forward switch and reverse switch turn on, the inverter will not start. Also, if both switch turn on while running, the inverter stops.

9. Acceleration → constant speed
Turn the volume (frequency setting
potentiometer) clockwise slowly to full.
The frequency value on the indication
increases according to *Pr. 7 Acceleration*time until "5\[COM\]"(50Hz) is displayed.

Display

The parameter number











Flicker ··· Parameter setting complete!!





SOOO HZ MON PU EXT



Operation


Display ·

10. Deceleration

Turn the volume (frequency setting potentiometer) counterclockwise slowly to full.

The frequency value on the indication decreases according to Pr. 8 Deceleration time unitl " [] [] " (0.00Hz) is displayed and operation status indication of FWD or REV flickers.

The motor stops.



11. Stop

Press STOP

Operation status indication of FWD (or REV)



- ? Change the frequency (50Hz) of the maximum value of potentiometer (at 5V)

 Adjust the frequency in Pr. 125 Terminal 2 frequency setting gain frequency. (Refer to page 47.)
- ? Change the frequency (0Hz) of the minimum value of potentiometer (at 0V)
 - P Adjust the frequency in calibration parameter C2 Terminal 2 frequency setting bias frequency. (Refer to Instruction Manual (applied).)




3.4.5 Perform frequency setting by analog (current input)

POINT

- · Use (FWD)I(REV) to give a start command.
- Turn the AU signal on.
- · Pr. 79 Operation mode selection must be set to "4" (external/PU combined operation mode 2)

[Connection diagram]



Operation

· Display ·

- Screen at powering on The monitor display appears.
- 2. Press (MODE) to choose the parameter setting mode.





The parameter number read previously appears.

3. Turn until *P.* 79 (*Pr. 79*) appears.





4. Press (SET) to read the currently set value. "[]" (initial value) appears.





5. Turn to change it to the setting value " 4".





6. Press (SET) to set.

- SET
- 4 P. 79

Flicker ··· Parameter setting complete!!

7. Mode/monitor check

Press (MODE) twice to choose the monitor/frequency monitor.

MOD



8. Start

Check that the terminal 4 input selection signal (ALI) is on

Press the start switch (FWD) (or (REV)).

FWD or REV of operation status indication flickers.

((REV)



Flickering

= CAUTION =

When both the forward switch and reverse switch turn on, the inverter will not start. Also, if both switch turn on while running, the inverter stops.

Display

- Operation

9. Acceleration → constant speed Perform 20mA input.

The frequency value on the indication increases according to *Pr. 7 Acceleration time* until " **5000**" (50.00Hz) is displayed.

10. Deceleration

Perform 4mA input.

The frequency value on the indication decreases according to *Pr. 8 Deceleration time* until " (0.00Hz) is displayed and the operation status indication of FWD or REV flickers.

The motor stops.

11. Stop

Press (STOP RESET)

FWD or REV of the operation status indication turns off







Flickering



REMARKS

Pr. 184 AU terminal function selection must be set to "4" (AU signal) (initial value). (Refer to Instruction Manual (applied).)

? Change the frequency (50Hz) at the maximum current input (at 20mA, initial value)

Adjust the frequency in Pr. 126 Terminal 4 frequency setting gain frequency. (Refer to page 49.)

? Change the frequency (0Hz) at the minimum current input (at 4mA, initial value)

Adjust the frequency in calibration parameter C5 Terminal 4 frequency setting bias frequency. (Refer to Instruction Manual (applied).)



3.5 Make a start and stop with terminals (external operation)

POINT

From where is the frequency command given?


- Operation at the frequency set in the frequency setting mode of the operation panel \rightarrow Refer to 3.5.1(Refer to page 42)
- Give a frequency command by switch (multi-speed setting) \rightarrow Refer to 3.5.2 (Refer to page 44)
- Perform frequency setting by a voltage output device \rightarrow Refer to 3.5.3 (Refer to page 46)
- Perform frequency setting by a current output device \rightarrow Refer to 3.5.5 (Refer to page 48)

3.5.1 Use the set frequency set by the operation panel (Pr. 79 = 3)

POINT

- Switch terminal STF(STR)-PC on to give a start command.
- Set "3" in Pr. 79 (External/PU combined operation mode 1).
- Refer to page 34 for the set frequency by the operation panel.

[Connection diagram]





- Screen at powering on The monitor display appears.
- 2.Press (MODE) to choose the parameter setting mode.
- 3. Turn until *P.* 79 (*Pr. 79*) appears.
- 4.Press (SET) to read the currently set value.
 "[]" (initial value) appears.
- 5.Turn to change it to the setting value " -7".
- 6.Press (SET) to set.
- 7. Turn the start switch (STF or STR) on.The motor runs at the frequency
 - The motor runs at the frequency set in the set frequency mode of the operation panel.
- 8. Turn to change running frequency.

 Display the frequency you want to set.

 The frequency flickers for about 5s.















Flicker ··· Parameter setting complete!!







Flickers for about 5s 🦔

Operation


Display ·

9. While the value is flickering, press (SET) to set the frequency.

> If you do not press (SET), the value flickers for about 5s and the display then returns to 0.00 (display) Hz. At this time, return to "Step 3" and set the frequency again.

Flicker ··· Frequency setting complete!!

10. Turn the start switch (STF or STR) off. The motor decelerates according to Pr. 8 Deceleration time to stop.





REMARKS

- Pr. 178 STF terminal function selection must be set to "60" (or Pr. 179 STR terminal function selection must be set to "61"). (all are initial values)
- When Pr. 79 Operation mode selection is set to "3", multi-speed operation (refer to page 44) is also made valid.

? When the inverter is stopped by



of the operation panel (FR-DU07), P5





are

displayed alternately.

- 1. Turn the start switch (STF or STR) off.
 - 2. The display can be reset by $\binom{PU}{EXT}$.




3.5.2 Use switches to give a start command and a frequency setting (multi-speed setting) (Pr. 4 to Pr. 6)


POINT

- · Start command by terminal STF (STR)-PC
- · Frequency command by terminal RH, RM, RL and STR-PC
- · [EXT] must be lit. (When [PU] is lit, switch it to [EXT] with $\frac{PU}{EXT}$.)
- · The initial values of the terminals RH, RM, RL are 50Hz, 30Hz, and 10Hz. (Use Pr. 4, Pr. 5 and Pr. 6 to change.)
- · Operation at 7-speed can be performed by turning two (or three) terminals simultaneously. (Refer to Instruction Manual (applied).)

[Connection diagram]



Changing example Set "40Hz" in *Pr. 4 Multi-speed setting (high speed)* and turn on terminal RH and STF (STR)-SD to operate.




Operation -

- Display -


7. Mode/monitor check
Press work twice to choose the monitor/frequency monitor.



8. Turn on the high speed switch (RH).



- 9. Turn the start switch (STF or STR) on. "4000" (40Hz) appears.
 - 30Hz appears when RM is on and 10Hz appears when RL is on.





Turn the start switch (STF or STR) off. The motor stops according to *Pr. 8*Deceleration time.





- ? [EXT] is not lit even when $\frac{PU}{EXT}$ is pressed ... Why?
 - Switchover of the operation mode with $\frac{PU}{EXT}$ is valid when Pr. 79 = "0" (initial value).
- ? 50Hz, 30Hz and 10Hz are not output from RH, RM and RL respectively when they are turned on. ... Why?
 - Check for the setting of Pr. 4, Pr. 5, and Pr. 6 once again.
 - © Check for the setting of Pr. 1 Maximum frequency and Pr. 2 Minimum frequency once again. (Refer to page 52)
 - © Check for the Pr. 79 setting once again. (Pr. 79 must be set to "0" or "2".) (Refer to page 57)
 - © Check that Pr. 180 RL terminal function selection = "0", Pr. 181 RM terminal function selection = "1", Pr. 182 RH terminal function selection = "2" and Pr. 59 Remote function selection = "0". (all are initial values)
- ? [FWD (or REV)] is not lit. ... Why?
 - Check that wiring is correct. Check it again.
 - © Check that "60" is set in *Pr. 178 STF terminal function selection* (or "61" is set in *Pr. 179 STR terminal function selection*)? (all are initial values)
- ? How is the frequency setting from 4 to 7 speed?
 - The setting differs according to Pr. 24 to Pr. 27 (multi-speed setting). Refer to Instruction Manual (applied).
- ? Perform multi-speed operation higher than 8 speed. ... How?
 - Use the REX signal to perform the operation. Refer to Instruction Manual (applied).

REMARKS


External operation is fixed by setting "2" (external operation mode) in Pr. 79 Operation mode selection when you do not want to take time pressing $\frac{PU}{EXT}$ or when you want to use the current start command and frequency command. (Refer to page 57)



3.5.3 Perform frequency setting by analog (voltage input)

[Connection diagram]

(The inverter supplies 5V of power to frequency setting potentiometer. (Terminal 10))



Operation

Display -

- 1. Power on → operation mode check For the initial setting, the inverter operates in the external operation mode [EXT] when powering on. Check that the operation command indication is [EXT]. If not displayed, press $\frac{PU}{EXT}$ to change to the external [EXT] operation mode. If the operation mode still does not change, set Pr. 79 to change to the external operation mode. (Refer to page 57.)
- 2.Start

Turn the start switch (STF or STR) on. Operation status indication of FWD (or REV) flickers.

= CAUTION =

When both the forward switch and reverse switch are on, the inverter will not start. Also, if both switches turn on while running. the inverter decelerates to stop.


3.Acceleration \rightarrow constant speed Turn the volume (frequency setting potentiometer) clockwise slowly to full. The frequency value on the indication increases according to Pr. 7 Acceleration time until " \(\int \mathbb{\beta} \mathbb{\beta} \mathbb{\beta} \) (50Hz) is displayed.

4. Deceleration

Turn the volume (frequency setting potentiometer) counterclockwise slowly to full. The frequency value of the indication decreases according to Pr. 8 Deceleration time until "[[[[]]]" (0.00Hz) is displayed. The motor stops.

5.Stop

Turn the start switch (STF or STR) off.













Flickering



When you want to operate in the external operation mode always at powering on or when you want to save the trouble of $\frac{PU}{EXT}$ input, set "2" (external operation mode) in Pr. 79 Operation mode selection to choose external operation mode always.

REMARKS

Pr. 178 STF terminal function selection must be set to "60" (or Pr. 179 STR terminal function selection must be set to "61"). (all are initial values)

- ? The motor will not rotate ... Why?

 Check that [EXT] is lit.

 [EXT] is valid when Pr. 79 = "0" (initial value).

 Use $\frac{PU}{EXT}$ to lit [EXT].
 - P Check that wiring is correct. Check once again.
- ? Change the frequency (0Hz) of the minimum value of potentiometer (at 0V)

PAdjust the frequency in calibration parameter C2 Terminal 2 frequency setting bias frequency. (Refer to

Instruction Manual (applied).)


When you want to compensate frequency setting, use terminal 1. For details, refer to Instruction Manual (applied).

3.5.4 Change the frequency (50Hz) of the maximum value of potentiometer (at 5V)

<How to change the maximum frequency?>

Changing example

When you want to use the 0 to 5VDC input frequency setting potentiometer to change the 5V-time frequency from 50Hz (initial value) to 40Hz Adjust to output 40Hz at 5V voltage input. Set "40Hz" in *Pr. 125*.





Flicker ··· 40Hz output at 5V input complete!!

5.Mode/monitor check


calibration parameter C0.

Press (MODE) twice to choose the monitor/frequency monitor.





(Refer to Instruction Manual (applied).)



REMARKS

As other adjustment methods of frequency setting voltage gain, there are methods to adjust with a voltage applied to across terminals 2-5 and adjust at any point without a voltage applied.

(Refer to Instruction Manual (applied) for the setting method of calibration parameter C4.)




3.5.5 Perform frequency setting by analog (current input)

POINT

- · Switch terminal STF(STR)-PC on to give a start command.
- · Turn the AU signal on.
- · Set "2" (external operation mode) in Pr. 79 Operation mode selection

[Connection diagram]



Operation

1.Power on \rightarrow operation mode check For the initial setting, the inverter operates in the external operation mode [EXT] when powering on. Check that the operation command indication is [EXT]. If not displayed, press $\stackrel{\text{Pl}}{\text{EXT}}$ to change to the external [EXT] operation mode. If the operation mode still does not change, set Pr. 79 to change to the external operation mode. (Refer to page 57.)

2.Start

Turn the start switch (STF or STR) on. FWD or REV of operation indication flickers.

= CAUTION

When both the forward switch and reverse switch are on, the inverter will not start. Also, if both switches turn on while running, the inverter decelerates to stop.

- 3. Acceleration → constant speed Perform 20mA input. The frequency value on the indication increases according to Pr. 7 Acceleration time until "5000" (50.00Hz) is displayed.
- 4. Deceleration

Perform 4mA input.
The frequency value on the indication decreases according to *Pr. 8*Deceleration time until "QQQ" (0.00Hz) is displayed and FWD or REV of the operation

status indication flickers.

The motor stops.


5.Stop

Turn the start switch (STF or STR) off.











REMARKS

Pr. 184 AU terminal function selection must be set to "4" (AU signal) (initial value). (Refer to 🛄 Instruction Manual (applied).)

- ? The motor will not rotate ... Why?
 - Check that [EXT] is lit. [EXT] is valid when Pr: 79 = "0" (initial value).
 - Use $\stackrel{\text{PU}}{\underset{\text{EXT}}{\text{EXT}}}$ to lit [EXT].
 - Check that the AU signal is on. Turn the AU signal on.
 - P Check that wiring is orrect. Check it again.
- ? Change the frequency (0Hz) of the minimum value of potentiometer (at 4mA)
 - Adjust the frequency in *calibration parameter C5 Terminal 4 frequency setting bias frequency*.


(Refer to Instruction Manual (applied).)

3.5.6 Change the frequency (50Hz) of the maximum value of potentiometer (at 20mA)

<How to change the maximum frequency?>

Changing example


When you want to use the 4 to 20mA input frequency setting potentiometer to change the 20mA-time frequency from 50Hz (initial value) to 40Hz Adjust to output 40Hz at 20mA current input. Set "40Hz" in $Pr.\ 126$.



- 5. Mode/monitor check

 Press word twice to choose the monitor/frequency monitor.
- 6.Turn the start switch (STF or STR) on to allow 20mA current to flow. (Refer to 3.5.5 steps 2 to 5)
- **?** Set frequency at 4mA using *calibration* parameter C5 and adjust the indicator using *calibration* parameter C0.

(Refer to Instruction Manual (applied).)



REMARKS

As other adjustment methods of frequency setting voltage gain, there are methods to adjust with a voltage applied to across terminals 4-5 and adjust at any point without a voltage applied.

(Refer to Instruction Manual (applied) for the setting method of calibration parameter C7.)

4 ADJUSTMENT

4.1 Simple mode parameter list

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel (FR-DU07). For details of parameters, refer to Instruction Manual (applied).

POINT

Only simple mode parameters are displayed by the initial setting of *Pr. 160 User group read selection*. Set *Pr. 160 User group read selection* as required. (*Refer to page 63*.)

Pr. 160	Description
9999 (Initial Value)	Only the simple mode parameters can be displayed.
0	Simple mode and extended mode parameters can be displayed.
1	Only the parameters registered in the user group can be displayed.

Parameter Number	Name	Incre ments	Initial Value	Range	Applications	Refer to
0	Torque boost	0.1%	6/4/3/2/ 1.5/1% *1	0 to 30%	Set to increase a starting torque or when the motor with a load will not rotate, resulting in an alarm [OL] and a trip [OC1] *1 Initial values differ according to the inverter capacity. (00023 / 00038 to 00083 / 00126,00170 / 00250 to 00770 / 00930, 01160 /01800 or more)	51
1	Maximum frequency	0.01Hz	120/ 60Hz*2	0 to 120Hz	Set when the maximum output frequency need to be limited. *2 Initial values differ according to the inverter capacity. (01160 or less/01800 or more)	52
2	Minimum frequency	0.01Hz	0Hz	0 to 120Hz	Set when the minimum output frequency need to be limited.	
3	Base frequency	0.01Hz	50Hz	0 to 400Hz	Check the motor rating plate.	53
4	Multi-speed setting (high speed)	0.01Hz	50Hz	0 to 400Hz		
5	Multi-speed setting (middle speed)	0.01Hz	30Hz	0 to 400Hz	Set when changing the preset speed in the parameter with a terminal.	44
6	Multi-speed setting (low speed)	0.01Hz	10Hz	0 to 400Hz		
7	Acceleration time	0.1s	5/15s*3	0 to 3600s	Acceleration/deceleration time can be set.	
8	Deceleration time	0.1s	10/30s*3	0 to 3600s	*3 Initial values differ according to the inverter capacity. (00170 or less/00250 or more)	54
9	Electronic thermal O/L relay	0.01/ 0.1A*4	Inverter rated current	0 to 500/ 0 to 3600A*4	Protect the motor from overheat by the inverter. Set the rated motor current. *4 Setting increments and setting range differ according to the inverter capacity. (01160 or less/01800 or more)	
60	Energy saving control selection	1	0	0, 4, 9	The inverter output voltage is minimized when using for fan and pump applications.	55
79	Operation mode selection	1	0	0, 1, 2, 3, 4, 6, 7	Select the start command location and frequency setting location.	57
125	Terminal 2 frequency setting gain frequency	0.01Hz	50Hz	0 to 400Hz	Frequency for the maximum value of the potentiometer (at 5V) can be changed.	
126	Terminal 4 frequency setting gain frequency	0.01Hz	50Hz	0 to 400Hz	Frequency at 20mA input can be changed.	49
160	User group read selection	1	9999	0, 1, 9999	Make extended parameters valid	_


4.2 Increase the starting torque (Pr. 0)


Set this parameter when "the motor with a load will not rotate", "an alarm [OL] is output, resulting in an inverter trip due to [OC1], etc.

Parameter Number	Name	Initial Value		Setting Range	Description
		00023	6%		
		00038 to 00083	4%		Motor torque in the low-
0	Torque boost	00126, 00170	3%	0 to 30%	frequency range can be
	Torque boost	00250 to 00770	2%	0 10 30 %	adjusted to the load to increase
		00930, 01160	1.5%		the starting motor torque.
		01800 or more	1%		

Changing example

When the motor with a load will not rotate, increase the $Pr.\ \theta$ value 1% by 1% unit by looking at the motor movement. (The guideline is for about 10% change at the greatest.)





- 5.Press (SET) to read the currently set value.
 "5.0" (initial value is 6% for the
 FR-F740-00023) appears.
- 6.Turn to change it to the set value
- 7.Press (SET) to set.







Flicker ··· Parameter setting complete!!

- · By turning O, you can read another parameter.
- · Press (SET) to show the setting again.
- \cdot Press (SET) twice to show the next parameter.

REMARKS

A too large setting may cause the motor to overheat, resulting in an overcurrent trip (OL (overcurrent alarm) then E.OC1 (Overcurrent shut-off during acceleration)), thermal trip (E.THM (Motor overload shut-off), and E.THT (Inverter overload shut-off)).

When an error (E.OC1) occurs, release the start command, and decrease the *Pr. 0* value 1% by 1% to reset. (*Refer to page 95.*)

POINT

If the inverter still does not operate properly after the above measures, adjust *Pr. 80 Motor capacity(simple magnetic flux vector control)* [extended mode]. (*Refer to Instruction Manual (applied)*.)




4.3 Limit the maximum and minimum output frequency (Pr. 1, Pr. 2)

Parameter Number	Name	Initial Value		Setting Range	Description
1	Maximum frequency	01160 or less 01800 or more	120Hz 60Hz	0 to 120Hz	Set the upper limit of the output frequency.
2	Minimum frequency	0Hz		0 to 120Hz	Set the lower limit of the output

Changing example

Limit the frequency set by the potentiometer, etc. to 50Hz maximum.

(Set "50"Hz in Pr. 1 Maximum frequency.)



Operation 1. Screen at powering on The monitor display appears. 2. Press PU indication is lit. PU indication i

6.Turn to change it to the set value "5000".

7. Press (SET) to set.



Flicker ··· Parameter setting complete!!

- By turning (), you can read another parameter.
- · Press (SET) to show the setting again.
- · Press (SET) twice to show the next parameter.

REMARKS

- · The output frequency is clamped by the $Pr.\ 2$ setting even if the set frequency is lower than the $Pr.\ 2$ setting (The frequency will not decrease to the $Pr.\ 2$ setting.)
 - Note that *Pr. 15 Jog frequency* has higher priority than the minimum frequency.
- When the Pr: 1 setting is changed, frequency higher than the Pr: 1 setting can not be set by \bigcirc .
- · When performing a high speed operation at 120Hz or more, setting of *Pr. 18 High speed maximum frequency* is necessary. (*Refer to Instruction Manual (applied).*)

A CAUTION


If the *Pr. 2* setting is higher than the *Pr. 13 Starting frequency* value, note that the motor will run at the set frequency according to the acceleration time setting by merely switching the start signal on, without entry of the command frequency.

4.4 When the rated motor frequency is 60Hz (Pr. 3)

First, check the motor rating plate. If a frequency given on the rating plate is "60Hz" only, always set *Pr. 3 Base frequency* to "60Hz".

Parameter Number	Name	Initial Value	Setting Range	Description
3	Base frequency	50Hz	0 to 400Hz	Set the frequency when the motor rated torque is generated.

Changing example Change Pr. 3 Base frequency to 60Hz according to the motor rated frequency.



- · By turning O, you can read another parameter.
- · Press (SET) to show the setting again.
- · Press (SET) twice to show the next parameter.



4.5 Change acceleration and deceleration time (Pr. 7, Pr. 8)

Set in *Pr.* 7 Acceleration time a larger value for a slower speed increase and a smaller value for a faster speed increase. Set in *Pr.* 8 Deceleration time a larger value for a slower speed decrease and a smaller value for a faster speed decrease.

Parameter Number	Name	Initial Value		Setting Range	Description
7	Acceleration time	00170 or less	5s	0 to 3600/	Set the motor acceleration time.
'	Accordation time	00250 or more	15s	360s *	oct the motor doctoration time.
8	Deceleration time	00170 or less	10s	0 to 3600/	Set the motor deceleration time.
8	Deceleration time	00250 or more	30s	360s *	Set the motor deceleration time.

^{*} Depends on the Pr. 21 Acceleration/deceleration time increments setting. The initial value for the setting range is $\forall 0$ to $3600 \sigma \forall$ and setting increments is $\forall 0.1 \sigma \forall$.

Changing example Change the Pr. 7 Acceleration time setting from "5s" Pr.20 to "10s". (50Hz) Running frequency (HZ) frequency Time Acceleration Pr.7 Deceleration Pr.8 time Operation Display 1. Screen at powering on The monitor display appears. PU indication is lit. 2. Press $\binom{PU}{EXT}$ to choose the PU operation mode. The parameter 3. Press (MODE) to choose the parameter number read setting mode. previously appears. 4. Turn Ountil P $\P(Pr. 7)$ appears. **5.**Press (SET) to read the currently set value. The initial value differs according "50" (initial value) appears. to the capacity. 6. Turn () to change it to the set value "!\!\!\" 7. Press (SET) to set. Flicker ··· Parameter setting complete!! · By turning (, you can read another parameter.

- · Press (SET) to show the setting again.
- · Press(SET) twice to show the next parameter.

4.6 Energy saving operation (Pr. 60)

Without a fine parameter setting, the inverter automatically performs energy saving operation. This inverter is appropriate for fan and pump applications

Parameter Number	Name	Initial Value	Setting Range	Remarks
			0	Normal operation mode
60	Energy saving control selection	0	4	Energy saving operation mode
			9	Optimum excitation control mode

4.6.1 Energy saving operation mode (setting "4")

- · When "4" is set in Pr. 60, the inverter operates in the energy saving operation mode.
- · In the energy saving operation mode, the inverter automatically controls the output voltage to minimize the inverter output voltage during a constant operation.

REMARKS

· For applications a large load torque is applied to or machines repeat frequent acceleration/deceleration, an energy saving effect is not expected.

4.6.2 Optimum excitation control mode (setting "9")

- · When "9" is set in *Pr.* 60, the inverter operates in the optimum excitation control mode.
- The optimum excitation control mode is a control system which controls excitation current to improve the motor efficiency to maximum and determines output voltage as an energy saving method.

REMARKS

· When the motor capacity is too small as compared to the inverter capacity or two or more motors are connected to one inverter, the energy saving effect is not expected.

CAUTION

- · When the energy saving mode and optimum excitation control mode are selected, deceleration time may be longer than the setting value. Since overvoltage alarm tends to occur as compared to the constant torque load characteristics, set a longer deceleration time.
- The energy saving mode and optimum excitation control functions only under V/F control.


 When a value other than "9999" is set in *Pr. 80 Motor capacity (simple magnetic flux control)*, the energy saving mode and optimum excitation control does not function.

(For simple magnetic flux vector control, refer to the Instruction Manual (applied).)

POINT

When you want to check the energy saving effect, refer to the Instruction Manual (applied) to check the energy saving effect monitor.





- Flicker ··· Parameter setting complete!!
- 8. Perform normal operation. When you want to check the energy saving effect, refer to the instruction manual applied to check the energy saving effect monitor.
 - · By turning), you can read another parameter.
 - to show the setting again.
 - · Press (SET) twice to show the next parameter.

REMARKS

If the motor decelerates to stop, the deceleration time may be longer than the set time. Since overvoltage tends to occur as compared to the constant torque characteristics, set a longer deceleration time.

4.7 Selection of the operation command and frequency command locations (Pr. 79)

Select the start command location and frequency command location.

Parameter Number	Name	Initial Value	Setting Range	Descr	iption	LED Indication □: Off □: On
			0	Use external/PU switchover in between the PU and external page 34)) At power on, the inverter is in mode.	Il operation mode. (Refer to	EXT PU operation mode
			1	Fixed to PU operation mode		PU EXT NET
			2	Fixed to external operation mode Operation can be performed by switching between the external and NET operation mode.		External operation mode EXT NET operation mode
				External/PU combined operation mode 1		
				Running frequency	Start signal	
79	Operation mode	0	3	PU (FR-DU07/FR-PU04/ FR-PU07) setting or external signal input (multi- speed setting, across terminals 4-5 (valid when AU signal turns on)).	External signal input (terminal STF, STR)	PU EXT
7.5	selection	U		External/PU combined opera	ition mode 2	
	0010011011			Running frequency	Start signal	
			4	External signal input (Terminal 2, 4, 1, JOG, multi-speed selection, etc.)	Input from the PU (FR-DU07/FR-PU04/FR-PU07)	
			6	Switchover mode Switch among PU operation, external operation, and NET operation while keeping the same operation status.		PU operation mode External operation mode EXT NET operation mode
			7	External operation mode (PL X12 signal ON* Operation mode can be s mode. (output stop during externation and the component of the component of the component of the component of the component on the component of	PU operation mode External operation mode	

^{*} For the terminal used for the X12 signal (PU operation interlock signal) input, set "12" in Pr. 178 to Pr. 189 (input terminal function selection) to assign functions.

When the X12 signal is not assigned, function of the MRS signal switches from MRS (output stop) to PU operation interlock signal.


For Pr. 178 to Pr. 189, refer to Instruction Manual (applied).



4.8 Parameter clear, all parameter clear

POINT

- · Set "1" in *Pr. CL parameter clear, ALLC All parameter clear* to initialize parameters. (Parameters are not cleared when "1" is set in *Pr. 77 Parameter write selection*.)
- · Refer to the parameter list on page 64 for parameters to be cleared with this operation.



- ? and Ery are displayed alternately ... Why?
 - The inverter is not in the PU operation mode.
 - 1. Press (PU)
 - PU is lit and the monitor (4 digit LED) displays "0" (Pr. 79 = "0" (initial value)).
 - 2. Carry out operation from step 6 again.

4.9 Parameter copy and parameter verification


PCPY Setting	Description			
0	Cancel			
1	Copy the source parameters to the operation panel.			
Write the parameters copied to the operation panel into the destination inverter.				
3 Verify parameters in the inverter and operation panel. (Refer to page 60.)				

REMARKS


- When the copy destination inverter is not the FR-F700 series or parameter copy write is performed after parameter read is stopped, "model error (¬ E Ч)" is displayed.
- Refer to the parameter list on page 64 and later for availability of parameter copy.
- · When the power is turned off or an operation panel is disconnected, etc. during parameter copy write, perform write again or check the values by parameter verification.

4.9.1 Parameter copy

Multiple inverters and parameter settings can be copied.



- Connect the operation panel to the copy source inverter.
- 8.After performing steps 2 to 5, turn to change it to " 2".
- 9.Press (SET) to write the parameters copied to the operation panel to the destination inverter.
- 10.When copy is completed, " 2" and " P[P]" flicker.
- 11. After writing the parameter values to the copy destination inverter, always reset the inverter, e.g. switch power off once, before starting operation.



Flicker ··· Parameter copy complete!!


- ୮ ୧ ፣ appears...Why? 🦃 Parameter read error. Perform operation from step 3 again.
- 🧎 ८६२ appears...Why? 🏈 Parameter write error. Perform operation from step 8 again.
- ?[P and [][] flicker alternately
- P Appears when parameters are copied between the inverter of 01160 or less and 01800 or more.
 - 1. Set "0" in Pr. 160 User group read selection.
 - 2. Set the following setting (initial value) in Pr. 989 Parameter copy alarm release.

	01160 or less	01800 or more
Pr. 989 Setting	10	100

^{3.} Reset Pr. 9, Pr. 30, Pr. 51, Pr. 52, Pr. 54, Pr. 56, Pr. 57, Pr. 70, Pr. 72, Pr. 80, Pr. 90, Pr. 158, Pr. 190 to Pr. 196, Pr. 893.

4.9.2 Parameter verification

Whether same parameter values are set in other inverters or not can be checked.



Flicker ··· Parameter verification complete!!

REMARKS

When the copy destination inverter is not the FR-F700 series, "model error (- E 4)" is displayed.

- ? rea flickers ... Why?
 - Set frequencies, etc. may be different. Check set frequencies.



4.10.1 List of parameters classified by purpose of use

Set the parameters according to the operating conditions. The following list indicates purpose of use and corresponding parameters.


	Purpose of Use	Parameter Number
	Manual torque boost	Pr. 0, Pr. 46
	Simple magnetic flux vector control	Pr. 80, Pr. 90
Adjust the output torque of	Slip compensation	Pr. 245 to Pr. 247
the motor (current)	Stall prevention operation	Pr. 22, Pr. 23, Pr. 48, Pr. 49, Pr. 66, Pr. 148, Pr. 149, Pr. 154, Pr. 156, Pr. 157
	Multiple rating setting	Pr. 570
Limit the output frequency	Maximum/minimum frequency	Pr. 1, Pr. 2, Pr. 18
Limit the output frequency	Pr. 31 to Pr. 36	
	Base frequency, voltage	Pr. 3, Pr. 19, Pr. 47
Set V/F pattern	V/F pattern matching applications	Pr. 14
	Adjustable 5 points V/F	Pr. 71, Pr. 100 to Pr. 109
	Multi-speed setting operation	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239
Frequency setting with	Jog operation	Pr. 15, Pr. 16
terminals (contact input)	Input compensation of multi-speed and remote setting	Pr. 28
	Remote setting function	Pr. 59
	Acceleration/deceleration time setting	Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45
Acceleration/deceleration	Starting frequency	Pr. 13, Pr. 571
time/pattern adjustment	Acceleration/deceleration pattern and backlash measures	Pr. 29, Pr. 140 to Pr. 143
	Regeneration avoidance functions at deceleration	Pr. 882 to Pr. 886
Selection and protection of a	Motor protection from overheat (electronic thermal relay function)	Pr. 9, Pr. 51
motor	Use the constant torque motor (applied motor)	Pr. 71
	DC injection brake	Pr. 10 to Pr. 12
Motor brake and stop	Selection of regeneration unit	Pr. 30, Pr. 70
operation	Selection of motor stopping method	Pr. 250
	Decelerate the motor to a stop at instantaneous power failure	Pr. 261 to Pr. 266
	Function assignment of input terminal	Pr. 178 to Pr. 189
	Start signal selection	Pr. 250
	Logic selection of output stop signal (MRS)	Pr. 17
Function assignment of	Selection of action conditions of the second function signal (RT)	Pr. 155
Function assignment of external terminal and control	Terminal assignment of output terminal	Pr. 190 to Pr. 196
	Detection of output frequency (SU, FU, FU2 signal)	Pr. 41 to Pr. 43, Pr. 50
	Detection of output current (Y12 signal) Detection of zero current (Y13 signal)	Pr. 150 to Pr. 153, Pr. 166, Pr. 167
	Remote output function (REM signal)	Pr. 495 to Pr. 497
	Speed display and speed setting	Pr. 37, Pr. 144
Monitor display and monitor	Change of DU/PU monitor descriptions Cumulative monitor clear	Pr. 52, Pr. 170, Pr. 171, Pr. 563, Pr. 564, Pr. 891
output signal	Change of the monitor output from terminal CA and AM	Pr. 54 to Pr. 56, Pr. 158, Pr. 867, Pr. 869
	Adjustment of terminal CA and AM (calibration)	C0 (Pr. 900), C1 (Pr. 901)
	Energy saving monitor	Pr. 891 to Pr. 899
Detection of outset for such	Detection of output frequency (SU, FU, FU2 signal)	Pr. 41 to Pr. 43, Pr. 50
Detection of output frequency and current	Detection of output current (Y12 signal) Detection of zero current (Y13 signal)	Pr. 150 to Pr. 153, Pr. 166, Pr. 167



	Purpose of Use	Parameter Number				
Operation selection at power	Restart operation after instantaneous power failure/Flying	Pr. 57, Pr. 58, Pr. 162 to Pr. 165, Pr.				
failure and instantaneous power failure	start	299, Pr. 611				
power failure	Decelerate the motor to a stop at instantaneous power failure	Pr. 261 to Pr. 266				
	Retry function at alarm occurrence	Pr. 65, Pr. 67 to Pr. 69				
Operation setting at alarm	Output function of alarm code	Pr. 76				
occurrence	Input/output phase failure protection selection	Pr. 251, Pr. 872				
	Regeneration avoidance function	Pr. 882 to Pr. 886				
Energy saving operation	Energy saving control selection	Pr. 60				
	How much energy can be saved (energy saving monitor)	Pr. 891 to Pr. 899				
Reduction of the motor noise Measures against noise and	Carrier frequency and SoftPWM selection	Pr. 72, Pr. 240, Pr. 260				
leakage currents	Noise elimination at the analog input	Pr. 74				
	Analog input selection	Pr. 73, Pr. 267, Pr. 573				
	Override function	Pr. 73, Pr. 252, Pr. 253				
Frequency setting by analog	Noise elimination at the analog input	Pr. 74				
input	Change of analog input frequency, adjustment of voltage, current input and frequency (calibration)	Pr. 125, Pr. 126, Pr. 241, C2 to C7 (Pr. 902 to Pr. 905)				
	Compensation at the analog input	Pr. 242, Pr. 243				
	Reset selection, disconnected PU detection	Pr. 75				
	Prevention of parameter rewrite	Pr. 77				
Misoperation prevention and parameter setting restriction	Prevention of reverse rotation of the motor	Pr. 78				
parameter setting restriction	Display necessary parameters only. (user group)	Pr. 160, Pr. 172 to Pr. 174				
	Control of parameter write by communication	Pr. 342				
	Operation mode selection	Pr. 79				
	Operation mode when power is on	Pr. 79, Pr. 340				
Selection of operation mode and operation location	Operation command source and speed command source during communication operation	Pr. 338, Pr. 339				
	Selection of the NET mode operation control source	Pr. 550				
	Selection of the PU mode operation control source	Pr. 551				
	PU connector communication	Pr. 117 to Pr. 124, Pr. 331 to Pr. 337, Pr. 341, Pr. 539				
	Control of parameter write by communication	Pr. 342				
Communication operation	ModbusRTU communication specifications	Pr. 343				
and setting	Operation command source and speed command source during communication operation	Pr. 338, Pr. 339				
	Selection of the NET mode operation control source	Pr. 550				
	ModbusRTU protocol (communication protocol selection)	Pr. 549				
	PID control	Pr. 127 to Pr. 134, Pr. 575 to Pr. 577				
Special operation and	Switch between the inverter operation and commercial power-supply operation to use	Pr. 135 to Pr. 139, Pr. 159				
frequency control	Pump function	Pr.575 to Pr.591				
	Traverse function	Pr. 592 to Pr. 597				
	Regeneration avoidance function	Pr. 882 to Pr. 886				
	Free parameter	Pr. 888, Pr. 889				
Licoful functions	Increase cooling fan life	Pr. 244				
Useful functions	To determine the maintenance time of parts.	Pr. 255 to Pr. 259, Pr. 503, Pr. 504				
	How much energy can be saved (energy saving monitor)	Pr. 60, Pr. 891 to Pr. 899				
	Parameter unit language switchover	Pr. 145				
Setting from the parameter	Operation selection of the operation panel	Pr. 161				
unit and operation panel	Buzzer control of the operation panel	Pr. 990				
	Contrast adjustment of the parameter unit	Pr. 991				
	•	•				

4.11Extended parameters

4.11.1 Used to display the extended parameters



- · By turning O, you can read another parameter.
- · Press (SET) to show the setting again.
- · Press (SET) twice to show the next parameter.

After parameter setting is completed, press (MODE) once to show the alarm history and press (MODE) twice to return to the monitor display. To change settings of other parameters, perform the operation in above steps 3 to 7.

? Error display?

 $\mathcal{F}_{\mathcal{F}}$! If the operation panel does not have the write precedence

REMARKS

If the setting has not been changed, the value does not flicker and the next parameter number appears.

Pr. 160	Description
9999 (Initial Value)	Only the simple mode parameters can be displayed.
0	Simple mode and extended mode parameters can be displayed.
1	Only the parameters registered in the user group can be displayed.



4.12Parameter list

(a) indicates simple mode parameters.

on	Paran								Param eter	Param eter	All param eter
Function Function Related Parameters		nted neters	ម្ពុ Name	Incre ments	Initial Value	Range	Description		сору	clear	clear
Ful	Name ments Value Range							O: enab			
						Set the output voltage at 0Hz as %. *1 Initial values differ according to the inverter capacity.		×:	uisai	neu	
Manual torque boost		_			6/4/3/2/		Inverter capacity 400V class	Initial value			
e p	0	0	Torque boost	0.1%	1.5/1%	0 to 30%	00023	6%	0	0	0
orqu					*1		00038 to 00083	4%			
al tc							00126, 00170	3%			
anuš							00250 to 00770	2%			
Ĕ							00930, 01160	1.5% 1%			
							01800 or more				
		46	Second torque boost	0.1%	9999	0 to 30%	is on.	Set the torque boost when the RT signal is on.			0
						9999	Without second torque boost				<u> </u>
nimum iy	1	0	Maximum frequency	0.01Hz	120/ 60Hz*2	0 to 120Hz	Set the upper limit of the output frequency. *2 The setting depends on the inverter capacity. (01160 or less/01800 or more)		0	0	0
/mir enc	Maximum/minimum frequency		Minimum frequency	0.01Hz	0Hz	0 to 120Hz	Set the lower limit of the output frequency.		0	0	0
Maximum frequ			High speed maximum frequency	0.01Hz	120/ 60Hz*3	120 to 400Hz	Set when performing the of 120Hz or more. *3 The setting depends capacity. (01160 or less)	on the inverter	0	0	0
ltage	3	0	Base frequency	0.01Hz	50Hz	0 to 400Hz	Set the frequency when the motor rated torque is generated. (50Hz/60Hz)		0	0	0
0,			Base frequency voltage		8888	0 to 1000V	Set the base voltage. 95% of power supply voltage Same as power supply voltage		0	0	0
ncy		19		0.1V		8888					
dne						9999					
Base frequency, voltage		47	Second V/F (base frequency)	0.01Hz	9999	0 to 400Hz	Set the base frequency who signal is on.	en the RT	0	0	0
В						9999	Second V/F is invalid				
u	4	0	Multi-speed setting (high speed)	0.01Hz	50Hz	0 to 400Hz	Set frequency when the RT	Set frequency when the RT signal is on.		0	0
peratic	5	0	Multi-speed setting (middle speed)	0.01Hz	30Hz	0 to 400Hz	Set frequency when the RM signal is on.		0	0	0
tting o	6	0	Multi-speed setting (low speed) 0.01Hz	10Hz	0 to 400Hz	Set frequency when the F	L signal is on.	0	0	0	
Multi-speed setting operation		to 27	Multi-speed setting (4 speed to 7 speed)	0.01Hz	9999	0 to 400Hz, 9999	Frequency from 4 speed to be set according to the corr	bination of the	0	0	0
Mult		to	Multi-speed setting (8 speed to 15 speed)	0.01Hz	9999	0 to 400Hz, 9999	RH, RM, RL and REX signal 9999: not selected	als.	0	0	0

_	Paran	neter						Param	Param	All param
Function		ted eters	Name	Incre	Initial	Range	Description	eter copy	eter clear	eter clear
Fun		Related parameters		ments	Value				enab disab	
7		<u> </u>	Acceleration time	0.1/ 0.01s	5/15s *4	0 to 3600/ 360s	Set the motor acceleration time. *4 Initial values differ according to the inverter capacity. (00170 or less/00250 or more)	0	O	0
		0	Deceleration time	0.1/ 0.01s	10/30s *5	0 to 3600/ 360s	Set the motor deceleration time. *5 Initial values differ according to the inverter capacity. (00170 or less/00250 or more)		0	0
Acceleration/deceleration time setting		20	Acceleration/ deceleration reference frequency	0.01Hz	50Hz	1 to 400Hz	Set the frequency referenced as acceleration/deceleration time. Set the frequency change time from stop to <i>Pr. 20</i> for acceleration/deceleration time.	0	0	0
/decelerati		21	Acceleration/ deceleration time	1	0	0	Increments: 0.1s Range: 0 to 3600s Increments and setting range of acceleration/ deceleration time	0	0	0
leration/			increments			1	Increments: 0.01s Range: 0 to 360s deceleration time setting can be changed.			
Ассе		44	Second acceleration/ deceleration time	0.1/ 0.01s	5s	0 to 3600/ 360s	Set the acceleration/deceleration time when the RT signal is on.	0	0	0
		45	Second deceleration time	0.1/ 0.01s	9999	0 to 3600/ 360s 9999	Set the deceleration time when the RT signal is on. Acceleration time = deceleration time		0	0
ion at rmal n)	9	© Electronic thermal O/L relay 0.01/ 0.14*6 Current 1.60 Curre		0	0	0				
Motor protection from overheat (electronic thermal relay function)		51	Second electronic thermal O/L relay	0.01/ 0.1A *7	9999	0 to 500A 0 to 3600A *7	Made valid when the RT signal is on. Set the rated motor current. *7 The setting depends on the inverter capacity (01160 or less/01800 or more)		0	0
ı e						9999	Second electronic thermal O/L relay invalid			L
	10		DC injection brake	0.01Hz	3Hz	0 to 120Hz	Set the operation frequency of the DC injection brake. Operate when the output frequency	0	0	0
ake	10		operation frequency	0.01112	3112	9999	becomes less than or equal to Pr.13Starting frequency.)
on br	on br				0.5s	0	DC injection brake disabled Set the operation time of the DC injection			
jecti	11		DC injection brake operation time			0.1 to 10s	brake. Operate DC injection brake for the time X13 signal is on.		0	0
DC injection br		operation time				8888				
			DO initiative tool			0	DC injection brake disabled Set the DC injection brake voltage (torque).			
	12		DC injection brake operation voltage	0.1%	4/2/1% *8	0.1 to 30%	 *8 Initial values differ according to the inverter capacity. (00170 or less/00250 to 01160/01800 or more) 		0	0
ncy	13		Starting frequency	0.01Hz	0.5Hz	0 to 60Hz	Starting frequency can be set.	0	0	0
g freque		571	Holding time at a	0.4	9999	0.0 to 10.0s	Set the holding time of <i>Pr.13 Starting</i> frequency.	0		
Startinç	Starting frequency		start	0.1s	J333	9999	Holding function at a start is invalid		0	0
V/F pattern matching applications	14		Load pattern 1 1		0	0	0			
V/F patte appli		selection				1	For reduced-torque load			



Parameter		neter							Param	Param	All param			
ctio	Function Related Sarameters		Name		Initial	Range	Description		eter copy	eter clear	eter clear			
Fun				ments	Value					enab				
	15	ď	log froguency	0.01	5Hz	0 to 400Hz	Sat the frequency for	ing operation	×:	disab	olea			
Jog operation	16		Jog frequency Jog acceleration/ deceleration time	0.01Hz 0.1/ 0.01s	0.5s	0 to 3600/ 360s	Set the frequency for jog operation. Set the acceleration/deceleration time for jog operation. Set the time taken to reach the frequency set in Pr.20 Acceleration/deceleration reference frequency for acceleration/deceleration time. (Initial value is 60Hz) In addition, acceleration/deceleration time can not be set separately.		0	0	0			
Logic selection of output stop signal (MRS)	17		MRS input selection	1	0	2	Open input always Normally closed input specifications)	(NC contact input	0	0	0			
	18		Refer to Pr.1 and Pr.2						•					
_	19		Refer to Pr.3.											
	20,	21	Refer to Pr.7 and Pr.8	-										
	22		Stall prevention operation level	0.1%	110%	0 0.1 to 120%	Stall prevention operation selection becomes invalid. Set the current value at which stall prevention operation is started.		0	0	0			
						9999	Analog variable		ł					
	23		Stall prevention operation level compensation factor at double	0.1%	9999	0 to 150%	The stall operation lev when operating at a hi rated frequency.	gh speed above the	0	0	0			
			speed			9999	Constant according to Pr.22							
	4		Second stall 48 prevention operation current		110%	0 0.1 to 120%	Second stall prevention operation invalid The stall prevention operation level can be set.		0	0	0			
ı operation		49	Second stall prevention operation frequency	0.01Hz	0Hz	0 0.01 to 400Hz 9999	Second stall preventic Set the frequency at w prevention operation of Pr.48 is valid when the	which stall of Pr. 48 is started.	0	0	0			
Stall prevention operation			66	Stall prevention operation reduction starting frequency	0.01Hz	60Hz	0 to 400Hz	Set the frequency at voperation level is start		0	0	0		
Stal		148	Stall prevention level at 0V input	0.1%	110%	0 to 120%	Stall prevention opera		0	0	0			
		149	Stall prevention level at 10V input	0.1%	120%	0 to 120%	changed by the analogeterminal 1.	y signai input to	0	0	0			
		Voltage reduction			0	With voltage reduction	You can select whether to use							
					stall pr	selection during stall prevention operation	1	1	1	Without voltage reduction	output voltage reduction during stall prevention operation or not.	0	0	0
		156	Stall prevention operation selection	1	0	0 to 31, 100, 101	Pr. 156 allows you to se stall prevention or not a acceleration/deceleration	ccording to the on status.	0	0	0			
		157	OL signal output timer	0.1s	0s	0 to 25s 9999	Set the output start time output when stall preve Without the OL signal	ntion is activated.	0	0	0			
	24 to	27	Refer to Pr. 4 to Pr. 6.						-					

_	Paran	neter						Param	Param	All param	
Function		ed ters	Name	Incre	Initial	Range	Description		eter copy	eter clear	eter clear
Fun		Related parameters		ments	Value				enab		
_		٥				0	Without componenties		×:	disab	olea
Input compensation of multi-speed and remote setting	28		Multi-speed input compensation selection	1	0	1	Without compensation With compensation		0	0	0
						0	Linear acceleration/ d	eceleration			
	29		Acceleration/ deceleration pattern	1	0	1	S-pattern acceleration	/deceleration A	0	0	0
	20		selection	'	O	2	S-pattern acceleration	/deceleration B			
on on h measures		140	Backlash acceleration stopping frequency	0.01Hz	1Hz	0 to 400Hz	Backlash measures	Backlash measures		0	0
Acceleration/ deceleration pattern and backlash measures		141	Backlash acceleration stopping time	0.1s	0.5s	0 to 360s	Set the stopping freque	uency and time for	0	0	0
		142	Backlash deceleration stopping frequency	0.01Hz	1Hz	0 to 400Hz	Valid when Pr.29="3"		0	0	0
		143	Backlash deceleration stopping time	0.1s	0.5s	0 to 360s			0	0	0
ation unit	30	0	Regenerative	1	0	0	O1160 or less Brake unit Setting can not be made.	01800 or more Without regenerative function Brake unit, Power regeneration	0	0	0
Selection of regeneration unit			function selection			2	High power factor converter, power regeneration common converter converter				
Sele		70	Special regenerative brake duty	0.1%	0%	0 to 10%	You can set the brake duty when a brake unit or power regeneration converter is used. Setting can be made for the 01800 or more.		0	0	0
	31		Frequency jump 1A	0.01Hz	9999	0 to 400Hz, 9999			0	0	0
cal nts np)	32		Frequency jump 1B	0.01Hz	9999	0 to 400Hz, 9999			0	0	0
Avoid mechanical resonance points (frequency jump)	33		Frequency jump 2A	0.01Hz	9999	0 to 400Hz, 9999	1A to 1B, 2A to 2B, 3/ jumps	A to 3B is frequency	0	0	0
void m sonan requer	34		Frequency jump 2B	0.01Hz	9999	0 to 400Hz, 9999	9999: Function invalid	I	0	0	0
A re	35		Frequency jump 3A	0.01Hz	9999	0 to 400Hz, 9999			0	0	0
	36		Frequency jump 3B	0.01Hz	9999	0 to 400Hz, 9999			0	0	0
ay and ting	37		Speed display	1	0	0 1 to 9998	Frequency display, se Set the machine spee		0	0	0
Speed display and speed setting		144	Speed setting switchover	1	4	0, 2, 4, 6, 8, 10, 102, 104, 106, 108, 110	Set the number of motor poles when displaying the motor speed.		0	0	0



L	Paran	neter						Param	Param	All param
tio		d ers	Name	Incre	Initial	Range	Description	eter copy	eter clear	eter
Function		Related parameters	Name	ments	Value	Range	Description	0:	enab	
ш		par						×:	disab	oled
uency II)	41		Up-to-frequency sensitivity	0.1%	10%	0 to 100%	Set the level where the SU signal turns on.	0	0	0
out frequ 2 signa	42		Output frequency detection	0.01Hz	6Hz	0 to 400Hz	Set the frequency where the FU signal turns on.	0	0	0
Detection of output frequency (SU, FU, FU2 signal)	43		Output frequency detection for	0.01Hz	9999	0 to 400Hz	Set the frequency where the FU signal turns on in reverse rotation.	0	0	0
ctior SU,	,		reverse rotation			9999	Same as Pr.42 setting			
Dete		50	Second output frequency detection	0.01Hz	30Hz	0 to 400Hz	Set the frequency where the FU2 signal turns on.	0	0	0
	44,	45	Refer to Pr. 7 and Pr.	8.						
_	46		Refer to Pr. 0.							
	47		Refer to Pr. 3.							
	48,	49	Refer to Pr. 22 and Pr	: 23.						
_	50		Refer to Pr. 41 to Pr. 4	43.						
	51		Refer to Pr. 9.							
	52		DU/PU main display data selection	1	0	0, 5, 6, 8 to 14, 17, 20, 23 to 25, 50 to 57, 100	Select the monitor to be displayed on the operation panel and parameter unit. The setting value of "9" is available only for the 01800 or more.	0	0	0
						0	Set "0" to clear the watt-hour meter monitor.			
Sur		170	Watt-hour meter clear	1	9999	10	Set the maximum value when monitoring from communication to 0 to 9999kWh.	×	×	0
iptio						9999	Set the maximum value when monitoring from communication to 0 to 65535kWh.			
Change of DU/PU monitor descriptions Cumulative monitor clear		171	Operation hour meter clear	1	9999	0, 9999	Set "0" in the parameter to clear the watt- hour monitor. Setting "9999" has no effect.	×	×	×
noni			Monitor decimal			0	Displays the monitor as integral value.			
⊃U r ive r		268	digits selection	1	9999	1	Displays the monitor in increments of 0.1.	0	0	0
e of DU/PU monitor desc Cumulative monitor clear		563	Energization time carrying-over times	1	0	9999 0 to 65535	No fixed decimal position The numbers of cumulative energization time monitor exceeded 65535h is displayed. Reading only	×	×	×
Chang		564	Operating time carrying-over times	1	0	0 to 65535	The numbers of operation time monitor exceeded 65535h is displayed. Reading only	×	×	×
			Cumulative power			0 to 4	Set the number of times to shift the cumulative power monitor digit. Clamp the monitor value at maximum.			
		891	monitor digit shifted times	1	9999	9999	No shift Clear the monitor value when it exceeds the maximum value.	0	0	0
	54		CA terminal function selection	1	1	1 to 3, 5, 6, 8 to 14, 17, 21, 24, 50, 52, 53	Select the monitor output to terminal CA. The setting value of "9" is available only for the 01800 or more.	0	0	0
monitor rminal M	55		Frequency monitoring reference	0.01Hz	50Hz	0 to 400Hz	Set the full-scale value to output the output frequency monitor value to terminal CA and AM.	0	0	0
Change of the monitor output from terminal CA and AM	56		Current monitoring reference	0.01/ 0.1A *9	Inverter rated current	0 to 500/ 0 to 3600A	Set the full-scale value to output the output current monitor value to terminal CA and AM. *9 The setting depends on the inverter capacity (01160 or less/01800 or more)	0	0	0
Char		158	AM terminal function selection	1	1	1 to 3, 5, 6, 8 to 14, 17, 21, 24, 50, 52, 53	Select the monitor output to terminal AM. The setting value of "9" is available only for the 01800 or more.	0	0	0
		867	AM output filter	0.01s	0.01s	0 to 5s	Set the output filter of terminal AM.	0	0	0
		869	Current output filter	0.01s	0.02s	0 to 5s	Adjust response level of current output.	0	0	0
			i			1				·

_	Paran	neter							Param	Param	All
Function		d	Name	Incre	Initial	Range	Descri	ntion	eter copy	eter clear	param eter clear
oun:		Related parameters	Name	ments	Value	Range	Descri	ption	0:	enab	
Щ		R							×:	disab	led
	57		Restart coasting time	0.1s	9999	0 0.1 to 5s/	The coasting time is 00038 or less		0	0	0
						0.1 to 30s *10	restart after an instantal *10 The setting depe capacity (01160 or No restart				
	58		Restart cushion time	0.1s	1s	0 to 60s	Set a voltage starting	time at restart.	0	0	0
			Automatic restart			0	With frequency search				
		162	after instantaneous power failure	1	0	1	Without frequency sea voltage system)		0	0	0
			selection			10	Frequency search at 6				
tion eous			First cushion time			11	Reduced voltage syste	em at every start			
Restart operation after instantaneous power failure		163	for restart	0.1s	0s	0 to 20s	Set a voltage starting Consider according to		0	0	0
estart er inst powe		164	First cushion voltage for restart	0.1%	0%	0 to 100%	load (moment of inerti	a/torque).	0	0	0
R		165	Stall prevention operation level for restart	0.1%	110%	0 to 120%	Consider the rated inv 100% and set the stal operation level during	l prevention	0	0	0
						0	Without rotation direct	ion detection			
			Rotation direction			1	With rotation direction	detection			
		299	detection selection at restarting	1	9999	9999	When <i>Pr.</i> 78="0", the n detected. When <i>Pr.</i> 78="1","2", th is not detected.		0	0	0
		611	Acceleration time at	0.1s	5/15s *11	0 to 3600s	Set the acceleration time to reach the set frequency at a restart.	*11 The setting depends on the inverter capacity	0	0	0
		011	a restart	0.13	0/103 11	9999	Acceleration time for restart is the normal acceleration time (e.g. <i>Pr.</i> 7).	(01160 or less/ 01800 or more)		O	Ö
ction							RH, RM, RL signal function	Frequency setting storage function			
fun						0	Multi-speed setting	<u> </u>			
ting	59		Remote function	1	0	2	Remote setting	Yes No	0	0	0
Remote setting function			selection	· 		3	Remote setting Remote setting	No (Turning STF/ STR off clears remotely-set frequency.)))
ing tion						0	Normal operation mode	•			
gy savi I selec	60	0	Energy saving control selection	1	0	4	Energy saving operati	on mode	0	0	0
Energy saving control selection			23			9	Optimum excitation co	ontrol mode			



_		neter						Param	Param	All param
Function		Related parameters	Name	Incre ments	Initial Value	Range	Description	copy	eter clear enab	eter clear
Ţ		Re							disab	
	65		Retry selection	1	0	0 to 5	An alarm for retry can be selected.	0	0	0
ence						0	No retry function			
m occurre		67	Number of retries at	1	0	1 to 10	Set the number of retries at alarm occurrence. An alarm output is not provided during retry operation.	0	0	0
Retry function at alarm occurrence			alarm occurrence			101 to 110	Set the number of retries at alarm occurrence. (The setting value minus 100 is the number of retries.) An alarm output is provided during retry operation.			
ry func		68	Retry waiting time	0.1s	1s	0 to 10s	Set the waiting time from when an inverter alarm occurs until a retry is made.	0	0	0
Ref		69	Retry count display erase	1	0	0	Clear the number of restarts succeeded by retry.	0	0	0
_	66		Refer to Pr.22 and Pr.	23.						
	67 to	69	Refer to Pr.65.							
_	70		Refer to Pr.30.							
r) ut						0	Thermal characteristics of a standard motor			
consta motor I moto	71		Applied motor	1	0	1	Thermal characteristics of the Mitsubishi constant-torque motor	0	0	0
Use the constant torque motor (applied motor)	' '		Applied motor	'	O	2	Thermal characteristic of standard motor Adjustable 5 points V/F	O		0
N						20	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)			
	72		PWM frequency selection	1	2	0 to 15/ 0 to 6, 25 *12	PWM carrier frequency can be changed. The setting displayed is in [kHz]. Note that 0 indicates 0.7kHz, 15 indicates 14.5kHz and 25 indicates 2.5kHz. *12 The setting depends on the inverter capacity (01160 or less/01800 or more)	0	0	0
enc)			Soft-PWM			0	Soft-PWM invalid			
arrier frequenc and SoftPWM selection		240	operation selection	1	1	1	When <i>Pr.</i> 72="0 to 5" ("0 to 4" for the 01800 or more), Soft-PWM is valid.	0	0	0
Carrier frequency and SoftPWM selection		260	PWM frequency automatic switchover	1	1	0	PWM carrier frequency is constant independently of load. When the carrier frequency is set to 3kHz or more (Pr. 72≥3), perform continuous operation at less than 85% of the rated inverter current. Decreases PWM carrier frequency automatically when load increases.	0	0	0

Function	Paran		Name	Incre	Initial	Panga	Description	Param eter copy	Param eter clear	All param eter clear
Func		Related parameters	Name	ments	Value	Range	Description	_	enab disak	led
	73		Analog input selection	1	1	0 to 7, 10 to 17	You can select the input specifications of terminal 2 (0 to 5V, 0 to 10V, 0 to 20mA) and input specifications of terminal 1 (0 to \pm 5V, 0 to \pm 10V). To change the terminal 2 to the voltage input specification (0 to 5V/ 0 to 10V), turn OFF(initial status) the voltage/current input switch 2. To change it to the curren input(0 to 20mA), turn ON the voltage/current input switch 2. Override and reversible operation can be selected.		×	0
		242	Terminal 1 added compensation amount (terminal 2)	0.1%	100%	0 to 100%	Set the ratio of added compensation amount when terminal 2 is the main speed.	0	0	0
Analog input selection		243	Terminal 1 added compensation amount (terminal 4)	0.1%	75%	0 to 100%	Set the ratio of added compensation amount when terminal 4 is the main speed.	0	0	0
g inpu		252	Override bias	0.1%	50%	0 to 200%	Set the bias side compensation value of override function.	0	0	0
Analo		253	Override gain	0.1%	150%	0 to 200%	Set the gain side compensation value of override function.	0	0	0
		267	Terminal 4 input selection	1	0	0	Terminal 4 input 4 to 20mA Turn ON the voltage/current input switch 1 (initial status). Terminal 4 input 0 to Turn OFF the	0	×	0
						2	Terminal 4 input 0 to 10V			
		573	4mA input check selection	1	9999	1 9999	When the current input drops to or below 2mA, the LF signal is output and inverter continues operation at the frequency just before current reaches 2mA. 4mA input is not checked.		0	0
Noise elimination at the analog input	74		Input filter time constant	1	1	0 to 8	The primary delay filter time constant for the analog input can be set. A larger setting results in a larger filter.	0	0	0
Reset selection, disconnected PU detection	75		Reset selection/ disconnected PU detection/PU stop selection	1	14	0 to 3, 14 to 17 100 to 103, 114 to 117*	You can select the reset input acceptance, disconnected PU (FR-DU07/FR-PU04/FR-PU07) connector detection function and PU stop function, and reset restriction (01800 o more). For the initial value, reset always enabled, without disconnected PU detection, with PU stop function, and without reset restriction (01800 or more) are set. * 100 to 103 and 114 to 117 can be set onl for 01800 or more.	0	×	×
Output function of alarm code	76		Alarm code output selection	1	0	0 1 2	Without alarm code output With alarm code output Alarm code output at alarm occurrence only	0	0	0



tion	Paran			Incre	Initial	_		Param eter copy	Param eter clear	All param eter
Function		Related parameters	Name	ments	Value	Range	Description	0:	enab disab	
ite						0	Write is enabled only during a stop			
n o'						1	Parameter write is disabled.			
Prevention of parameter rewrite	77		Parameter write selection	1	0	2	Parameter write is enabled in any operation mode regardless of operation status.	0	0	0
n of tation otor			_			0	Both forward and reverse rotations allowed			
ntic r of a	78		Reverse rotation	1	0	1	Reverse rotation disallowed	0	0	0
Prevention of reverse rotation of the motor			prevention selection			2	Forward rotation disallowed			
						0	External/PU switchover mode			
						1	Fixed to PU operation mode			
						2	Fixed to External operation mode			
	79	0	Operation mode	1	0	3	External/PU combined operation mode 1	0	0	0
	13	•	selection	'	U	4	External/PU combined operation mode 2			0
<u>_</u>						6	Switchover mode			
selectic						7	External operation mode (PU operation interlock)			
Je 8						0	As set in Pr.79.			
Operation mode selection			Communication			1, 2	Started in the network operation mode. When the setting is "2", it will resume the pre- instantaneous power failure operation mode after an instantaneous power failure occurs.			
ō		340	startup mode selection	1	0	10, 12	Started in the network operation mode. Operation mode can be changed between the PU operation mode and network operation mode from the operation panel. When the setting is "12", it will resume the preinstantaneous power failure operation mode after an instantaneous power failure occurs.	0	0	0
netic or	80		Motor capacity(simple magnetic flux vector control)	0.01kW/ 0.1kW *13	9999	0.4 to 55/ 0 to 3600kW *13	To select the simple magnetic flux vector control, set the capacity of the motor used. *13 The setting depends on the inverter capacity (01160 or less/01800 or more) V/F control is performed	0	0	0
naç ect						5555	Used to set the motor primary resistance			
Simple magnetic flux vector control	90		Motor constant (R1)	0.001Ω/ 0.01mΩ*	9999	0 to 50Ω/ 0 to 400mΩ *14	value. (Normally setting is not necessary.) *14 The setting depends on the inverter capacity (01160 or less/01800 or more) Use the Mitsubishi motor (SF-JR, SF-	0	×	0
					9999	HRCA) constants				

on	Paran							Param eter	Param eter	All param eter
Function		Related parameters	Name	Incre ments	Initial Value	Range	Description	_	enab disab	clear led
	100		V/F1(first frequency)	0.01Hz	9999	0 to 400Hz, 9999		0	0	0
	101		V/F1(first frequency voltage)	0.1V	0V	0 to 1000V		0	0	0
	102		V/F2(second frequency)	0.01Hz	9999	0 to 400Hz, 9999		0	0	0
//F	103 sti 104		V/F2(second frequency voltage)	0.1V	0V	0 to 1000V		0	0	0
ooints '	104		V/F3(third frequency)	0.01Hz	9999	0 to 400Hz, 9999	Set each points (frequency, voltage) of V/F pattern.	0	0	0
Adjustable 5 points V/F	105		V/F3(third frequency voltage)	0.1V	0V	0 to 1000V	9999: No V/F setting	0	0	0
Adjusta	106		V/F4(fourth frequency)	0.01Hz	9999	0 to 400Hz, 9999		0	0	0
,	107		V/F4(fourth frequency voltage)	0.1V	0V	0 to 1000V	000V	0	0	0
	108		V/F5(fifth frequency)	0.01Hz	9999	0 to 400Hz, 9999	OHz,	0	0	0
	109		V/F5(fifth frequency voltage)	0.1V	0V	0 to 1000V		0	0	0
		71	Refer to page 70.							



Function	Paran	Related barameters	Name	Incre ments	Initial Value	Range	Descri	ption	Param eter copy	Param eter clear	All param eter clear
Ē		Rela paran			valuo				_	enab disab	
	117		PU communication station number	1	0	0 to 31	Specify the inverter station of the inverter station of more inverters are connected to the computer.	umbers when two or	0	0	0
	118		PU communication speed	1	192	48, 96, 192, 384	Set the communication. The setting value × 10 communication speed For example, the communication when the setting the communication speeds.	00 equals the munication speed is	0	0	0
							Stop bit length	data length			
			PU communication			0	1bit	8bit			
	119		stop bit length	1	1	1	2bit	8bit	0	0	0
			otop bit longti			10	1bit	7bit			
						11	2bit	7bit			
	1		PU communication			0	Without parity check				
	120		parity check	1	2	1	With odd parity check		0	0	0
			,			2	With even parity chec				
U connector communication	121		Number of PU communication retries	1	1	0 to 10	Set the permissible nu occurrence of a data r If the number of conse exceeds the permissil inverter will come to a	eceive error. ecutive errors ble value, the	0	0	0
tor co						9999	If a communication er inverter will not come				
nec						0	No PU connector com				
PU con	122		PU communication check time interval	0.1s	9999	0.1 to 999.8s	Set the communication of a no-communication of the period of the communication of the communi	n state persists for rmissible time, the	0	0	0
						9999	No communication ch	eck			
	123		PU communication waiting time setting	1	9999	0 to 150ms	Set the waiting time b transmission to the inv		0	0	0
						9999	Set with communication	on data.			
			PU communication			0	Without CR/LF		_	_	_
	124		CR/LF presence/	1	1	1	With CR		0	0	0
			absence selection			2	With CR/LF				
		342	Communication EEPROM write	1	0	0	Parameter values writt communication are wri and RAM.		0	0	0
			selection			1	Parameter values writ communication are w	itten to the RAM.			
		551	PU mode operation command source	1	2	1	Select the RS-485 ter operation mode control	ol source.	0	0	0
		007	selection	,	_	2	Select the PU connect operation mode control		Ū		

_	Paran	neter							Param	Param	All param
Function		ed ters	Name	Incre	Initial	Range	Descri	ption	eter copy	eter clear	eter
Fun		Related parameters		ments	Value	3				enab disab	
	125	0	Terminal 2 frequency setting gain frequency	0.01Hz	50Hz	0 to 400Hz	Set the frequency of to (maximum).	erminal 2 input gain	0	×	0
ration)	126	0	Terminal 4 frequency setting gain frequency	0.01Hz	50Hz	0 to 400Hz	Set the frequency of to (maximum).	erminal 4 input gain	0	×	0
alib			Analog input			0	Displayed in %	Select the unit for			
cy, ency (c		241	display unit switchover	1	0	1	Displayed in V/mA	analog input display.	0	0	0
it frequenc		C2 (902)	Terminal 2 frequency setting bias frequency	0.01Hz	0Hz	0 to 400Hz	Set the frequency on the bias side of terminal 2 input.		0	×	0
nalog inpu ent input		C3 (902)	Terminal 2 frequency setting bias	0.1%	0%	0 to 300%	Set the converted % of the bias side voltage (current) of terminal 2 input.		0	×	0
Change of analog input frequency, voltage, current input and frequenc		C4 (903)	Terminal 2 frequency setting gain	0.1%	100%	0 to 300%	Set the converted % c voltage of terminal 2 in	•	0	×	0
Change of analog input frequency, adjustment of voltage, current input and frequency (calibration)		C5 (904)	Terminal 4 frequency setting bias frequency	0.01Hz	0Hz	0 to 400Hz	Set the frequency on the bias side of terminal 4 input.		0	×	0
adjustr		C6 (904)	Terminal 4 frequency setting bias	0.1%	20%	0 to 300%	Set the converted % c current (voltage) of ter		0	×	0
		C7 (905)	Terminal 4 frequency setting gain	0.1%	100%	0 to 300%	Set the converted % c current (voltage) of ter	rminal 4 input.	0	×	0

The parameter number in parentheses is the one for use with the parameter unit (FR-PU04/FR-PU07).



	Function	Parameter	Name	Incre	Initial	Range	Descri	intion	Param eter copy	Param eter clear	All param eter clear
	Fund	Related parameters	Name	ments	Value	Range	Descri	puon		enab disab	led
ľ			PID control automatic			0 to 400Hz	Set the frequency at value automatically change				
		127	switchover frequency	0.01Hz	9999	9999	Without PID automati function		0	0	0
						10	PID reverse action	Deviation value			
						11	PID forward action	signal (terminal 1)			
						20	PID reverse action	Measured value			
						21	PID forward action	input (terminal 4) Set value (terminal 2 or <i>Pr. 133</i>)			
		128	PID action selection	1	10	50	PID reverse action	Deviation value	0	0	0
						51	PID forward action	signal input (LONWORKS, CC- Link communication)			
						60	PID reverse action	Measured value,			
						61	PID forward action	set value input (LONWORKS, CC- Link communication)			
	PID control	129	PID proportional band	0.1%	100%	0.1 to 1000%	If the proportional bar (parameter setting is a manipulated variable slight change of the m Hence, as the proport the response sensitivi but the stability deterioccurs. Gain K = 1/proportion	small), the varies greatly with a neasured value. ional band narrows, ity (gain) improves orates, e.g. hunting	0	0	0
						9999	No proportional contro				
		130	PID integral time	0.1s	1s	0.1 to 3600s	Time required for only action to provide the svariable as that for the action. As the integral set point is reached e occurs more easily.	same manipulated e proportional (P) time decreases, the	0	0	0
						9999	No integral control.				
		131	PID upper limit	0.1%	9999	0 to 100%	Set the upper limit valu If the feedback value ex FUP signal is output. To (20mA/5V/10V) of the r (terminal 4) is equivaled	cceeds the setting, the he maximum input measured value	0	0	0
						9999	No function				
		132	PID lower limit	0.1%	9999	0 to 100%	Set the lower limit value If the measured value range, the FDN signal in The maximum input (20 measured value (terminum).	falls below the setting s output. DmA/5V/10V) of the	0	0	0
						9999	No function				
		133	PID action set point	0.01%	9999	0 to 100% 9999	Used to set the set po Terminal 2 input volta		0	0	0

Name	Ę	Param	neter						Param eter	Param eter	All param
134 PID differential time 0.01s 9999 0.01 to 10.00s 10.00s 2000 20 20 20 20 20 20	ctic		ted eters	Name			Range	Description			
Section to provide the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as the strict of the same manipulated variable as that for the proportional (P) Comparison of the same manipulated variable as the strict of the comparison of the same manipulated variable as the strict of the proportional (P) Comparison of the same manipulated variable as the strict of the proportional (P) Comparison of the same manipulated variable as the strict of the proportional (P) Comparison of the strict of the proportional (P) Comparison of the proportional (P) Comparison of the same manipulated variable as that or the proportional (P) Comparison of the same manipulated variable as the proportional (P) Comparison of the proportion of the proportio	Fun		Relat param		ments	value					
Start waiting time 0.1s 1s 0 to 3000s 10 to 3000		134		PID differential time	0.01s	9999	10.00s	action to provide the same manipulated variable as that for the proportional (P) action. As the differential time increases, greater response is made to a deviation change.	0	0	0
Section Sect	0.	Ī					9999				
136 Coutput interruption detection level 0.1Hz 0Hz 0Hz 0 to 400Hz Set the frequency at which the output interruption detection level 777 Output interruption 0.1% 1000% 900 to 1100% 500 to 100% 500 t	PID contr		575		0.1s	1s		remains lower than the <i>Pr. 576</i> setting for longer than the time set in <i>Pr. 575</i> , the inverter stops operation.	0	0	0
200 Output interruption Output interru				Output interruption			9999				
135 Electronic bypass sequence selection 1			576		0.01Hz	0Hz	0 to 400Hz	interruption processing is performed.	0	0	0
135 sequence selection 1 0 1 With electronic bypass sequence 0 0 0 0 0 0 0 0 0			577		0.1%	1000%	900 to 1100%	release the PID output interruption	0	0	0
Sequence selection 1 With electronic bypass sequence 1 With electronic bypass sequence 1 1 1 1 1 1 1 1 1		135			1	0	0	Without electronic bypass sequence	0	С)
136 interlock time 0.1s 1s 0 to 100s and MC3. Set the time slightly longer (0.3 to 0.5s or 0 to 100s soft that the time from when the ON signal enters MC3 until it actually turns on.		100		15	'	0	1	With electronic bypass sequence	Ŭ	Ŭ	
137 Start waiting time 0.1s 0.5s 0 to 100s so) than the time from when the ON signal enters MC3 until it actually turns on.		136			0.1s	1s	0 to 100s		0	0	0
STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop. STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop.	n to use	137		Start waiting time 0.1s 0.5s 0 to 100s so) than the time from when the ON signal enters MC3 until it actually turns on.		0	0	0			
STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop. STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to the inverter operation and the motor decelerates to stop.	eratio		Inverter output is stopped (motor coast) at								
STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop. STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to the inverter operation and the motor decelerates to stop.	er-supply op	138			1	0	1	bypass operation at inverter fault (Not switched when an external thermal error	0	0	0
STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop. STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to the inverter operation and the motor decelerates to stop.	l powe						0 to 60Hz				
STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop. STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to the inverter operation and the motor decelerates to stop.	commercia	139		frequency from inverter to bypass	0.01Hz	9999	9999	Without automatic switchover	0	0	0
STR) is turned off after operation is switched from inverter operation to bypass operation, operation and the motor decelerates to stop. STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to the inverter operation and the motor decelerates to stop.	between the inverter operation and			switchover frequency range from bypass to	0.01Hz	9999	0 to 10Hz	operation $(Pr.139 \neq 9999)$ When the frequency command decreases below $(Pr.139 \text{ to } Pr.159)$ after operation is switched from inverter operation to bypass operation, the inverter automatically switches operation to inverter operation and operates at the frequency of frequency command. When the inverter start command (STF/STR) is turned off, operation is switched to inverter operation also.	0	0	0
	Switch b			·			9999	operation ($Pr.139 \neq 9999$) When the inverter start command (STF/STR) is turned off after operation is switched from inverter operation to bypass operation, operation is switched to the inverter operation and the motor			
144 Refer to <i>Pr.37</i> .		140 to	143	Refer to Pr.29.							
	_	144		Refer to Pr.37.							



_	Paran	neter						Param	Param	All param
l ig		d	Name	Incre	Initial	Range	Description	eter copy	eter clear	eter
Function		Related parameters	Name	ments	Value	Ixalige	Description	0:	enab	
ш		pai						×:	disab	oled
_						0	Japanese			
Parameter unit language switchover						1	English			
ir ur			DLL diaplay			3	Germany French			
Parameter unit guage switchov	145		PU display language selection	1	1	4	Spanish	0	×	×
aran Jage			language selection			5	Italian			
P. Bugu						6	Swedish			
<u></u>						7	Finnish			
_	148,	149	Refer to Pr.22 and Pr.	23.						
	150		Output current detection level	0.1%	110%	0 to 120%	Set the output current detection level. 100% is the rated inverter current.	0	0	0
signal) gnal)	151		Output current detection signal delay time	0.1s	0s	0 to 10s	Set the output current detection period. Set the time from when the output current has risen above the setting until the output current detection signal (Y12) is output.	0	0	0
ent (Y12 s ht (Y13 si	152		Zero current detection level	0.1%	5%	0 to 150%	Set the zero current detection level. Suppose that the rated inverter current is 100%.	0	0	0
Detection of output current (Y12 signal) Detection of zero current (Y13 signal)	153		Zero current detection time	0.01s	0.5s	0 to 1s	Set this parameter to define the period from when the output current drops below the <i>Pr.152</i> value until the zero current detection signal (Y13) is output.	0	0	0
stection of etection o		166	Output current detection signal retention time	0.1s	0.1s	0 to 10s	Set the retention time when the Y12 signal is on. The Y12 signal on status is retained.	0	0	0
ă		167	Output current detection operation selection	1	0	0	The signal is turned off at the next start. Operation continues when the Y12 signal is on The inverter is brought to an alarm stop when the Y12 signal is on. (E.CDO)	0	0	0
_	154		Refer to Pr.22 and Pr.	23.						ı
n of action ns of the function	155		RT signal function	1	0	0	Second function is immediately made valid with on of the RT signal. Second function is valid only during the	0	0	0
Selection condition second f	155		validity condition selection	-	U	10	RT signal is on and constant speed operation. (Invalid during acceleration/deceleration)))	0
	156,	157	Refer to Pr.22 and Pr.	23.						
_	158		Refer to Pr.54 to Pr.56	5			· · · · · · · · · · · · · · · · · · ·			
	159		Refer to Pr.135 to Pr.	139.						
						9999	Only the simple mode parameters can be displayed.			
	160	0	User group read selection	1	9999	1	Only the parameters registered in the user group can be displayed.	0	0	0
olied d user on						0	Simple mode and extended mode parameters can be displayed.			
Display of applied parameters and user group function		172	User group registered display/	1	0	(0 to 16)	Displays the number of cases registered as a user group (reading only).	0	×	×
play nete			batch clear			9999	Batch clear the user group registration			
Dis _i parar gr		173	User group registration	1	9999	0 to 999, 9999	Set the parameter numbers to be registered to the user group. Read value is always "9999".	0	×	×
		174	User group clear	1	9999	0 to 999, 9999	Set the parameter numbers to be cleared from the user group. Read value is always "9999".	0	×	×

	Parameter							_	_	All
ion			Incre	Initial				Param	Param eter clear	param eter
Function	Related parameters	Name	ments	Value	Range	Descri	ption	copy	enab	clear
正	Re								disab	
					0	Setting dial frequency				
ctior						setting mode	Key lock mode invalid			
sele	404	Frequency setting/	_		1	Setting dial potentiometer mode	ilivaliu	_		_
Operation selection of the operation panel	161	key lock operation selection	1	0	10	Setting dial frequency		0	×	0
oera ne o						setting mode	Key lock mode valid			
of #					11	Setting dial potentiometer mode	valiu			
	162 to 165	Refer to Pr.57 and Pr.	58.			1-	l	1		l.
	166, 167	Refer to Pr.150 to Pr.	153.							
_	168, 169	Parameter for manuf	facturer	setting. I	Do not set.					
	170, 171	Refer to Pr.52.								
	172 to 174	Refer to Pr.160.								
					0 to 8, 10 to					
	178	STF terminal	1	60	14, 16, 24, 25, 37, 60,	0: Low-speed operat	ion command	0	×	0
		function selection			62, 64 to 67,	1: Middle-speed ope	ration command			
					9999 0 to 8, 10 to	2: High-speed opera3: Second function se				
		CTD to media al			14, 16, 24,	4: Terminal 4 input se				
	1/4	STR terminal function selection	1	61	25, 37, 61,	5: Jog operation sele6: Selection of autom		0	×	0
					62, 64 to 67, 9999	instantaneous pov				
	400	RL terminal function				7: External thermal re				
lal	180	selection	1	0		8: Fifteen speed sele 10: Inverter operation er		0	×	0
im:	181	RM terminal	1	1	0 to 8, 10 to 14, 16,	MT-HC, FR-CV con	nection)	0	×	0
ut te		function selection			24, 25, 37,	11: FR-HC, MT-HC co	nnection, ver failure detection			
finp	182	RH terminal function selection	1	2	62, 64 to 67, 9999	12: PU operation exte	rnal interlock	0	×	0
nt o	400	RT terminal function			3333	13: External DC inject 14: PID control valid to				
assignment of input terminal	183	selection	1	3		16: PU-external opera		0	×	0
ssign					0 to 8,	24: Output stop	-1			
	184	AU terminal	1	4	24, 25, 37,	25: Start self-holding s 37:Traverse function s		0	×	0
Function		function selection			62 to 67,	60: Forward rotation con	nmand (assigned to			
Fu		100 to			9999	STF terminal (<i>Pr.178</i> 61: Reverse rotation cor				
	185	JOG terminal function selection	1	5		STR terminal (Pr.179		0	×	0
	400	CS terminal			1	62: Inverter reset 63: PTC thermistor inp	out (aggigned to ALL	_		
	186	function selection	1	6	0 to 8,	terminal (<i>Pr.184</i>) o		0	×	0
	187	MRS terminal	1	24	10 to 14, 16, 24, 25, 37,	64: PID forward/revers		0	×	0
	ļ	function selection			62, 64 to 67,	65: PU-NET operation 66: External-NET operation				<u> </u>
	188	STOP terminal function selection	1	25	9999	67: Command source		0	×	0
	400	RES terminal			1	9999: No function				
	189	function selection	1	62				0	×	0



L.	Parameter						Param eter	Param eter	All param
Function	Related	Name	Incre ments	Initial Value	Range	Description	сору	clear	eter clear led
ш	R							disab	
	190	RUN terminal function selection	1	0	0 to 5, 7, 8, 10 to 19, 25,	0, 100: Inverter running 1, 101: Up to frequency 2, 102: Instantaneous power failure/ undervoltage 3, 103: Overload warning	0	×	0
	191	SU terminal function selection	1	1	26, 45 to 47, 64, 70 to 78 90 to 96, 98, 99,	4, 104: Output frequency detection 5, 105: Second output frequency detection 7, 107: Regenerative brake prealarm	0	×	0
	192	IPF terminal function selection	1	2	100 to 105, 107, 108, 110 to 116, 125, 126, 145 to 147,	(Only for the 01800 or more) 8, 108: Electronic thermal relay function prealarm 10, 110: PU operation mode 11, 111: Inverter operation ready	0	×	0
	193	OL terminal function selection	1	3	164, 170, 190 to 196, 198, 199, 9999	12, 112: Output current detection 13, 113: Zero current detection 14, 114: PID lower limit 15, 115: PID upper limit	0	×	0
	194	FU terminal function selection	1	4		16, 116: PID forward/reverse rotation output 17, —: Bypass operation switchover	0	×	0
output terminal	195	ABC1 terminal function selection	1	99		MC1 18, —: Bypass operation switchover MC2 19, —: Bypass operation switchover MC3 25, 125: Fan fault output 26, 126: Heatsink overheat pre-alarm 45, 145: Inverter running and start command is on 46, 146: During deceleration at	0	×	0
Terminal assignment of output terminal	196	ABC2 terminal function selection	1	9999	0 to 5, 7, 8, 10 to 19, 25, 26, 45 to 47, 64, 70 to 78, 90, 91, 94 to 96, 98, 99, 100 to 105, 107, 108, 110 to 116, 125, 126, 145 to 147, 164, 170, 190, 191, 194 to 196, 198, 199, 9999	occurrence of power failure (retained until release) 47, 147: During PID control activated 64, 164: During retry 70, 170: PID output interruption 71, —: Commercial-power supply side motor 1 connection RO1 72, —: Commercial-power supply side motor 2 connection RO2 73, —: Commercial-power supply side motor 3 connection RO3 74, —: Commercial-power supply side motor 4 connection RO4 75, —: Inverter side motor 1 connection RIO1 76, —: Inverter side motor 2 connection RIO2 77, —: Inverter side motor 3 connection RIO3 78, —: Inverter side motor 4 connection RIO4 90, 190: Life alarm 91, 191: Alarm output 3 (power-off signal) 92, 192: Energy saving average value updated timing 93, 193: Current average monitor signal 94, 194: Alarm output 2 95, 195: Maintenance timer signal 96, 196: Remote output 98, 198: Minor fault output 9999:No function 0 to 99: Positive logic, 100 to 199: Negative logic	0	×	0

_	Param	neter							Param	Param	All
Function		ed ters	Name	Incre	Initial	Range	Descri	ption	eter copy	eter clear	param eter clear
Fun		Related parameters		ments	Value	- tunge	2000	P		enab	
	232 to		Refer to Pr.4 to Pr.6.						×:	disab	olea
	240	200	Refer to <i>Pr.72</i> .								
_	241		Refer to Pr.125 and P	r.126.							
		243	Refer to Pr.73.								
Increase cooling fan life	244		Cooling fan operation selection	1	1	0	Operates at power on Cooling fan on/off con cooling fan is always o	trol invalid (The on at power on)	0	0	0
Incre						1	Cooling fan on/off con	trol valid			
	245		Rated slip	0.01%	9999	0 to 50%	Used to set the rated		0	0	0
			•			9999	No slip compensation Used to set the respon				
Slip compensation	246		Slip compensation time constant	0.01s	0.5s	0.01 to 10s	compensation. When smaller, response will as load inertia is great overvoltage (E.OV□) to occur.	the value is made be faster. However, ter, a regenerative error is more liable	0	0	0
Slip	247		Constant-power range slip compensation	1	9999	0	Slip compensation is a constant output range above the frequency s	(frequency range set in <i>Pr.3</i>)	0	0	0
			selection			9999	Slip compensation is r output range.	nade in the constant			
						0 to 100s	The motor is coasted to a stop when the preset time elapses after the start signal is turned off. When 1000s to	STF signal: Forward rotation start STR signal: Reverse rotation start			
of motor method	250		Ston coloction	0.1s	9999	1000 to 1100s	1100s is set (<i>Pr. 250</i> setting-1000)s later, the motor coasts to stop.	STF signal: Start signal STR signal: Forward/reverse signal	0	0	0
Selection stopping	230		Stop selection	0.15	9999	9999	When the start signal is turned off, the motor decelerates to	STF signal: Forward rotation start STR signal: Reverse rotation start		O	0
						8888	stop.	STF signal: Start signal STR signal: Forward/reverse signal			
ase	054		Output phase			0	Without output phase	failure protection		_	_
Input/output phase failure protection selection	251		failure protection selection	1	1	1	With output phase fail		0	0	0
outp re pr			Input phase failure			0	Without input phase fa	ailure protection			
Input/ failur s		872	protection selection	1	0	1	With input phase failu	re protection	0	0	0
_	252,	253	Refer to Pr.73.								



uc	Parameter						Param eter	Param eter	All param		
Function	Related parameters	Name	Incre ments	Initial Value	Range	Description	сору	clear	eter		
교	Rel							enab disab			
arts	255	Life alarm status display	1	0	(0 to 15)	Display whether the control circuit capacitor, main circuit capacitor, cooling fan, and each parts of the inrush current limit circuit has reached the life alarm output level or not.	×	×	×		
verter p	256	Inrush current limit circuit life display	1%	100%	(0 to 100%)	Display the deterioration degree of the inrush current limit circuit. Reading only	×	×	×		
e of the in	257	Control circuit capacitor life display	1%	100%	(0 to 100%)	Display the deterioration degree of the control circuit capacitor. Reading only	×	×	×		
Display of the life of the inverter parts	258	Main circuit capacitor life display	1%	100%	(0 to 100%)	Display the deterioration degree of the main circuit capacitor. Reading only The value measured by <i>Pr. 259</i> is displayed.	×	×	×		
Disp	259	Main circuit capacitor life measuring	1	0	0, 1	Start measuring the main circuit capacitor life. Switch the power supply on again and check the Pr. 259 setting. Measurement is complete if the setting is "3". Set the deterioration degree in $Pr.258$.	0	0	0		
_	260	Refer to Pr.72.									
	261 Power failure stop selection Power failure stop selection Power failure stop selection Coasting to stop When undervoltage or power failure occurs, the inverter output is shut off. When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.				0	When undervoltage or power failure occurs, the inverter output is shut off.					
φ		0	0	0							
power failur					2	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop. If power is restored during a power failure, the inverter accelerates again.					
at instantaneous power failure	262	Subtracted frequency at deceleration start	0.01Hz	3Hz	0 to 20Hz	Normally operation can be performed with the initial value unchanged. But adjust the frequency according to the magnitude of the load specifications (moment of inertia, torque).	0	0	0		
Decelerate the motor to a stop at	263	Subtraction starting frequency	0.01Hz	50Hz	0 to 120Hz	When output frequency $\geq Pr.263$ Decelerate from the speed obtained from output frequency minus $Pr.262$. When output frequency $< Pr.263$ Decelerate from output frequency Decelerate from the speed obtained from	0	0	0		
The m					9999	output frequency minus Pr.262.					
lerate t	264	Power-failure deceleration time 1	0.1/ 0.01s	5s	0 to 3600/ 360s	Set a deceleration slope down to the frequency set in <i>Pr.266</i> .	0	0	0		
Dece	265	Power-failure deceleration time 2	0.1/ 0.01s	9999	0 to 3600/ 360s 9999	Set a deceleration slope below the frequency set in <i>Pr.266</i> . Same slope as in <i>Pr.264</i>	0	0	0		
	266	Power failure deceleration time switchover frequency	0.01Hz	50Hz		Set the frequency at which the deceleration slope is switched from the $Pr.264$ setting to the $Pr.265$ setting.	0	0	0		
	267	Refer to Pr.73.									
	268	Refer to Pr.52.									
_	269	Parameter for manuf	acturer	setting. D	Do not set.						
299 Refer to <i>Pr.57</i> .											

_	Paran	neter						Param	Param	All param
Function		ed ters	Name	Incre	Initial	Range	Description	eter copy	eter clear	eter clear
Fun		Related parameters		ments	Value	90	2000		enab	
		d					Set the inverter station number.	×:	disab	iea
	331		RS-485 communication station number	1	0	0 to 31 (0 to 247)	(same specifications as <i>Pr.117</i>) When "1" (Modbus-RTU protocol) is set in <i>Pr.551</i> , the setting range within parenthesis is applied.	0	0	0
	332		RS-485 communication speed	1	96	3, 6, 12, 24, 48, 96, 192, 384	Used to select the communication speed. (same specifications as $Pr.118$)	0	0	0
	333		RS-485 communication stop bit length	1	1	0, 1, 10, 11	Select stop bit length and data length. (same specifications as $Pr.119$)	0	0	0
	334		RS-485 communication parity check selection	1	2	0, 1, 2	Select the parity check specifications. (same specifications as $Pr.120$)	0	0	0
	335		RS-485 communication retry count	1	1	0 to 10, 9999	Set the permissible number of retries at occurrence of a data receive error. (same specifications as <i>Pr.121</i>)	0	0	0
			RS-485 communication			0	RS-485 communication can be made, but the inverter will come to an alarm stop in the NET operation mode.			
	336		check time interval	0.1s	0s	0.1 to 999.8s	Set the communication check time interval. (same specifications as <i>Pr.122</i>)	0	0	0
						9999	No communication check			
	337		RS-485 communication waiting time setting	1	9999	0 to 150ms, 9999	Set the waiting time between data transmission to the inverter and response. (same specifications as <i>Pr.123</i>)	0	0	0
	338		Communication operation command	1	0	0	Operation command source communication	0	0	0
	330		source	'	O	1	Operation command source external)
						0	Speed command source communication			
cation	339	Communication speed command source	1	0	1	Speed command source external (Frequency setting from communication is invalid, terminal 2 and 1 setting from external is valid)	0	0	0	
U connector communication			command course			2	Speed command source external (Frequency setting from communication is valid, terminal 2 and 1 setting from external is invalid)			
ector c	341		RS-485 communication CR/LF selection	1	1	0, 1, 2	Select presence/absence of CR/LF. (same specifications as <i>Pr.124</i>)	0	0	0
J conn	342		Communication	1	0	0	Parameter values written by communication are written to the EEPROM and RAM.	0	0	0
PL			EEPROM write selection			1	Parameter values written by communication are written to the RAM.			
	343		Communication error count	1	0	(read only)	Display the number of communication errors during Modbus-RTU communication. Read only. Displayed only when Modbus-RTU protocol is selected.	×	×	×
			Modbus-RTU			0	Modbus-RTU communication can be made, but the inverter will come to an alarm stop in the NET operation mode.			
		539	communication check time interval	0.1s	9999	0.1 to 999.8s	Set the interval of communication check time. (same specifications as <i>Pr. 122</i>)	0	0	0
						9999	No communication check (signal loss detection) is made)			
						0	Mitsubishi inverter (computer link) protocol (switch power off, then on) the			
		549	Protocol selection	1	0	1	Modbus-RTU protocol Modbus-RTU protocol The setting change is reflected after a reset.	0	0	0
						0	Communication option valid			
			NET mode operation			1	Inverter RS-485 terminal valid			
		550	NET mode operation command source 1 9999 selection	9999	Automatic recognition of the communication option Normally, the RS-485 terminals are valid. Communication option is valid when the communication option is mounted.	0	0	0		
			PU mode operation			1	Select the RS-485 terminals as the PU operation mode control source.			
	551	command source selection	1	2	2	Select the PU connector as the PU operation mode control source.	0	0	0	



_	Parameter						Param	Param	All param
Function	ted	Name	Incre	Initial Value	Range	Description	eter copy	eter clear	eter clear
T T	Related parameters		ments	value			O: enabled ×: disabled		
_	340	Refer to Pr.79.					^ •	uisak	ieu
		Remote output			0	Remote output data clear at powering off			
utput on gnal)	495	selection	1	0	1	Remote output data retention even at powering off	0	0	0
Remote output function (REM signal)	496	Remote output data	1	0	0 to 4095	Output terminal can be switched on and off.	×	×	×
Re Re	497	Remote output data 2	1	0	0 to 4095	output terminal can be switched on and on.	×	×	×
Maintenance of parts	503	Maintenance timer	1	0	0 (1 to 9998)	Display the cumulative energization time of the inverter in 100h increments. Reading only Writing the setting of "0" clears the cumulative energization time.	×	×	×
intena	504	Maintenance timer alarm output set	1	9999	0 to 9998	Set the time taken until when the maintenance timer alarm output signal (Y95) is output.	0	×	0
Ma		time			9999	No function			
_	539, 549, 550	Refer to Pr.331 to Pr.3	Refer to Pr.331 to Pr.339, Pr.341 to Pr.343.						
	551	Refer to Pr.117 to Pr.1	24, Pr.3.	31 to Pr.3	39, Pr.341 to	Pr.343.			
alne	555	Current average time	0.1s	1s	0.1 to 1.0s	Set the time taken to average the current during start bit output (1s).	0	0	0
erage v	556	Data output mask time	0.1s	0s	0.0 to 20.0s	Set the time for not obtaining (mask) transient state data.	0	0	0
Current average value monitor signal	557	Current average value monitor signal output reference current	0.01/ 0.1A *15	Rated inverter current	0 to 500/ 0 to 3600A *15	Set the reference (100%) for outputting the signal of the current average value. *15 Setting increments and setting range differ according to the inverter capacity. (01160 or less/01800 or more)	0	0	0
_	563, 564	Refer to Pr.52.							
ating		Multiple netice			0	SLD: Ambient temperature 40°C, overload 110% 60s, 120% 3s			
Multiple rating selection	570	Multiple rating setting	1	0	1	LD: Ambient temperature 50°C, overload 120% 60s, 150% 3s	0	×	×
	571	Refer to Pr.13.			•				
_	573	Refer to Pr.73.							
	575 to 577	Refer to Pr.127 to Pr.	efer to Pr.127 to Pr.134.						

	Doromotor								All
Function	Parameter		Incre	Initial	Range	Description	Param eter copy	Param eter clear	param eter clear
Fun	Related parameters		ments	Value	l manigo			enab disab	
		A iliam . maatan			0	No auxiliary motor operation			
	578	Auxiliary motor operation selection	1	0	1 to 3	Set the number of auxiliary motors to be run	0	0	0
					0	Basic system			
	579	Motor connection	1	0	1	Alternative system	0	0	0
	319	function selection	'	U	2	Direct system		O	
					3	Alternative-direct system			
	580	MC switching interlock time	0.1s	1s	0 to 100s	You can set the MC switching interlock time when $Pr. 579 = ^{\circ}2, 3^{\circ}$.	0	0	0
	581	Start waiting time	0.1s	1s	0 to 100s	You can set the time from MC switch- over to a start when $Pr. 579 = ^{\circ}2, 3^{\circ}$. Set this time a little longer than the MC switching time.	0	0	0
	582	Auxiliary motor connection-time deceleration time	0.1s	1s	0 to 3600s	You can set the deceleration time for decreasing the output frequency of the inverter if a motor connection occurs under advanced PID control.	0	0	0
E E		deceleration time			9999	The output frequency is not forcibly changed.			
Pump function	583	Auxiliary motor disconnection-time	0.1s	1s	0 to 3600s	You can set the acceleration time for increasing the output frequency of the inverter if a motor disconnection occurs under advanced PID control.	0	0	0
		acceleration time			9999	The output frequency is not forcibly changed.			
	584	Auxiliary motor 1 starting frequency	0.01Hz	50Hz	0 to 400Hz		0	0	0
	585	Auxiliary motor 2 starting frequency	0.01Hz	50Hz	0 to 400Hz	Set the frequency to connect an auxiliary motor.	0	0	0
	586	Auxiliary motor 3 starting frequency	0.01Hz	50Hz	0 to 400Hz		0	0	0
	587	Auxiliary motor 1 stopping frequency	0.01Hz	0Hz	0 to 400Hz		0	0	0
	588	Auxiliary motor 2 stopping frequency	0.01Hz	0Hz	0 to 400Hz	Set the frequency to open an auxiliary motor.	0	0	0
	589	Auxiliary motor 3 stopping frequency	0.01Hz	0Hz	0 to 400Hz		0	0	0
	590	Auxiliary motor start detection time	0.1s	5s	0 to 3600s	You can set the delay time until the auxiliary motor is started.	0	0	0
	591	Auxiliary motor stop detection time	0.1s	5s	0 to 3600s	You can set the delay time until the auxiliary motor is stopped.	0	0	0



_	Parameter						Param	Param	All param
Function	ed iters	Name	Incre	Initial	Range	Description	eter copy	eter clear	eter
Fun	Related parameters		ments	Value	95		_	enab disab	
	0				0	Traverse function invalid	×:	uisau	nea
					0	Traverse function invalid Traverse function is valid only in the			
	592	Traverse function	1	0	1	external operation mode	0	0	0
		selection			2	Traverse function is valid independently			
					2	of operation mode			
_	593	Maximum amplitude amount	0.1%	10%	0 to 25%	Amplitude amount during traverse operation	0	0	0
Traverse function	594	Amplitude compensation amount during deceleration	0.1%	10%	0 to 50%	Compensation amount at the time of amplitude inversion (acceleration → deceleration)	0	0	0
Trav	595	Amplitude compensation amount during acceleration	0.1%	10%	0 to 50%	Compensation amount during amplitude inversion operation (deceleration → acceleration)	0	0	0
	596	Amplitude acceleration time	1s	5s	0.1 to 3600s	Acceleration time during traverse operation	0	0	0
	597	Amplitude deceleration time	1s	5s	0.1 to 3600s	Deceleration time during traverse operation	0	0	0
	611	Refer to Pr.57 and Pr.	58.						
_	867, 869	Refer to Pr.54 to Pr.56	efer to Pr.54 to Pr.56.						
	872	Refer to Pr.251.	fer to <i>Pr.251</i> .						
					0	Regeneration avoidance function invalid			
	882	Regeneration avoidance	1	0	1	Regeneration avoidance function is always valid	0	0	0
		operation selection			2	Regeneration avoidance function is valid only during a constant speed operation			
nce function	883	Regeneration avoidance operation level	0.1V	DC760V	300 to 800V	Set the bus voltage level at which regeneration avoidance operates. When the bus voltage level is set to low, overvoltage error will be less apt to occur. However, the actual deceleration time increases.	0	0	0
Regeneration avoidance function	884	Regeneration avoidance at deceleration detection sensitivity	1	0	0 to 5	Set sensitivity to detect the bus voltage change. 1 (Low) → 5 (High)	0	0	0
Regenel	885	Regeneration avoidance compensation	0.01Hz	6Hz	0 to 10Hz	Set the limit value of frequency which rises at activation of regeneration avoidance function.	0	0	0
		frequency limit value			9999	Frequency limit invalid			
	886	Regeneration avoidance voltage gain	0.1%	100%	0 to 200%	Adjust responsiveness at activation of regeneration avoidance. A larger setting will improve responsiveness to the bus voltage change. However, the output frequency could become unstable.	0	0	0
<u>.</u>	888	Free parameter 1	1	9999	0 to 9999	Parameters you can use for your own	0	×	×
Free	889	Free parameter 2	1	9999	0 to 9999	purposes. Used for maintenance, management, etc. by setting a unique number to each inverter when multiple inverters are used.	0	×	×

					-				
Function	Related Parameters	Name	Incre ments	Initial Value	Range	Description		Param eter clear enab disak	
	891	Refer to Pr.52.					•		
	892	Load factor	0.1%	100%	30 to 150%	Set the load factor for commercial power- supply operation. This value is used to calculate the power consumption estimated value during commercial power supply operation.	0	0	0
	893	Energy saving monitor reference (motor capacity)	0.01/ 0.1kW *16	LD/SLD value of Applied motor Capacity	0.1 to 55/ 0 to 3600kW *16	Set the motor capacity (pump capacity). Set when calculating power saving rate and average power saving rate value. *16 The setting depends on the inverter capacity (01160 or less/01800 or more)	0	0	0
		Control coloction			0	Discharge damper control (fan)			
		Control selection during commercial			1	Inlet damper control (fan)			
	894	power-supply	1	0	2	Valve control (pump)	0	0	0
itor		operation			3	Commercial power-supply drive (fixed value)			
Energy saving monitor	005	Power saving rate	_		0	Consider the value during commercial power-supply operation as 100%			
ving.	895	reference value	1	9999	1 Consider the <i>Pr.893</i> setting as 100%.	0	0	0	
/ sa					9999	No function	-		
Energ	896	Power unit cost	0.01	9999	0 to 500	Set the power unit cost. Display the power saving rate on the energy saving monitor	0	0	0
_					9999	No function			
		Power saving			0	Average for 30 minutes			
	897	monitor average	1	9999	1 to 1000h	Average for the set time	0	0	0
		time			9999	No function			
					0	Cumulative monitor value clear			
		Power saving			1	Cumulative monitor value hold			
	898	cumulative monitor	1	9999	10	Cumulative monitor continue (communication data upper limit 9999)	0	0	0
		ologi			9999	Cumulative monitor continue (communication data upper limit 65535)			
;	899	Operation time rate (estimated value)	0.1%	9999	0 to 100%	Use for calculation of annual power saving amount. Set the annual operation ratio (consider 365 days × 24hr as 100%).	0	0	0
					9999	No function			



uo	Parameter						Param eter	Param eter	All param	
Function	Related parameters	Name	Incre ments	Initial Value	Range	Description	сору	clear	eter	
Fu	Rel							enab disab		
nent of al CA AM ation)	C0 (900)	CA terminal calibration	_	-	_	Calibrate the scale of the meter connected to terminal CA.	0	×	0	
Adjustment of terminal CA and AM (calibration)	C1 (901)	AM terminal calibration	1	-	_	Calibrate the scale of the analog meter connected to terminal AM.	0	×	0	
	C2 (902)	Terminal 2 frequency setting bias frequency			,			•	•	
	C3 (902)	Terminal 2 frequency setting bias								
	C4 (903)	Terminal 2 frequency setting gain	Defende	efer to Pr 125 and Pr 126.						
	C5 (904)	Terminal 4 frequency setting bias frequency	Refer to	Pr.125 and	a Pr.126.					
	C6 (904)	Terminal 4 frequency setting bias								
	C7 (905)	Terminal 4 frequency setting gain								
rent	C8 (930)	Current output bias signal	0.1%	0%	0 to 100%	Set the output signal value at the minimum analog current output.		0	0	
Analog output current calibration	C9 (930)	Current output bias current	0.1%	0%	0 to 100%	Set the minimum current value at the minimum analog current output.		0	0	
log out calibr	C10 (931)	Current output gain signal	0.1%	100%	0 to 100%	Set the output signal value at the maximum analog current output.	0	0	0	
Ana	C11 (931)	Current output gain current	0.1%	100%	0 to 100%	Set the maximum current value at the maximum analog current output.	0	0	0	
_	989	Parameter copy alarm release	1	10/100 *17	10, 100	Parameters for alarm release at parameter copy *17 The setting depends on the inverter capacity (01160 or less/01800 or more)	0	×	0	
Buzzer control of the operation panel	990	PU buzzer control	1	1	1	Without buzzer With buzzer	0	0	0	
Contrast adjustment of the parameter unit	991	PU contrast adjustment	1	58	0 to 63	Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed. 0 (Light) → 63 (Dark)	0	0	0	
	Pr.CL	Parameter clear	1	0	0, 1	Setting "1" returns all parameters except constraints are parameters to the initial values.	alibrati	ion	1	
ar, oy	ALLC	All parameter clear	1	0	0, 1	Setting "1" returns all parameters to the ini				
Parameter clear, parameter copy	Er.CL	Alarm history clear	1	0	0, 1	Setting "1" will clear eight past alarms.				
nete nete					0	Cancel				
arar arar	DCDV	Darameter earl	4	•	1	Read the source parameters to the operation				
<u>q</u> q	PCPY	Parameter copy	1	0 2	2	Write the parameters copied to the operation destination inverter.	on pan	iei to th	ne	
					3	Verify parameters in the inverter and opera	ation pa	anel.		

The parameter number in parentheses is the one for use with the parameter unit (FR-PU04/FR-PU07).

5 TROUBLESHOOTING

When an alarm (major failures) occurs in the inverter, the protective function is activated bringing the inverter to an alarm stop and the PU display automatically changes to any of the following error (alarm) indications.

If your fault does not correspond to any of the following errors or if you have any other problem, please contact your sales representative.

- When the protective function is activated, take the corresponding corrective action, then reset the inverter, and resume operation.

Not doing so may lead to the inverter fault and damage.

Inverter alarm displays are roughly divided as below. (1) Error message

A message regarding operational fault and setting fault by the operation panel (FR-DU07) or parameter unit (FR-PU04/FR-PU07) is displayed. The inverter does not shut off output.

(2) Warnings

The inverter does not shut off output even when a warning is displayed. However, failure to take appropriate measures will lead to a major fault.

(3) Minor fault

The inverter output is not shut off. You can also output a minor fault signal by making parameter setting.

(4) Maijor fault

When the protective function is activated, the inverter output is shut off and an alarm is output.

5.1 Reset method of protective function

(1) Resetting the inverter

The inverter can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter. Recover about 1s after reset is cancelled.

Operation 1: Using the operation panel, press



to reset the inverter.


(Enabled only when the inverter protective function is activated (major fault) (Refer to *page 95* for major fault.))



Operation 2: Switch power off once, then switch it on again.



Operation 3: Turn on the reset signal (RES) for more than 0.1s. (If the RES signal is kept on, "Err." appears (flickers) to indicate that the inverter is in a reset status.)





5.2 List of alarm display

	Operation P	anel n	Name	Refer to
	E	E	Alarm history	103
Ф	HOLd	HOLD	Operation panel lock	91
Error message	Er 1 to Er4	Er1 to 4	Parameter write error	91
Error	- E to	rE1 to 4	Copy operation error	92
	Err.	Err.	Error	92
	0L	OL	Stall prevention (overcurrent)	93
	οL	oL	Stall prevention (overvoltage)	93
2	rЬ	RB	Regenerative brake prealarm	94
Warnings	ſΗ	TH	Electronic thermal relay function prealarm	94
Š	25	PS	PU stop	93
	ΠΓ	MT	Maintenance signal output	94
	[2	CP	Parameter copy	94
Minor fault	Fn	FN	Fan fault	95
	E.DC 1	E.OC1	Overcurrent shut-off during acceleration	95
	5.00.3	E.OC2	Overcurrent shut-off during constant speed	95
	E.003	E.OC3	Overcurrent shut-off during deceleration or stop	95
	E.O. 1	E.OV1	Regenerative overvoltage shut-off during acceleration	96
	E.Ou2	E.OV2	Regenerative overvoltage shut-off during constant speed	96
in	E.O u 3	E.OV3	Regenerative overvoltage shut- off during deceleration or stop	96
Major fault	E.F.H.F	E.THT	Inverter overload shut-off (electronic thermal relay function)	96
Me	E.C H.O	E.THM	Motor overload shut-off (electronic thermal relay function)	96
	E.F.L.n	E.FIN	Fin overheat	97
	EJ PF	E.IPF	Instantaneous power failure	97
	Е. ЬЕ	E.BE	Brake transistor alarm detection/internal circuit error	97
	E.U (E.UVT	Undervoltage	97
	ELLE	E.ILF*	Input phase failure	98
	E.DL F	E.OLT	Stall prevention	98

	Operation P Indicatio	anel n	Name	Refer to
	E. GF	E.GF	Output side earth fault overcurrent	98
	E. LF	E.LF	Output phase failure	98
	6.0HF	E.OHT	External thermal relay operation *2	98
	E.P.F.E	E.PTC*	PTC thermistor operation	98
	E.0PF	E.OPT	Option alarm	99
	E.0P 1	E.OP1	Communication option alarm	99
	€. 1	E. 1	Option alarm	99
	E. PE	E.PE	Parameter storage device alarm	99
	<i>E.PUE</i>	E.PUE	PU disconnection	99
	E E.F	E.RET	Retry count excess	100
fault	<i>E.P.E.2</i>	E.PE2*	Parameter storage device alarm	99
Major fault	E. 67 E. 77 E.CPU	E. 6 / E. 7 / E.CPU	CPU error	100
	E.C.F.E	E.CTE	Operation panel power supply short circuit, RS-485 terminal power supply short circuit	100
	E.P.24	E.P24	24VDC power output short circuit	100
	06 J.3	E.CDO*	Output current detection value exceeded	100
	EJ OH	E.IOH*	Inrush current limit circuit alarm	100
	8.58 r	E.SER*	Communication error (inverter)	101
	E.RT E	E.AIE*	Analog input error	101
	E. 13	E.13	Internal circuit error	101

^{*} If an error occurs when using the FR-PU04/FR-PU07, "Fault 14" is displayed on the FR-PU04/FR-PU07.

5.3 Causes and corrective actions

(1) Error Message

A message regarding operational troubles is displayed. Output is not shut off.

Operation Panel Indication	HOLD	HOLD HOLD						
Name	Operation par	peration panel lock						
Description	Operation loc	Operation lock mode is set. Operation other than (STOP) is made invalid. (Refer to page 30.)						
Check point								
Corrective action	tive action Press MODE for 2s to release lock.							

Operation Panel Indication	Er1	Er I		
Name	Write disable error			
Description	 You attempted to make parameter setting when <i>Pr. 77 Parameter write selection</i> has been set to disable parameter write. Frequency jump setting range overlapped. Adjustable 5 points V/F settings overlapped The PU and inverter cannot make normal communication 			
Check point	 1. Check the setting of Pr. 77 Parameter write selection (Refer to Instruction Manual (applied).) 2. Check the settings of Pr. 31 to 36 (frequency jump). (Refer to Instruction Manual (applied).) 3. Check the settings of Pr. 100 to Pr. 109 (Adjustable 5 points V/F). (Refer to Instruction Manual (applied).) 4. Check the connection of the PU and inverter. 			

Operation Panel Indication	Er2	Er2				
Name	Write error du	ring operation				
Description		When parameter write was performed during operation with a value other than "2" (writing is enabled independently of operating status in any operation mode) is set in <i>Pr. 77</i> and the STF (STR) is on.				
Check point	1. Check the <i>Pr. 77</i> setting. (<i>Refer to Instruction Manual (applied).</i>) 2. Check that the inverter is not operating.					
Corrective action		1. Set "2" in <i>Pr. 77</i> . 2. After stopping operation, make parameter setting.				

Operation Panel Indication	Er3 & - 3			
Name	Calibration en	Calibration error		
Description	Analog input bias and gain calibration values are too close.			
Check point	Check the setti	Check the settings of C3, C4, C6 and C7 (calibration functions). (Refer to 🕮 Instruction Manual (applied).)		

Operation Panel Indication	Er4	Er4			
Name	Mode designa	tion error			
Description	You attempted	You attempted to make parameter setting in the NET operation mode when Pr. 77 is not "2".			
Check point	1. Check that operation mode is "PU operation mode".				
2. Check the <i>Pr. 77</i> setting. (<i>Refer to</i> Instruction Manual (applied).)					
	1. After setting the operation mode to the "PU operation mode", make parameter setting. (Refer to page				
Corrective action	57.)				
	2. After setting "2" in <i>Pr. 77</i> , make parameter setting.				

Operation Panel Indication	rE1	rE I			
Name	Parameter rea	Parameter read error			
Description	An error occurred in the EEPROM on the operation panel side during parameter copy reading.				
Check point					
Corrective action		parameter copy again. (Refer to page 59.) c for an operation panel (FR-DU07) failure. Please contact your sales representative.			



Operation Panel Indication	rE2	- E C					
Name	Parameter wr	Parameter write error					
Description		You attempted to perform parameter copy write during operation. An error occurred in the EEPROM on the operation panel side during parameter copy writing.					
Check point	Is the FWD or REV LED of the operation panel (FR-DU07) lit or flickering?						
Corrective action	 After stopping operation, make parameter copy again. (Refer to page 59.) Check for an operation panel (FR-DU07) failure. Please contact your sales representative. 						

Operation Panel Indication	rE3	r E 3				
Name	Parameter ve	Parameter verification error				
Description	Data on the operation panel side and inverter side are different. An error occurred in the EEPROM on the operation panel side during parameter verification.					
Check point	Check for the parameter setting of the source inverter and inverter to be verified.					
Corrective action	1. Press (SET) to continue verification. Make parameter verification again. (Refer to page 60.) 2. Check for an operation panel (FR-DU07) failure. Please contact your sales representative.					

Operation Panel Indication	rE4	rE4 - E4				
Name	Model error	Model error				
Description		A different model was used for parameter write and verification during parameter copy. When parameter copy write is stopped after parameter copy read is stopped				
Check point	2. Check that	Check that the verified inverter is the same model. Check that the power is not turned off or an operation panel is not disconnected, etc. during parameter copy read.				
Corrective action		Use the same model (FR-F700 series) for parameter copy and verification. Perform parameter copy read again.				

Operation Panel Indication	Err.	Err. Err.			
Description	1. The RES signal is on 2. The PU and inverter cannot make normal communication (contact fault of the connector) 3. When the control circuit power (R1/L11, S1/L21) and the main circuit power(R/L1, S/L2, T/L3) are connected to a separate power, it may appear at turning on of the main circuit. It is not a fault.				
Corrective action	Turn off the RES signal. Check the connection of the PU and inverter.				

(2) Warnings

When the protective function is activated, the output is not shut off.

Operation Panel	OL	0L	FR-PU04 FR-PU07	OL		
Indication	Ctall proventia					
Name	Stall prevention	evention (overcurrent)				
	During acceleration	22 Stall prevention operate the overload current de shut-off. When the overload currefunction increases the f	tion level, etc.), to creases to prevent has decreased requency again			
Description	During constant- speed operation	When the output current of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function lowers the frequency until the overload current decreases to prevent overcurrent shut-off. When the overload current has decreased below stall prevention operation level, this function increases the frequency up to the set value.				
	During deceleration	When the output current of the inverter exceeds the stall prevention operation level (<i>Pr. 22 Stall prevention operation level</i> , etc.), this function stops the decrease in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent shut-off. When the overload current has decreased below stall prevention operation level, this function decreases the frequency again.				
Check point	1. Check that the <i>Pr. 0 Torque boost</i> setting is not too large. 2. Check that the <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i> settings are not too small. 3. Check that the load is not too heavy. 4. Are there any failure in peripheral devices? 5. Check that the <i>Pr. 13 Starting frequency</i> is not too large. · Check the motor for use under overload.					
Corrective action	 Increase or decrease the <i>Pr. 0 Torque boost</i> value 1% by 1% and check the motor status. (<i>Refer to page 51.</i>) Set a larger value in <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i>. (<i>Refer to page 54.</i>) Reduce the load weight. Try simple magnetic flux vector control (<i>Pr. 80</i>). Change the <i>Pr. 14 Load pattern selection</i> setting. Set stall prevention operation current in <i>Pr. 22 Stall prevention operation level</i>. (The initial value is 110% °1.) The acceleration/deceleration time may change. Increase the stall prevention operation level with <i>Pr. 22 Stall prevention operation level</i>, or disable stall prevention with <i>Pr. 156 Stall prevention operation selection</i>. (Use <i>Pr. 156</i> to set either operation continued or not at OL operation.) 					

^{120%} when LD is selected

Operation Panel Indication	oL	οL	FR-PU04 FR-PU07	oL
Name	Stall prevention	n (overcurrent)		
Description	During deceleration	If the regenerative energy of the motor becomes excessive and exceeds the regenerative energy consumption capability, this function stops the decrease in frequency to prevent overvoltage shut-off. As soon as the regenerative energy has decreased, deceleration resumes. If the regenerative energy of the motor becomes excessive when regeneration avoidance function is selected (<i>Pr.</i> 882 = 1), this function increases the speed to prevent overvoltage shut-off. (<i>Refer to Instruction Manual (applied)</i> .)		
Check point	 Check for sudden speed reduction. Regeneration avoidance function (Pr. 882 to Pr. 886) is being used? (Refer to Instruction Manual (applied).) 			
Corrective action	The deceleration time may change. Increase the deceleration time using <i>Pr. 8 Deceleration time</i> .			

Operation Panel Indication	PS	PS	FR-PU04 FR-PU07	PS
Name	PU stop			
Description	Stop with RESE of the PU is set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection</i> . (For <i>Pr. 75</i> , refer to Instruction Manual (applied).)			
Check point	Check for a stop made by pressing STOP of the operation panel.			
Corrective action	Turn the start signal off and release with $\frac{PU}{EXT}$.			



Operation Panel Indication	RB	-6	FR-PU04 FR-PU07	RB	
Name	Regenerative	brake prealarm			
Description	Appears if the regenerative brake duty reaches or exceeds 85% of the <i>Pr. 70 Special regenerative brake duty</i> value. If the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs. The RBP signal can be simultaneously output with the [RB] display. For the terminal used for the RBP signal output, assign the function by setting "7" (positive logic) or "107" (negative logic) in any of <i>Pr. 190 to Pr. 196 (output terminal function selection). (Refer to Instruction Manual (applied))</i> Appears only for the 01800 or more.				
Check point	 Check that the brake resistor duty is not high. Check that the <i>Pr. 30 Regenerative function selection</i> and <i>Pr. 70 Special regenerative brake duty</i> values are correct. 				
Corrective action		deceleration time. r. 30 Regenerative function	n selection and P.	r. 70 Special regenerative brake duty values.	

Operation Panel Indication	тн	ſH	FR-PU04 FR-PU07	тн		
Name	Electronic the	rmal relay function pre	alarm			
Description	preset level. If (E. THM) occu The THP sign signal output,	Appears if the cumulative value of the <i>Pr. 9 Electronic thermal O/L relay</i> reaches or exceeds 85% of the preset level. If it reaches 100% of the <i>Pr. 9 Electronic thermal O/L relay</i> setting, a motor overload shut-off (E. THM) occurs. The THP signal can be simultaneously output with the [TH] display. For the terminal used for the THP signal output, assign the function by setting "8" (positive logic) or "108" (negative logic) in any of <i>Pr. 190 to Pr. 196 (output terminal function selection). (Refer to Image) Instruction Manual (applied)</i>				
Check point	 Check for large load or sudden acceleration. Is the <i>Pr. 9 Electronic thermal O/L relay</i> setting is appropriate? (<i>Refer to page 33.</i>) 					
Corrective action		load weight or the nutopriate value in Pr. 9 I		times. //L relay. (Refer to page 33.)		

Operation Panel	мт	n r	FR-PU04				
Indication	141.1	111	FR-PU07	MT			
Name	Maintenance	Maintenance signal output					
Description	Indicates that	Indicates that the cumulative energization time of the inverter has reached a given time.					
Check point	The Pr. 503 M	The Pr. 503 Maintenance timer setting is larger than the Pr. 504 Maintenance timer alarm output set time					
Check point	setting. (Refer to Instruction Manual (applied).)						
Corrective action	Setting "0" in	Setting "0" in Pr. 503 Maintenance timer erraces the signal.					

Operation Panel	СР	59	FR-PU04			
Indication		<u>_</u> '	FR-PU07	CP		
Name	Parameter co	Parameter copy				
Description	Appears wher more.	Appears when parameters are copied between models with capacities of 01160 or less and 01800 or more.				
Check point	Resetting of <i>Pr.9</i> , <i>Pr.30</i> , <i>Pr.51</i> , <i>Pr.52</i> , <i>Pr.54</i> , <i>Pr.56</i> , <i>Pr.57</i> , <i>Pr.70</i> , <i>Pr.72</i> , <i>Pr.80</i> , <i>Pr.90</i> , <i>Pr.158</i> , <i>Pr.190</i> to <i>Pr.196</i> , and <i>Pr.893</i> is necessary.					
Corrective action	Set the initial	value in <i>Pr. 989 Paramete</i>	er copy alarm rele	ase.		

(3) Minor fault

When the protective function is activated, the output is not shut off. You can also output a minor fault signal by making parameter setting. (Set "98" in any of Pr. 190 to Pr. 196 (output terminal function selection). (Refer to Instruction Manual (applied).))

Operation Panel Indication	FN	Fn	FR-PU04 FR-PU07	FN		
Name	Fan fault	Fan fault				
Description	For the inverter that contains a cooling fan, F_{\Box} appears on the operation panel when the cooling fan stops due to a fault or different operation from the setting of <i>Pr. 244 Cooling fan operation selection</i> .					
Check point	Check the cooling fan for a fault.					
Corrective action	Check for fan fault. Please contact your sales representative.					

(4) Major fault

When the protective function is activated, the inverter output is shut off and an alarm is output.

Operation Panel Indication	E.OC1	E.D.C 1	FR-PU04 FR-PU07	OC During Accs	
Name	Overcurrent s	hut-off during acceleration	on		
Description	When the inverter output current reaches or exceeds approximately 170% of the rated current during acceleration, the protective circuit is activated to stop the inverter output.				
Check point	 1. Check for sudden acceleration. 2. Check that the downward acceleration time is not long in vertical lift application. 3. Check for output short circuit. 4. Check that stall prevention operation is correct. 5. Check that the regeneration is not performed frequently. (Check that the output voltage becomes larger than the V/F reference voltage at regeneration and overcurrent due to increase in motor current occurs.) 				
Corrective action	1. Increase the acceleration time. (Shorten the downward acceleration time in vertical lift application.) 2. When "E.OC1" is always lit at starting, disconnect the motor once and start the inverter. If "E.OC1" is still lit, contact your sales representative. 3. Check the wiring to make sure that output short circuit does not occur. 4. Perform a correct stall prevention operation. (Refer to Instruction Manual (applied).) 5. Set base voltage (rated voltage of the motor, etc.) in Pr. 19 Base frequency voltage. (Refer to Instruction Manual (applied).)				

Operation Panel Indication	E.OC2	8.002	FR-PU04 FR-PU07	Stedy Spd OC			
Name	Overcurrent s	hut-off during constant s	speed				
Description		When the inverter output current reaches or exceeds approximately 170% of the rated current during constant speed operation, the protective circuit is activated to stop the inverter output.					
Check point	2. Check for o	Check for sudden load change. Check for output short circuit. Check that stall prevention operation is correct.					
Corrective action	2. Check the v	 Keep load stable. Check the wiring to avoid output short circuit. Check that stall prevention operation setting is correct. (Refer to Instruction Manual (applied).) 					

Operation Panel Indication	E.OC3	8.003	FR-PU04 FR-PU07	OC During Dec		
Name	Overcurrent s	hut-off during decelerat	ion or stop			
Description	When the inverter output current reaches or exceeds approximately 170% of the rated inverter current during deceleration (other than acceleration or constant speed), the protective circuit is activated to stop the inverter output.					
Check point	Check for sudden speed reduction. Check for output short circuit. Check for too fast operation of the motor's mechanical brake. Check that stall prevention operation setting is correct.					
Corrective action	 Increase the deceleration time. Check the wiring to avoid output short circuit. Check the mechanical brake operation. Check that stall prevention operation setting is correct. (Refer to Instruction Manual (applied).) 					



Operation Panel Indication	E.OV1	E.D.,	1	FR-PU04 FR-PU07	OV During Acc	
Name	Regenerative	Regenerative overvoltage shut-off during acceleration				
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.					
Check point	Check for too slow acceleration. (e.g. during descending acceleration with lifting load)					
Corrective action Decrease the acceleration time.						
	· Use regeneration avoidance function (Pr. 882 to Pr. 886). (Refer to 🚉 Instruction Manual (applied).)					

Operation Panel Indication	E.OV2	8.052	FR-PU04 FR-PU07	Stedy Spd OV	
Name		overvoltage shut-off during			
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.				
Check point	Check for sudden load change.				
Corrective action	 Keep load stable. Use regeneration avoidance function (Pr. 882 to Pr. 886). (Refer to Instruction Manual (applied).) Use the brake unit or power regeneration common converter (FR-CV) as required. 				

Operation Panel Indication	E.OV3	E.O u 3	FR-PU04 FR-PU07	OV During Dec	
Name	Regenerative	overvoltage shut-off dur	ing deceleration	or stop	
Description	If regenerative energy causes the inverter's internal main circuit DC voltage to reach or exceed the specified value, the protective circuit is activated to stop the inverter output. The circuit may also be activated by a surge voltage produced in the power supply system.				
Check point	Check for sudden speed reduction.				
Corrective action	 Increase the deceleration time. (Set the deceleration time which matches the moment of inertia of the load) Decrease the braking duty. Use regeneration avoidance function (Pr. 882 to Pr. 886). (Refer to Instruction Manual (applied).) Use the brake unit or power regeneration common converter (FR-CV) as required. 				

Operation Panel Indication	E.THT	E.F.H.F	FR-PU04 FR-PU07	Inv. Overload	
Name	Inverter overload shut-off (electronic thermal relay function) *3				
Description	If a current not less than 110%-2 of the rated output current flows and overcurrent shut-off does not occur (170% or less), inverse-time characteristics cause the electronic thermal relay to be activated to stop the inverter output in order to protect the output transistors. (overload immunity 110%-2 60s)				
Check point	Check the motor for use under overload.				
Corrective action	Reduce the load weight.				

^{*2 120%} when LD is selected

Operation Panel Indication	E.THM	E.C H.O	FR-PU04 FR-PU07	Motor Overload		
Name	Motor overloa	d shut-off (electronic the	rmal relay funct	ion) *3		
Description	The electronic thermal relay function in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation and pre-alarm (TH display) is output when the temperature reaches 85% of the <i>Pr. 9 Electronic thermal O/L relay</i> setting and the protection circuit is activated to stop the inverter output when the temperature reaches the specified value. When running a special motor such as a multi-pole motor or multiple motors, provide a thermal relay on the inverter output side since such motor(s) cannot be protected by the electronic thermal relay function.					
Check point	 Check the motor for use under overload. Check that the setting of <i>Pr. 71 Applied motor</i> for motor selection is correct. (<i>Refer to Manual (applied).</i>) Check that stall prevention operation setting is correct. 					
Corrective action		ant-torque motor, set the		e motor in Pr. 71 Applied motor. ect. (Refer to 🚅 Instruction Manual (applied).)		

^{*3} Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.



Operation Panel Indication	E.FIN	E.F.I. n	FR-PU04 FR-PU07	H/Sink O/Temp		
Name	Fin overheat					
Description	If the heatsink overheats, the temperature sensor is actuated to stop the inverter output. The FIN signal can be output when the temperature becomes approximately 85% of the heatsink overheat protection operation temperature. For the terminal used for the FIN signal output, assign the function by setting "26" (positive logic) or "126" (negative logic) in any of <i>Pr. 190 to Pr. 196 (output terminal function selection). (Refer to Instruction Manual (applied))</i>					
Check point	Check for too high ambient temperature. Check for heatsink clogging.					
	3. Check that the cooling fan is stopped. (Check that \digamma_{n} is displayed on the operation panel.)					
Corrective action	1. Set the amb 2. Clean the h 3. Replace the		hin the specificat	ions.		

Operation Panel Indication	E.IPF	E.I PF		FR-PU04 FR-PU07	Inst. Pwr. Loss	
Name	Instantaneous	s power failure				
Description	If a power failure occurs for longer than 15ms (this also applies to inverter input shut-off), the instantaneous power failure protective function is activated to stop the inverter output in order to prevent the control circuit from malfunctioning. If a power failure persists for longer than 100ms, the alarm warning output is not provided, and the inverter restarts if the start signal is on upon power restoration. (The inverter continues operating if an instantaneous power failure is within 15ms.) In some operating status (load magnitude, acceleration/deceleration time setting, etc.), overcurrent or other protection may be activated upon power restoration. When instantaneous power failure protection is activated, the IPF signal is output. (Refer to Instruction Manual (applied))					
Check point	Find the cause of instantaneous power failure occurrence.					
Corrective action	Prepare a bSet the fund	e instantaneous po backup power sup- ction of automatic Manual (applied).)	oly for insta	antaneous p	power failure. Beous power failure (<i>Pr. 57</i>). (<i>Refer to</i>	

Operation Panel Indication	E.BE	Ε.	<i>68</i>	FR-PU04 FR-PU07	Br. Cct. Fault
Name	Brake transisto	r alarm de	tection/internal	circuit error	
Description	This function stops the inverter output if an alarm occurs in the brake circuit, e.g. damaged brake transistors when using functions of the 01800 or more. In this case, the inverter must be powered off immediately. For the 01160 or less, it appears when an internal circuit error occurred.				
Check point	Reduce the load inertia. Check that the frequency of using the brake is proper. Check that the brake resistor selected is correct.				
Corrective action	For the 01800 or more, when the protective function is activated even if the above measures are taken, replace the brake unit with a new one. For the 01160 or less, replace the inverter.				activated even if the above measures are taken,

Operation Panel Indication	E.UVT	E.U., [FR-PU04 FR-PU07	Under Voltage		
Name	Undervoltage					
Description	If the power supply voltage of the inverter reduces, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage reduces below about 300VAC, this function stops the inverter output. When a jumper is not connected across P/+-P1, the undervoltage protective function is activated. When undervoltage protection is activated, the IPF signal is output. (Refer to Instruction Manual (applied))					
Check point	Check for start of large-capacity motor. Check that a jumper or DC reactor is connected across terminals P/+-P1.					
Corrective action	1. Check the power supply system equipment such as the power supply. 2. Connect a jumper or DC reactor across terminals P/+-P1. 3. If the problem still persists after taking the above measure, please contact your sales representative.					



Operation Panel	E.ILF	ELLF	FR-PU04	Fault 14		
Indication	E.ILF		FR-PU07	Input phase loss		
Name	Input phase failure					
Description	This alarm is output when function valid setting (=1) is set in <i>Pr. 872 Input phase failure protection selection</i> and one phase of the three phase power input opens. (<i>Refer to</i> Instruction Manual (applied).)					
Check point	Check for a break in the cable for the three-phase power supply input.					
Corrective action	· Repair a bra	bles properly. ake portion in the cable. Pr. 872 Input phase failure		ion setting.		

Operation Panel Indication	E.OLT	E.DL	FR-PU04 FR-PU07	Stll Prev STP (OL shown during stall prevention operation)	
Name	Stall prevention				
Description	If the frequency has fallen to 0.5Hz by stall prevention operation and remains for 3s, an alarm (E.OLT) appears to shutoff the inverter output. OL appears while stall prevention is being activated.				
Check point	· Check the motor for use under overload. (Refer to 📖 Instruction Manual (applied).)				
Corrective action	· Reduce the load weight.				

Operation Panel Indication	E.GF	Ε.	GF	FR-PU04 FR-PU07	Ground Fault		
Name	Output side ea	Output side earth fault overcurrent					
Description		This function stops the inverter output if an earth fault overcurrent flows due to an earth fault that occurred on the inverter's output (load) side.					
Check point	Check for an earth fault in the motor and connection cable.						
Corrective action	Remedy the earth fault portion.						

Operation Panel	E.LF	E. LF	FR-PU04		
Indication	L.L.		FR-PU07	E. LF	
Name	Output phase failure				
Description	This function stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) opens.				
Check point	Check the wiring (Check that the motor is normal.) Check that the capacity of the motor used is not smaller than that of the inverter.				
Corrective action	 Wire the cables properly. Check the <i>Pr. 251 Output phase failure protection selection setting</i>. 				

Operation Panel Indication	E.OHT	E.0HF	FR-PU04	OH Fault		
Name	External thermal relay operation ·4					
Description	If the external thermal relay provided for motor overheat protection, or the internally mounted temperature relay in the motor, etc. switches on (contacts open), the inverter output is stopped.					
Check point	 Check for motor overheating. Check that the value of 7 (OH signal) is set correctly in any of <i>Pr. 178 to Pr. 189 (input terminal function selection)</i>. 					
Corrective action	Reduce the load and operating duty. Even if the relay contacts are reset automatically, the inverter will not restart unless it is reset.					

^{*4} Functions only when any of *Pr. 178 to Pr. 189 (input terminal function selection)* is set to OH.

Operation Panel Indication	E.PTC	E.P.F.C	FR-PU04 FR-PU07	Fault 14 PTC activated		
Name	PTC thermisto	or operation				
Description		Appears when the motor overheat status is detected for 10s or more by the external PTC thermistor input connected to the terminal AU.				
Check point	Check the rIs valid sett	 Check the connection between the PTC thermistor switch and thermal relay protector. Check the motor for operation under overload. Is valid setting (= 63) selected in <i>Pr. 184 AU terminal function selection</i>? (<i>Refer to Instruction Manual (applied)</i>.) 				
Corrective action	Reduce the load weight.					

Operation Panel Indication	E.OPT	E.DPT	FR-PU04 FR-PU07	Option Fault			
Name	Option alarm	Option alarm					
Description		Appears when the AC power supply is connected to the terminal R/L1, S/L2, T/L3 accidentally when a high power factor converter is connected.					
Check point		· Check that the AC power supply is not connected to the terminal R/L1, S/L2, T/L3 when a high power factor converter (FR-HC, MT-HC) or power regeneration common converter (FR-CV) is connected.					
Corrective action	The inverter		AC power supp	oly is connected to the terminal R/L1, S/L2, T/L3			

Operation Panel Indication	E.OP1	E.DP 1	FR-PU04 FR-PU07	Option slot alarm 1		
Name	Communication	on option alarm				
Description	Stops the inve	rter output when a comr	nunication line e	error occurs in the communication option.		
Check point	Check for a wrong option function setting and operation. Check that the plug-in option is plugged into the connector securely. Check for a brake in the communication cable. Check that the terminating resistor is fitted properly.					
Corrective action	Check the option function setting, etc. Connect the plug-in option securely. Check the connection of communication cable.					

Operation Panel Indication	E. 1	ε.	1	FR-PU04 FR-PU07	Fault 1		
Name	Option alarm						
Description	communicatio	Stops the inverter output if a contact fault or the like of the connector between the inverter and communication option occurs.					
Check point		Check that the plug-in option is plugged into the connector securely. Check for excess electrical noises around the inverter.					
Corrective action	Connect the plug-in option securely. Take measures against noises if there are devices producing excess electrical noises around the inverter. If the problem still persists after taking the above measure, please contact your sales representative or distributor.						

Operation Panel Indication	E.PE	Ε.	PE	FR-PU04 FR-PU07	Corrupt Memry		
Name	Parameter sto	Parameter storage device alarm (control circuit board)					
Description	A fault occurre	A fault occurred in parameters stored (EEPROM failure)					
Check point	Check for too	Check for too many number of parameter write times.					
Corrective action	When perform	Please contact your sales representative. When performing parameter write frequently for communication purposes, set "1" in <i>Pr. 342</i> to enable RAM write. Note that powering off returns the inverter to the status before RAM write.					

Operation Panel	E.PE2	6.28	FR-PU04	Fault 14			
Indication	E.PEZ		FR-PU07	PR storage alarm			
Name	Parameter sto	Parameter storage device alarm (main circuit board)					
Description	A fault occurre	A fault occurred in parameters stored (EEPROM failure)					
Check point							
Corrective action	Please contac	t your sales representat	ive.				

Operation Panel Indication	E.PUE	E.PUE	FR-PU04 FR-PU07	PU Leave Out		
Name	PU disconnec	tion				
Description	This function stops the inverter output if communication between the inverter and PU is suspended, e.g. the operation panel and parameter unit is disconnected, when "2", "3", "16" or "17" was set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection.</i> This function stops the inverter output when communication errors occurred consecutively for more than permissible number of retries when a value other than "9999" is set in <i>Pr. 121 Number of PU communication retries</i> during the RS-485 communication with the PU connector. This function also stops the inverter output if communication is broken for the period of time set in <i>Pr. 122 PU communication check time interval</i> .					
Check point	Check that the FR-DU07 or parameter unit (FR-PU04/FR-PU07) is fitted tightly. Check the <i>Pr. 75</i> setting.					
Corrective action	Fit the FR-DU	07 or parameter unit (FF	R-PU04/FR-PU0	17) securely.		



Operation Panel Indication	E.RET	E E	FR-PU04 FR-PU07	Retry No Over			
Name	Retry count ex	Retry count excess					
Description	If operation ca output.	If operation cannot be resumed properly within the number of retries set, this function stops the inverter output.					
Check point	Find the cause of alarm occurrence.						
Corrective action	Eliminate the cause of the error preceding this error indication.						

	E. 6	Ε.	8		Fault 6	
Operation Panel Indication	E. 7	E.	7	FR-PU04 FR-PU07	Fault 7	
	E.CPU	E.C	ԲԱ		CPU Fault	
Name	CPU error					
Description	Stops the inverter output if the communication error of the built-in CPU occurs.					
Check point	Check for devices producing excess electrical noises around the inverter.					
Corrective action	 Take measures against noises if there are devices producing excess electrical noises around the inverter. Please contact your sales representative. 					

Operation Panel Indication	E.CTE	8.078	FR-PU04 FR-PU07	E.CTE		
Name	Operation par	el power supply short c	ircuit, RS-485 te	rminal power supply short circuit		
Description	output. At this from the PU countries function so At this time, countries and the state of the s	When the operation panel power supply (PU connector) is shorted, this function shuts off the power output. At this time, the operation panel (parameter unit) cannot be used and RS-485 communication from the PU connector cannot be made. When the power supply for the RS-485 terminals are shorted, this function shuts off the power output. At this time, communication from the RS-485 terminals cannot be made. To reset, enter the RES signal or switch power off, then on again.				
Check point		Check for a short circuit in the PU connector cable. Check that the RS-485 terminals are connected correctly.				
Corrective action	1. Check the F	PU and cable. connection of the RS-48	5 terminals			

Operation Panel Indication	E.P24	E.P.24	FR-PU04 FR-PU07	E.P24		
Name	24VDC power output short circuit					
Description	When the 24VDC power output from the PC terminal is shorted, this function shuts off the power output. At this time, all external contact inputs switch off. The inverter cannot be reset by entering the RES signal. To reset it, use the operation panel or switch power off, then on again.					
Check point	· Check for a short circuit in the PC terminal output.					
Corrective action	· Remedy the	e earth fault portion.				

Operation Panel	E.CDO	8.C d O	FR-PU04	Fault 14		
Indication	E.CDO	C.L.OU	FR-PU07	OC detect level		
Name	Output current detection value exceeded					
Description	This function i	This function is activated when the output current exceeds the Pr. 150 Output current detection level				
Description	setting.					
	Check the settings of Pr. 150 Output current detection level, Pr. 151 Output current detection signal delay time,					
Check point	Pr. 166 Output current detection signal retention time, Pr. 167 Output current detection operation selection.					
	(Refer to	Instruction Manual (applie	ed).)			

Operation Panel	E.IOH	EL OH	FR-PU04	Fault 14		
Indication	E.IOH	כו ער	FR-PU07	Inrush overheat		
Name	Inrush current	limit circuit alarm				
Description	This function is activated when the resistor of the inrush current limit circuit overheats. The inrush current limit circuit failure					
Check point	 Check that frequent ON/OFF is not repeated. Check that no meltdown is found in the primary side fuse (5A) in the power supply circuit of the inrush current suppression circuit contactor (FR-F740-03250 or more) or no fault is found in the power supply circuit of the contactor. 					
Corrective action		Configure a circuit where frequent ON/OFF is not repeated. If the problem still persists after taking the above measure, please contact your sales representative.				



Operation Panel	E.SER	E.5E-	FR-PU04	Fault 14		
Indication	E.SEK	C.3C C	FR-PU07	VFD Comm error		
Name	Communication	Communication error (inverter)				
Description	This function stops the inverter output when communication error occurs consecutively for more than permissible retry count when a value other than "9999" is set in <i>Pr. 335 RS-485 communication retry count</i> during RS-485 communication from the RS-485 terminals. This function also stops the inverter output if communication is broken for the period of time set in <i>Pr. 336 RS-485 communication check time interval</i> .					
Check point	Check the RS-485 terminal wiring.					
Corrective action	Perform wiring	g of the RS-485 terminals	s properly.			

Operation Panel	E.AIE	ERLE	FR-PU04	Fault 14		
Indication			FR-PU07	Analog in error		
Name	Analog input error					
Description	Appears when 30mA or more is input or a voltage (7.5V or more) is input with the terminal 2/4 set to current input.					
Check point	Check the setting of Pr. 73 Analog input selection and Pr. 267 Terminal 4 input selection. (Refer to Instruction Manual (applied).)					
Corrective action	Either give a frequency command by current input or set <i>Pr. 73 Analog input selection</i> or <i>Pr. 267 Terminal 4 input selection</i> to voltage input.					

Operation Panel Indication	E.13	Ε.	13	FR-PU04 FR-PU07	Fault 13	
Name	Internal circuit error					
Description	Appears when an internal circuit error occurred.					
Corrective action	Please contact your sales representative.					

= CAUTION =

- If protective functions of E.ILF, E.PTC, E.PE2, E.CDO, E.IOH, E.SER, E.AIE are activated when using the FR-PU04, "Fault 14"
- $\dot{\text{Also}}$ when the alarm history is checked on the FR-PU04, the display is "E.14".
- · If alarms other than the above appear, contact your sales representative.

REMARKS

For the 01800 or more, you can set Pr. 75 to disable reset operation until the thermal cumulative amount reaches 0 when a thermal trip (THM, THT) or an overcurrent trip (OC1 to OC3) occurs consecutively twice. (Refer to Indiruction Manual (applied).)




5.4 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel.

Actual	Digital
M	[7]
N	
0	
0	
Р	
S	5
T	!
U	<u></u>
V	
r	
-	-
) [-

5.5 Check and clear of the alarm history

(1) Check for the alarm (major fault) history






(2) Clearing procedure

POINT

The alarm history can be cleared by setting "1" in *Er.CL Alarm history clear*. (The alarm history is not cleared when "1" is set in *Pr. 77 Parameter write selection*)



5.6 Check first when you have troubles

POINT

If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then reset the required parameter values and check again.

5.6.1 Motor does not start

- 1) Check the value of Pr. 0 Torque boost setting. (Refer to page
- 2) Check the main circuit.
 - —Check that a proper power supply voltage is applied (operation panel display is provided).
 - —Check that the motor is connected properly.
 - —Check that the jumper across P/+-P1 is connected.

3) Check the input signals

- —Check that the start signal is input.
- —Check that both the forward and reverse rotation start signals are not input simultaneously.
- —Check that the frequency setting signal is not zero. (When the frequency command is 0Hz and the start command is entered, FWD or REV LED on the operation panel flickers.)
- —Check that the AU signal is on when terminal 4 is used for frequency setting signal.
- —Check that the output stop signal (MRS) or reset signal (RES) is not on.
- —Check that the CS signal is not OFF with automatic restart after instantaneous power failure function is selected ($Pr. 57 \neq$ "9999").
- —Check that the sink or source jumper connector is fitted securely. (Refer to page 18.)
- _Check that the voltage/current input switch is correctly set for analog input signal (0 to 5V/0 to 10V, 4 to 20mA).

4) Check the parameter settings

- —Check that Pr. 78 Reverse rotation prevention selection is not selected.
- —Check that the Pr. 79 Operation mode selection setting is correct.
- —Check that the bias and gain (calibration parameter C2 to C7) settings are correct.
- —Check that the Pr. 13 Starting frequency setting is not greater than the running frequency.
- —Check that frequency settings of each running frequency (such as multi-speed operation) are not zero.
- Check that especially the *Pr. 1 Maximum frequency* setting is not zero.
- —Check that the *Pr. 15 Jog frequency* setting is not lower than the *Pr. 13 Starting frequency* setting.

5) Inspection of load

- —Check that the load is not too heavy.
- —Check that the shaft is not locked.

5.6.2 Motor generates abnormal noise

No carrier frequency noises (metallic noises) are generated.

Soft-PWM control to change the motor tone into an unoffending complex tone is factory-set to valid by *Pr.72 PWM frequency selection*.

Adjust Pr.72 PWM frequency selection to change the motor tone.

(When operating the inverter with the carrier frequency of 3kHz or more set in Pr. 72, the carrier frequency will automatically decrease if the output current of the inverter exceeds the value in parenthesis of the rated output current on $page\ 116$. This may cause the motor noise to increase. But it is not a fault.)

- -Check for any mechanical looseness.
- Contact the motor manufacturer.

5.6.3 Motor generates heat abnormally

- —Is the fan for the motor is running? (Check for accumulated dust.)
- —Check that the load is not too heavy. Lighten the load.
- —Check that the inverter output voltages (U, V, W) balanced.
- —Check that the *Pr.0 Torque boost* setting is correct.
- —Was the motor type set? Check the setting of Pr. 71 Applied motor.



5.6.4 Motor rotates in opposite direction

- —Check that the phase sequence of output terminals U, V and W is correct.
- Check that the start signals (forward rotation, reverse rotation) are connected properly. (Refer to page 42)

5.6.5 Speed greatly differs from the setting

- —Check that the frequency setting signal is correct. (Measure the input signal level.)
- —Check that the Pr. 1, Pr. 2, Calibration parameter C2 to C7 settings are correct
- Check that the input signal lines are not affected by external noise.
- (Use shielded cables)
- —Check that the load is not too heavy.
- —Check that the *Pr. 31* to *Pr. 36* (frequency jump) settings are correct.

5.6.6 Acceleration/deceleration is not smooth

- —Check that the acceleration and deceleration time settings are not too short.
- —Check that the load is not too heavy.
- —Check that the torque boost (*Pr. 0, Pr. 46*) setting is not too large and the stall prevention function is not activate.

5.6.7 Motor current is large

- —Check that the load is not too heavy.
- —Check that the *Pr. 0 Torque boost* setting is correct.
- —Check that the *Pr. 3 Base frequency* setting is correct.
- —Check that the *Pr. 14 Load pattern selection* setting is appropriate.
- —Check that the *Pr. 19 Base frequency voltage* setting is correct.

5.6.8 Speed does not increase

- —Check that the Pr. 1 Maximum frequency setting is correct. (If you want to run the motor at 120Hz or more,
 - set Pr. 18 High speed maximum frequency. (Refer to Instruction Manual (applied).))
 - Check that the load is not too heavy.
 - (In agitators, etc., load may become heavier in winter.)
- —Check that the torque boost (*Pr. 0, Pr. 46*) setting is not too large and the stall prevention function is not activate.
- —Check that the brake resistor is not connected to terminals P/+-P1 accidentally.

5.6.9 Speed varies during operation

- 1) Inspection of load
 - Check that the load is not varying.
- 2) Check the input signals
 - —Check that the frequency setting signal is not varying.
 - —Check that the frequency setting signal is not affected by noise.
 - Check for a malfunction due to undesirable currents when the transistor output unit is connected. (Refer to page 19)
- 3) Others
 - Check that the wiring length is not too long for V/F control

5.6.10 Operation mode is not changed properly

1) Inspection of load

Check that the STF or STR signal is off.

When it is on, the operation mode cannot be changed.

2) Parameter setting

—Check the *Pr. 79* setting.

When the $Pr. 79 \ Operation \ mode \ selection$ setting is "0" (initial value), the inverter is placed in the external operation mode at input power-on. At this time, pressing $\frac{PU}{EXT}$ on the operation panel (press PU when the parameter unit (FR-PU04/FR-PU07) is used) switches the mode to the PU operation mode. For other values (1 to 4, 6, 7), the operation mode is limited accordingly.

5.6.11 Operation panel (FR-DU07) display is not operating

—Check that the operation panel is connected to the inverter securely.

5.6.12 POWER lamp is not lit

Check that wiring is securely performed and installation is correct.

5.6.13 Parameter write cannot be performed

—Make sure that operation is not being performed (signal STF or STR is not ON).

-Make sure that you are not attempting to set the parameter in the external operation mode.

—Check Pr. 77 Parameter write selection.

—Check Pr. 161 Frequency setting/key lock operation selection.

6 PRECAUTIONS FOR MAINTENANCE AND INSPECTION

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

Precautions for maintenance and inspection

For some short time after the power is switched off, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched off, and then make sure that the voltage across the main circuit terminals P/+-N/– of the inverter is not more than 30VDC using a tester, etc.

6.1 Inspection item

6.1.1 Daily inspection

Basically, check for the following faults during operation.

- (1) Motor operation fault
- (2) Improper installation environment
- (3) Cooling system fault
- (4) Unusual vibration and noise
- (5) Unusual overheat and discoloration

During operation, check the inverter input voltages using a tester.

6.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

Consult us for periodic inspection.

- 1) Check for cooling system fault......Clean the air filter, etc.
- 2) Tightening check and retighteningThe screws and bolts may become loose due to vibration, temperature changes, etc.

Tighten them according to the specified tightening torque. (Refer to page 12.)

- 3) Check the conductors and insulating materials for corrosion and damage.
- 4) Measure insulation resistance.
- 5) Check and change the cooling fan and relay.

6.1.3 Daily and periodic inspection

<u> </u>	Inspection Item			Inte	erval		က်
Area of Inspection			Inspection Item	Daily	Periodic	Corrective Action at Alarm Occurrence	Customer's Check
		rounding ironment	Check the ambient temperature, humidity, dirt, corrosive gas, oil mist , etc	0		Improve emvironment	
General	Overall unit		Check for unusual vibration and noise	0		Check alarm location and retighten	
		ver supply age	Check that the main circuit voltages and control voltages are normal *1	0		Inspect the power supply	
			(1)Check with megger (across main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer	
	Ger	neral	(2)Check for loose screws and bolts.		0	Retighten	
			(3)Check for overheat traces on the parts.		0	Contact the manufacturer	
			(4)Check for stain		0	Clean	
			(1)Check conductors for distortion.		0	Contact the manufacturer	
	Cor	nductors, cables	(2)Check cable sheaths for breakage and deterioration (crack, discoloration, etc.)		0	Contact the manufacturer	
Main circuit	Tra	nsformer/reactor	Check for unusual odor and abnormal increase in whining sound.	0		Stop the device and contact the manufacturer.	
	Teri	minal block	Check for damage.		0	Stop the device and contact the manufacturer.	
	Sm	oothing	(1)Check for liquid leakage.		0	Contact the manufacturer	
	aluminum electrolytic capacitor		(2)Check for safety valve projection and bulge.		0	Contact the manufacturer	
			(3)Visual check and judge by the life check of the main circuit capacitor (Refer to page 110)		0		
	Relay/contactor		Check that the operation is normal and no chatter is heard.		0	Contact the manufacturer	
	Operation check		(1)Check that the output voltages across phases with the inverter operated alone is balanced		0	Contact the manufacturer	
Control			(2)Check that no fault is found in protective and display circuits in a sequence protective operation test.		0	Contact the manufacturer	
circuit protective	*	Overall	(1)Check for unusual odor and discoloration.		0	Stop the device and contact the manufacturer.	
circuit	check		(2)Check for serious rust development		0	Contact the manufacturer	
	Parts c	Aluminum electrolytic	(1)Check for liquid leakage in a capacitor and deformation trance		0	Contact the manufacturer	
	ш	capacitor	(2)Visual check and judge by the life check of the control circuit capacitor. (Refer to page 110.)		0		
			(1)Check for unusual vibration and noise.	0		Replace the fan	
	Cod	oling fan	(2)Check for loose screws and bolts		0	Retighten	
Cooling			(3)Check for stain		0	Clean	
system	Hes	atsink	(1)Check for clogging		0	Clean	
-)	00		(2)Check for stain		0	Clean	
	Air	filter, etc.	(1)Check for clogging		0	Clean or replace	
		,	(2)Check for stain		0	Clean or replace	
Display	Indi	cation	(1)Check that display is normal. (2)Check for stain	0	0	Contact the manufacturer Clean	
Display	Met	er	Check that reading is normal	0		Stop the device and contact the manufacturer.	
Load motor	Оре	eration check	Check for vibration and abnormal increase in operation noise	0		Stop the device and contact the manufacturer.	
					٠		

^{*1} It is recommended to install a device to monitor voltage for checking the power supply voltage to the inverter.

^{*2} One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.



6.1.4 Display of the life of the inverter parts

The self-diagnostic alarm is output when the life span of the control circuit capacitor, cooling fan, each parts of the inrush current limit circuit is near to give an indication of replacement time .


The life alarm output can be used as a guideline for life judgement.

Parts	Judgement level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated 10% life remaining
Inrush current limit circuit	Estimated 10% life remaining (Power on: 100,000 times left)
Cooling fan	Less than 50% of the predetermined speed

For the life check of the main circuit capacitor, the alarm signal (Y90) will not be output if a measuring method of (2) is not performed. (Refer to page 111.)

(1) Display of the life alarm

· Pr. 255 Life alarm status display can be used to confirm that the control circuit capacitor, main circuit capacitor, cooling fan, and each parts of the inrush current limit circuit has reached the life alarm output level.



Pr. 255	Bit	Inrush Current	Cooling	Main Circuit	Control Circuit
(decimal)	(binary)	Limit Circuit Life	Fan Life	Capacitor Life	Capacitor Life
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	X	X	×	X

 \bigcirc : with alarm, \times : without alarm

POINT

Life check of the main circuit capacitor needs to be done by Pr. 259. (Refer to page 111.)



(2) Measuring method of life of the main circuit capacitor

- · If the value of capacitor capacity measured before shipment is considered as 100%, *Pr. 255* bit1 is turned on when the measured value falls below 85%.
- Measure the capacitor capacity according to the following procedure and check the deterioration level of the capacitor capacity.
- 1) Check that the motor is connected and at a stop.
- 2) Set "1" (measuring start) in Pr. 259
- 3) Switch power off. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is off.
- 4) After confirming that the LED of the operation panel is off, power on again.
- 5) Check that "3" (measuring completion) is set in *Pr. 259*, then read *Pr .255* and check the life of the main circuit capacitor.

REMARKS

- · The life of the main circuit capacitor can not be measured in the following conditions.
 - (a) FR-HC, FR-CV, FR-BU, MT-HC, MT-RC, MT-BU5, or BU is connected.
 - (b) Terminal R1/L11, S1/L21 or DC power supply is connected to the terminals P/+ and N/-.
 - (c) Switch power on during measuring.
 - (d) The motor is not connected to the inverter.
 - (e) The motor is running.(The motor is coasting.)
 - (f) The motor capacity is two rank smaller as compared to the inverter capacity.
 - (g) The inverter is at an alarm stop or an alarm occurred while power is off.
 - (h) The inverter output is shut off with the MRS signal.
 - (i) The start command is given while measuring.
- Operating environment:Ambient temperature (annual average 40°C (free from corrosive gas, flammable gas, oil mist, dust and dirt))

Output current (80% of the rated current of Mitsubishi standard 4P motor)

POINT

For the accurate life measuring of the main circuit capacitor, perform after more than 3h passed since the turn off of the power as it is affected by the capacitor temperature.

6.1.5 Cleaning

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.

CAU	TION

Do not use solvent, such as acetone, benzene, toluene and alcohol, as they will cause the inverter surface paint to peel off. The display, etc. of the operation panel (FR-DU07) and parameter unit (FR-PU04/FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.

6.1.6 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically. Use the life check function as a guidance of parts replacement.

Part Name	Standard Replacement Interval *1	Description
Cooling fan	10 years	Replace (as required.)
Main circuit smoothing capacitor	10 years *2	Replace (as required.)
On-board smoothing capacitor	10 years	Replace the board (as required)
Relays	_	as required.
Fuse (04320 or more)	10 years	Replace the fuse (as required)

^{*}Replacement years for when the yearly average ambient temperature is 40°C (without corrosive gas, flammable gas, oil mist, dust and dirt etc)

CAUTION

For parts replacement, consult the nearest Mitsubishi FA Center.

² Output current : equivalent to rating current of the Mitsubishi standard motor (4 poles)



(1) Cooling fan


The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the ambient temperature. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be replaced immediately.

CAUTION =

For parts replacement, consult the nearest Mitsubishi FA Center.

Inverter Type		Fan Type	Units
	00083, 00126	MMF-06F24ES-RP1 BKO-CA1638H01	1
	00170 to 00380	MMF-08D24ES-RP1 BKO-CA1639H01	2
	00470, 00620	MMF-12D24DS-RP1 BKO-CA1619H01	1
	00770	MMF-09D24TS-RP1 BKO-CA1640H01	2
F740	00930 to 01800	MMF-12D24DS-RP1 BKO-CA1619H01	2
1740	02160 to 03610	WINI - 12D24D3-KF 1 BKO-GA 10191101	3
	04320, 04810		3
	05470 to 06830	9LB1424H5H03	4
	07700, 08660		5
	09620 to 12120	9LB1424S5H04	6

The FR-F740-00023 to 00052 are not provided with a cooling fan.



7


• Reinstallation (00083 to 03610)


1) After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.




<Fan side face>

2) Reconnect the fan connectors.






00470, 00620



3) Reinstall the fan cover.







00083, 00126

00170 to 00620


00770 to 03610

CAUTION

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- When installing the fan, use care to prevent wires from being caught between the inverter and fan.
- Switch the power off before replacing fans. Since the inverter circuits are charged with voltage even after power off, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.




- Removal (04320 or more)
 - 1) Remove a fan cover.
 - 2) After removing a fan connector, remove a fan block.
 - 3) Remove a fan.



* The number of cooling fans differs according to the inverter capacity.

- Reinstallation (04320 or more)
 - 1) After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.



<Fan side face>

2) Install fans referring to the above figure.


CAUTION =

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- When installing the fan, use care to prevent wires from being caught between the inverter and fan.
- Switch the power off before replacing fans. Since the inverter circuits are charged with voltage even after power off, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.

6

(2) Replacement procedure of the cooling fan when using a heatsink protrusion attachment (FR-A7CN)

When replacing a cooling fan, remove a top cover of the heatsink protrusion attachment and perform replacement. After replacing the cooling fan, replace the top cover in the original position.



(3) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc.

The replacement intervals greatly vary with the ambient temperature and operating conditions. When the inverter is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

The appearance criteria for inspection are as follows:

- 1) Case: Check the side and bottom faces for expansion
- 2) Sealing plate: Check for remarkable warp and extreme crack.
- 3) Check for external crack, discoloration, fluid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.



Refer to page 111 to perform the life check of the main circuit capacitor.


(4) Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).


6.1.7 Inverter replacement

The inverter can be replaced with the control circuit wiring kept connected. Before replacement, remove the wiring cover of the inverter.

1) Loosen the two installation screws in both ends of the control circuit terminal block. (These screws cannot be removed.) Pull down the terminal block from behind the control circuit terminals.



2)Using care not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the mounting screws.



_ CAUTION _

Before starting inverter replacement, switch power off, wait for at least 10 minutes, and then check the voltage with a tester and such to ensure safety

SPECIFICATIONS

7.1 Rating

•400V class

SLD is initially set.

Type FR-F740-□□□□□-EC				00023	00038	00052	00083	00126	00170	00250	0031	0 003	80 0	0470	00620	00770	00930	01160
Appli (kW)	ied motor capacity	LE SL		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18	.5	22	30	37	45	55
	Rated capacity (kVA)*2	LE		1.6	2.7	3.7	5.8	8.8	12.2	17.5	22.	1 26	.7 3	2.8	43.4	53.3	64.8	80.8
¥	Doted current (A))	2.1 (1.8)	3.5 (3.0)	4.8 (4.1)	7.6 (6.5)	11.5 (9.8)	16 (13.6)	23 (20)	29 (25	3 (3		43 (37)	57 (48)	70 (60)	85 (72)	106 (90)
Output	Rated current (A)*	SL	_D	2.3 (2.0)	3.8 (3.2)	5.2 (4.4)	8.3 (7.1)	12.6 (10.7)	17 (14.5)	25 (21)	31 (26			47 (40)	62 (53)	77 (65)	93 (79)	116 (99)
	Overload current	LC)				120% (60s, 15	0% 3s	, 50°C	(inver	se tim	e cha	racte	ristics)			
	rating*4	SL	D	110% 60s, 120% 3s, 40°C (inverse time characteristics)														
	Voltage*5			Three-phase 380 to 480V														
	Rated input AC voltage	ge/freque	ncy					Thre	e-phas	se 380	to 480)V 50H	1z/60l	Hz				
ply	Permissible AC volta	ge fluctua	tion	323 to 528V 50Hz/60Hz														
Power supply	Permissible frequen fluctuation	су								±	5%							
) O		thout DC re	eactor	2.1	4.0	4.8	8.0	11.5	16	20	27	3	2	41	52	65	79	99
ш	system capacity (kVA)*6	ith DC read	ctor	1.2	2.6	3.3	5.0	8.1	10	16	19	2	4	31	41	50	61	74
	ective structure 1 1030)*8				Enclosed type (IP20)-7 Open type (IP00)													
Cool	ing system			Se	Self-cooling Forced air cooling													
Appr	ox. mass (kg)			3.5	3.5	3.5	3.5	3.5	6.5	6.5	7.5	5 7.	5	13	13	23	35	35
Ty	ype FR-F740-□□□		;	01800	02160	02600	03250	03610	04320 0	04810 0	5470	06100	06830	07700	08660	0 09620	10940	12120
Appli	ied motor capacity	L	D	75	90	110	132	160	185	220	250	280	315	355	400	450	500	560
(kW)	*1	S	LD	90	110	132	160	185	220	250	280	315	355	400	450	500	560	630
	Rated capacity (kVA	L L	D	110	137	165	198	247	275	329	366	416	464	520	586	659	733	833
-	valed capacity (KVA	S	LD	137	165	198	247	275	329	366	416	464	520	586	659	733	833	923
± [Patad current (A)+a	L	D	144 (122)	180 (153)	216 (184)	260 (221)	325	361	432	481	547	610	683 (580)	770 (654)		962 (817)	1094 (929)
Output	valed current (A) 3	ed current (A)*3					` '	(276)			(408)	(464)	(518)	(000)	(,	(100)	. ,	
		S	LD	180 (153)	216 (184)	260 (221)	325 (276)	, ,	(306)	(367) 481	(408) 547 (464)	610 (518)	683 (580)	770 (654)	866 (736)	962	1094 (929)	1212 (1030)
	Overload current rat	ng*4	D		216 (184)		325 (276) 120%	361 (306) 60s, 15	(306) 432 (367) 50% 3s	(367) 481 (408) s, 50°C	547 (464) (inve	610 (518)	683 (580) ne cha	770 (654) aracte	866 (736)	962 (817)		
C	Overload current rat	ng*4			216 (184)		325 (276) 120%	361 (306) 60s, 15	(306) 432 (367) 50% 3s	(367) 481 (408)	547 (464) (inve	610 (518)	683 (580) ne cha	770 (654) aracte	866 (736)	962 (817)		
	Overload current rat	ng*4	D		216 (184)		325 (276) 120%	361 (306) 60s, 15	(306) 432 (367) 50% 3s 20% 3s	(367) 481 (408) s, 50°C	547 (464) (inve	610 (518) rse tim	683 (580) ne cha	770 (654) aracte	866 (736)	962 (817)		
V		ng*4 L	D LD		216 (184)		325 (276) 120%	361 (306) 60s, 15 60s, 12	(306) 432 (367) 50% 3s 20% 3s Thre	(367) 481 (408) 5, 50°C 6, 40°C	547 (464) (inver (inver se 380	610 (518) rse timese timese to 50	683 (580) ne cha ne cha	770 (654) aracte	866 (736)	962 (817)		
V	/oltage*5 Rated input AC voltage/ Permissible AC voltage	Ing*4 L S	D SLD / n		216 (184)		325 (276) 120%	361 (306) 60s, 15 60s, 12	(306) 432 (367) 50% 3s 20% 3s Thre	(367) 481 (408) 6, 50°C 6, 40°C e-phas	(inverse 380 to 50	610 (518) rse tim rse tim to 500	683 (580) ne cha ne cha ne cha 0V Hz/60	770 (654) aracte	866 (736)	962 (817)		
V R P P	/oltage∗₅ Rated input AC voltage/	Ing*4 L S	D SLD / n		216 (184)		325 (276) 120%	361 (306) 60s, 15 60s, 12	(306) 432 (367) 50% 3s 20% 3s Thre	(367) 481 (408) 5, 50°C 6, 40°C e-phas se 380 to 528	(inverse 380 to 50	610 (518) rse tim rse tim to 500	683 (580) ne cha ne cha ne cha 0V Hz/60	770 (654) aracte	866 (736)	962 (817)		
wer supply	/oltage-5 Rated input AC voltage/ Permissible AC voltage Permissible frequency Power supply Without	Ing*4 L S	D SLD / n		216 (184)		325 (276) 120%	361 (306) 60s, 15 60s, 12	(306) 432 (367) 50% 3s 20% 3s Thre	(367) 481 (408) 5, 50°C 6, 40°C e-phas se 380 to 528	(inverse 380 to 50	610 (518) rse tim rse tim to 500	683 (580) ne cha ne cha ne cha 0V Hz/60	770 (654) aracte	866 (736)	962 (817)		
ower supply	Coltage*5 Rated input AC voltage/ Permissible AC voltage Permissible frequency Power supply System Without	frequency fluctuation fluctuation fluctuation fluctuation the description of the second secon	D SLD / n		216 (184)		325 (276) 120% 110%	361 (306) 60s, 18 60s, 12 Thre	(306) 432 (367) 50% 3s 7hre ee-pha 323	(367) 481 (408) 5, 50°C 6, 40°C e-phas se 380 to 528	(464) (inverse 380 to 50 by 50H	610 (518) rse tim rse tim to 500	683 (580) ne cha ne cha ne cha 0V Hz/60	770 (654) aracte	866 (736) cristics	962 (817)		
Power supply	Coltage*5 Rated input AC voltage/Permissible AC voltage Permissible frequency Power supply system Rapacity With react	frequency fluctuation fluctuat	D SLD / n on	(153)	(184)	-	325 (276) 120% 110%	361 (306) 60s, 15 60s, 12 Three	(306) 432 (367) 50% 3s 70% 3s Three-ee-pha 323	(367) 481 (408) 5, 50°C c., 40°C e-phas se 380 to 528	(464) (inverse 380 to 50 by 50H	610 (518) rse tim to 500 0V 50 Hz/60H	683 (580) ne cha ne cha DV Hz/60 Hz	770 (654) aracte aracte Hz	866 (736) ristics ristics	962 (817)	(929) - 733	(1030)
Power supply Protes	/oltage·5 Rated input AC voltage/ Permissible AC voltage Permissible frequency Power supply system Lapacity With	frequency fluctuation fluctuat	D SLD / n on tor	- 110	(184) - 137	- 165	325 (276) 120% 110%	361 (306) 60s, 15 60s, 12 Thre	(306) 432 (367) 50% 3s 20% 3s Three-pha 323 - 275 329	(367) 481 (408) 5, 50°C c., 40°C e-phas se 380 to 528	(inverse 380 to 50	610 (518) rse tim rse tim to 500 0V 50 Hz/60H	683 (580) ne cha ne ch ne cha ne cha ne cha ne cha ne cha ne cha ne cha ne cha ne cha	770 (654) aracte racte Hz	866 (736) ristics ristics	962 (817)	(929) - 733	- 833
Nower supply by the control of the c	Coltage*5 Rated input AC voltage/Permissible AC voltage Permissible frequency Power supply system capacity kVA)*6 With react	frequency fluctuation fluctuat	D SLD / n on tor	- 110	(184) - 137	- 165	325 (276) 120% 110%	361 (306) 60s, 15 60s, 12 Thre	(306) 432 (367) 50% 3s 7hre ee-pha 323 - 275 329 (600)	(367) 481 (408) 5, 50°C 5, 40°C e-phas se 380 to 528 - 329 3366 4	547 (464) (invertible 380 to 50 to 50 tv 50h tc 5% - 366 416	610 (518) rse tim rse tim rse tim to 500 0V 500 1z/60H - 416 464	683 (580) ne cha ne ch ne cha ne cha ne cha ne cha ne cha ne cha ne cha ne cha ne cha	770 (654) aracte racte Hz	866 (736) ristics ristics	962 (817)	(929) - 733	- 833
Nower supply Cooli	Permissible AC voltage/Permissible AC voltage Permissible frequency Power supply system capacity kVA)*6 With react voltage W	frequency fluctuation fluctuat	D SLD / n on tor	- 110	(184) - 137	- 165	325 (276) 120% 110%	361 (306) 60s, 15 60s, 12 Thre	(306) 432 (367) 50% 3s 7 (368) (367) (367) (368) (367) (368) (36	(367) 481 (408) 5, 50°C 6, 50°C e-phas se 380 to 528 - 329 3 366 4 Open ty	547 (464) (invertible 380 to 50 to 50 tv 50h tc 5% - 366 416	610 (518) rse tim rse tim rse tim to 500 0V 500 1z/60H - 416 464	683 (580) ne cha ne ch ne cha ne cha ne cha ne cha ne cha ne cha ne cha ne cha ne cha	770 (654) aracte racte Hz	866 (736) ristics ristics	962 (817))) - - - - - - - - - - - - - - - - -	(929) - 733	- 833

The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.

The rated output capacity indicated assumes that the output voltage is 440V.

When operating the inverter with the carrier frequency set to 3kHz or more, the carrier frequency automatically decreases if the inverter output current exceeds the value in parenthesis of the rated current. This may cause the motor noise to increase.

The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.

The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range.

^{*5}

However, the pulse voltage value of the inverter output side voltage remains unchanged at about $\sqrt{2}$ that of the power supply. The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables). When the hook of the inverter front cover is cut off for installation of the plug-in option, the inverter changes to an open type (IP00).

FR-DU07: IP40 (except for the PU connector)

7.2 Common specifications

				High carrier frequency PWM control (V/F control)/optimum excitation control/simple						
	Cor	ntrol metho	od	magnetic flux vector control						
	Out	tout freque	ency range	0.5 to 400Hz						
		-	mey range	0.015Hz/0 to 60Hz (terminal 2, 4: 0 to 10V/12bit)						
	sett	quency	Analog input	0.03Hz/0 to 60Hz (terminal 2, 4: 0 to 5V/11bit, 0 to 20mA/11bit, terminal 1: 0 to ±10V/12bit)						
SI		olution		0.06Hz/0 to 60Hz (terminal 1: 0 to ±5V/11bit)						
I i			Digital input	0.01Hz						
Ę		quency	Analog input	Within ±0.2% of the max. output frequency (25°C ± 10°C)						
eci		uracy	Digital input	Within 0.01% of the set output frequency						
lsp		tage/frequ racteristic	•	0 to 400Hz of the base frequency can be set from constant torque/adjustable 5 points V/F can be selected.						
Control specifications		rting torqu		120% (3Hz) when simple magnetic flux vector control and slip compensation are set						
ည်			deceleration	0 to 3600s (acceleration and deceleration can be set individually), linear or S-pattern						
		e setting	2000101411011	acceleration/deceleration mode can be selected.						
		injection b	orake	Operation frequency (0 to 120Hz), operation time (0 to 10s), operation voltage (0 to 30%) variable						
				Operation current level can be set (0 to 150% variable), whether to use the function or not						
	Stal	I preventior	operation level	can be set.						
	Fre sett	quency	Analog input	Terminal 2, 4: 0 to 10V, 0 to 5V, 4 to 20mA can be selected Terminal 1: -10 to +10V, -5 to 5V can be selected						
	sigr		Digital input	Four-digit BCD or16-bit binary using the setting dial of the operation panel or parameter unit (when used with the option FR-A7AX)						
	Sta	rt signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.						
	Input signals			You can select any twelve signals using <i>Pr.178 to Pr.189 (input terminal function selection)</i> from among multi speed selection, second function selection, terminal 4 input selection, JOG operation selection, selection of automatic restart after instantaneous power failure, external thermal relay input, HC connection (inverter operation enable signal), HC connection (instantaneous power failure detection), PU operation/external interlock signal, External DC injection brake operation start, PID control enable terminal, PU operation, external operation switchover, output stop, start self-holding selection, traverse function selection, forward rotation command, reverse rotation command, inverter reset, PTC thermistor input, PID forward reverse operation switchover, PU-NET operation switchover, External-NET operation switchover, command source switchover.						
cifications	Operational functions			Maximum and minimum frequency settings, frequency jump operation, external thermal relay input selection, polarity reversible operation, automatic restart after instantaneous power failure operation, original operation continuation at an instantaneous power failure, commercial power supply-inverter switchover operation, forward/reverse rotation prevention, operation mode selection, external DC injection braking start, PID control, computer link operation (RS-485).						
Operation specifications	Output signals	Operating status		You can select any seven signals using <i>Pr.190 to Pr.196 (output terminal function selection)</i> from among inverter running, up-to-speed, instantaneous power failure /undervoltage, overload warning, output frequency detection, second output frequency detection, regenerative brake prealarm·4, electronic thermal relay function pre-alarm, PU operation mode, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward rotation reverse rotation output, bypass operation-inverter switchover MC1 to MC3, commercial power supply side motor 1 to 4 connection, inverter side motor 1 to 4 connection, fan fault output, heatsink overheat pre-alarm, inverter running start command on, deceleration at an instantaneous power failure, PID control activated, during retry, during PID output suspension, life alarm, alarm output 3 (power-off signal), power savings average value update timing, current average monitor, alarm output 2, maintenance timer alarm, remote output, minor failure output, alarm output, traverse function. Open collector output (5 points), relay output (2 points) and alarm code of the inverter can be output (4 bit) from the open collector.						
	Out		When used with the FR-A7AY, FR-A7AR (option)	You can select any seven signals using <i>Pr.313 to Pr. 319 (extension output terminal function selection)</i> from among control circuit capacitor life, main circuit capacitor life, cooling fan life, inrush current limit circuit life. (Only positive logic can be set for extension terminals of the FR-A7AR)						
	Pulse/analog		alog output	Selection can be made from output frequency, motor current (steady or peak value), output voltage, frequency setting value, running speed, converter output voltage (steady or peak value), electronic thermal relay function load factor, input power, output power, load meter, reference voltage output, motor load factor, power saving effect, regenerative brake duty-4, PID set value, PID measured value using <i>Pr.54 CA terminal function selection (pulse train output)</i> and <i>Pr.158 AM terminal function selection (analog output)</i> .						



Dieplay	PU (FR-DU07/ FR-PU04/	Operating status	Output frequency, motor current (steady or peak value), output voltage, alarm indication, frequency setting, running speed, converter output voltage (steady or peak value), electronic thermal relay function load factor, input power, output power, load meter, cumulative energization time, actual operation time, motor load factor, cumulative power, power saving effect, cumulative saving power, regenerative brake duty-4,PID set point, PID measured value, PID deviation value, inverter I/O terminal monitor, input terminal option monitor-1, output terminal option monitor-1, option fitting status monitor-2, terminal assignment status-2					
	FR-PU07)	Alarm definition	Alarm definition is displayed during the protective function is activated, output voltage/current/frequency/cumulative energization time and eight past alarm definition is stored.					
		Interactive guidance	Operation guide/trouble shooting with a help function +2					
F	Protective/warni		Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, instantaneous power failure occurrence, undervoltage, input phase failure, motor overload, output side earth fault overcurrent, output phase failure, external thermal relay operation, PTC thermistor operation, option alarm, parameter error, PU disconnection, retry count excess, CPU alarm, operation panel power supply short circuit, 24VDC power output short circuit, output current detection value excess, inrush current limit circuit alarm, communication alarm (inverter), analog input error, internal circuit error (15V power supply), fan fault, overcurrent stall prevention, overvoltage stall prevention, electronic thermal relay function prealarm, PU stop, maintenance timer alarm-1, brake transistor alarm detection -4, parameter write error, copy operation error, operation panel lock, parameter copy					
	Ambient	LD	-10°C to +50°C (non-freezing)					
- Lovinoumout	1	SLD (initial setting)	-10°C to +40°C (non-freezing)					
2	Ambient hun	nidity	90%RH or less (non-condensing)					
	Storage tem	oerature∗₃	-20°C to +65°C					
٤	Atmosphere		Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)					
	Altitude, vibr	ation	Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (92%) 5.9m/s ² or less *5					


^{*1} Can be displayed only on the operation panel (FR-DU07).
*2 Can be displayed only on the parameter unit (FR-PU04/FR-PU07).
*3 Temperature applicable for a short period in transit, etc.
*4 Only the 01800 or more functions.

^{*5} 2.9m/s² or less for the 04320 or more.


7.3 Outline dimension drawings

7.3.1 Inverter outline dimension drawings

• FR-F740-00023, 00038, 00052, 00083, 00126-EC




• FR-F740-00170, 00250, 00310, 00380-EC




$\sqrt{}$


• FR-F740-00470, 00620-EC




• FR-F740-00770, 00930, 01160-EC



• FR-F740-01800-EC




• DC reactor supplied



DC reactor Type	W	W1	н	H1	D	Mass (kg)
FR-HEL-H90K (FR-F740-01800-EC)	150	130	340	310	190	20




• FR-F740-02160, 02600, 03250, 03610-EC




Inverter Type	Н	H1	D
FR-F740-02160, 02600-EC	595	620	300
FR-F740-03250, 03610-EC	715	740	360

• DC reactor supplied




DC reactor Type	w	W1	Н	H1	D	S	S1	Mass (kg)
FR-HEL-H110K(FR-F740-02160-EC)	150	130	340	310	195	M6	M6	22
FR-HEL-H132K(FR-F740-02600-EC)	175	150	405	370	200	M8	M6	26
FR-HEL-H160K(FR-F740-03250-EC)	175	150	405	370	205	M8	M6	28
FR-HEL-H185K(FR-F740-03610-EC)	175	150	405	370	240	M8	M6	29

• FR-F740-04320, 04810-EC



• DC reactor supplied





* Remove the eye nut after installation of the product.

DC reactor Type	W	W1	Н	H1	D	S	S1	S2	ф	Mass (kg)
FR-HEL-H220K (FR-F740-04320-EC)	175	150	405	370	240	M8	M6	M6	M12	30
FR-HEL-H250K (FR-F740-04810-EC)	190	165	440	400	250	M8	M8	M8	M12	35




• FR-F740-05470, 06100, 06830-EC






• DC reactor supplied




* Remove the eye nut after installation of the product.

DC reactor Type	W	W1	Н	H1	D	S	S1	S2	ф	Mass (kg)
FR-HEL-H280K (FR-F740-05470-EC)	190	165	440	400	255	M8	M8	M8	M16	38
FR-HEL-H315K (FR-F740-06100-EC)	210	185	495	450	250	M10	M8	M8	M16	42
FR-HEL-H355K (FR-F740-06830-EC)	210	185	495	450	250	M10	M8	M8	M16	46

• FR-F740-07700, 08660-EC






* Remove the eye nut after installation of the product.


DC reactor Type	Mass (kg)
FR-HEL-H400K (FR-F740-07700-EC)	50
FR-HEL-H450K (FR-F740-08660-EC)	57




• FR-F740-09620, 10940, 12120-EC



• DC reactor supplied




* Remove the eye nut after installation of the product.




DC reactor Type	н	D	D1	Mass (kg)
FR-HEL-H500K (FR-F740-09620-EC)	345	455	405	67
FR-HEL-H560K (FR-F740-10940-EC)	360	460	410	85
FR-HEL-H630K (FR-F740-12120-EC)	360	460	410	95


• Operation panel (FR-DU07)



• Parameter unit (option) (FR-PU07)



Parameter unit (option) (FR-PU04)





7.4 Heatsink protrusion attachment procedure

When encasing the inverter in an enclosure, the generated heat amount in an enclosure can be greatly reduced by installing the heatsink portion of the inverter outside the enclosure. When installing the inverter in a compact enclosure, etc., this installation method is recommended.


7.4.1 When using a heatsink protrusion attachment (FR-A7CN)

For the FR-F740-00023 to 03610, a heatsink can be protruded outside the enclosure using a heatsink protrusion attachment (FR-A7CN). For a panel cut dimension drawing and an installation procedure of the heatsink protrusion attachment (FR-A7CN) to the inverter, refer to a manual of "heatsink protrusion attachment (FR-A7CN01 to 11)".

7.4.2 Protrusion of heatsink of the FR-F740-04320 or more

(1) Panel cutting

Cut the panel of the enclosure according to the inverter capacity.




(2) Shift and removal of a rear side installation frame


• FR-F740-05470 to 06830

One installation frame is attached to each of the upper and lower part of the inverter. Change the position of the rear side installation frame on the upper and lower side of the inverter to the front side as shown on the right. When changing the installation frames, make sure that the installation orientation is correct.

• FR-F740-04320/04810, 07700 or more

Two installation frames each are attached to the upper and lower parts of the inverter. Remove the rear side installation frame on the upper and lower side of the inverter as shown on the right.









(3) Installation of the inverter

Push the inverter heatsink portion outside the enclosure and fix the enclosure and inverter with upper and lower installation frame.



* For the FR-F740-05470 or more, there are finger guards behind the enclosure. Therefore, the thickness of the panel should be less than 10mm(*1) and also do not place anything around finger guards to avoid contact with the finger guards.



Inverter Type	D1(mm)
FR-F740-04320, 04810	185
FR-F740-05470 to 12120	184

CAUTION

- · Having a cooling fan, the cooling section which comes out of the enclosure can not be used in the environment of water drops, oil, mist, dust, etc.
- · Be careful not to drop screws, dust etc. into the inverter and cooling fan section.

APPENDICES

Appendix 1 For customers who have replaced the older model with this inverter


Appendix 1-1 Replacement of the FR-F500 series

(1) Instructions for installation

- 1)Removal procedure of the front cover was changed. (with screws) Please note. (Refer to page 4.)
- 2)Removal procedure of the operation panel was changed. (with screws) Please note. (Refer to page 4.)
- 3)Plug-in options of the F500 series are not compatible
- 4)Operation panel (FR-DU04) can not be used.
- 5)Setup software (FR-SW0-SETUP) can not be used.

(2) Wiring instructions

1)The control circuit terminal block can be used for the FR-F700 series without removing wiring. Note that the wiring cover (00023 to 00470) is not compatible.



(Note that the relay output 2 (A2, B2, C2) specific for the FR-F700 series can not be used with the FR-F500 series terminals.)

(3) Instructions for continuous use of the FR-PU04 (parameter unit)

- 1)For the FR-F700 series, many functions (parameters) have been added. When setting these parameters, the parameter name and setting range are not displayed. Parameter list, change list, initial value list, initial value list 2 and parameter clear of the HELP function can not be used.
- 2) For the FR-F700 series, many protective functions have been added. These functions activate, but all alarms are displayed as "Fault 14". When the alarm history has been checked, "E.14" appears. Added alarm display will not appear on the parameter unit.
- 3) User initial value setting can not be used.
- 4) User registration/clear (user group 2) can not be used.
- 5) Parameter copy/verification function can not be used.

(4) Main differences and compatibilities with the FR-F500(L) series

Item	FR-F500(L)	FR-F700				
	Simple mode parameters 61	Simple mode parameters 15				
	Pr. 0 Torque boost initial value 00250 to 01160:2%	Pr. 0 Torque boost initial value initial value 00250 to 00770: 2%, 00930, 01160: 1.5% (When the torque boost value of the FR-F500 series used was the initial value, it is not necessary to change the torque boost value from the initial value when replacing with the FR-F700 series.)				
	User group 1 (16), user group 2 (16) (Pr. 160, Pr. 173 to Pr. 175)	User group (16) only Setting methods were partially changed (Pr. 160, Pr. 172 to Pr. 173)				
Changed/cleared functions	User initial value setting (Pr. 199)	"User initial value setting" (Pr. 199) was cleared Substitutable with the copy function of the operation panel (FR-DU07)				
	Intelligent optimum acceleration/deceleration (Pr. 60 setting "3" and Pr. 61 to Pr. 63)	Function was cleared For deceleration time, overvoltage alarm can be avoided with regeneration avoidance function (Pr. 882 to Pr. 885).				
	Automatic torque boost (Pr. 38, Pr. 39)	Automatic torque boost was cleared because of addition of "Simple magnetic flux vector" (Pr. 80)				
	Advanced PID (pump function) Pr. 500 to Pr. 516	Parameter number change Pr. 575 to Pr. 591				
Terminal block	Removable terminal block	Removable terminal block Upward compatibility (Terminal block of the F500 can be mounted)				
PU	FR-PU04, DU04	FR-PU07 FR-DU07 FR-DU04 unavailable (Partly restricted when the FR-PU04 is used. <i>Refer to page 131</i> .)				
	Dedicated plug-in o	option (not compatible)				
Plug-in option	Computer link, relay output option FR-A5NR	Built into the inverter (RS-485 terminal, relay output 2 points)				
	Three boards can be mounted	One board can be mounted				
Installation size		0 to 01160 are compatible in mounting dimensions npatibility attachment (FR-AAT) is necessary.				

Appendix 1-2 Replacement of the FR-A100 <EXCELENT> series

Instructions for installation

• When using the installation holes of the FR-A100(E) series, FR-A5AT (intercompatibility attachment) is necessary.

Appendix 2 Instructions for UL and cUL Compliance

(Conforming standard UL 508C, CSA C22.2 No.14)

(1) Installation

This inverter is a UL / cUL Listed, enclosed type device with a suitably rated enclosure.

Design an enclosure so that the inverter ambient temperature, humidity and atmosphere satisfy the specifications. (*Refer to page 117.*)

Wiring protection

For installation in the United States, branch circuit protection must be provided in accordance with the National Electrical Code and any applicable provincial codes.

For installation in Canada, branch circuit protection must be provided in accordance with the Canadian Electrical Code and any applicable provincial codes.

Provide the appropriate UL and cUL listed Class RK5, Class T or Class L type fuse or UL489 molded case circuit breaker (MCCB) that is suitable for branch circuit protection in accordance with the table below.

FR-F74	0-000-EC	00023	00038	00052	00083	00126	00170	00250	00310	00380	00470	00620	00770	00930	01160
Rated fuse voltage(V)								480V o	r more	!					
Maximum	Without power factor improving reactor	6	10	15	20	30	40	70	80	90	110	150	175	200	250
allowable rating (A)*	With power factor improving reactor	6	10	10	15	25	35	60	70	90	100	125	150	175	200
Molded case circuit breaker (MCCB) Maximum allowable rating (A)*		15	15	15	20	30	40	60	70	90	100	150	175	225	250

FR-F74	0-000-EC	01800	02160	02600	03250	03610	04320	04810	05470	06100	06830	07700	08660	09620	10940	12120
Rated fuse	voltage(V)	500V or more														
Fuse Maximum	Without power factor improving reactor						_								_	_
allowable rating (A)*	With power factor improving reactor	300	350	400	500	600	700	800	900	1000	1100	1200	1350	1500	1800	2000
Molded case circuit breaker (MCCB) Maximum allowable rating (A)*		450	500	600	800	900	1000	1200	1200	1200	1600	1600	2000	2000	2500	3000

Maximum allowable rating by US National Electrical Code at SLD rating.
 Exact size must be chosen for each installation.

(2) Wiring of the power supply and motor

For wiring the input (R/L1, S/L2, T/L3) and output (U, V, W) terminals of the inverter, use the UL Listed copper, stranded wires (rated at 75°C) and round crimping terminals. Crimp the crimping terminals with the crimping tool recommended by the terminal maker.

(3) Short circuit ratings


- Model 01160 or less
 - Suitable For Use in A Circuit Capable Of Delivering Not More Than 100kA rms Symmetrical Amperes, 528V Maximum.
- Model 01800 or more
 - Suitable For Use in A Circuit Capable Of Delivering Not More Than 100kA rms Symmetrical Amperes, 550V Maximum.

(4) Motor overload protection

This inverter is certified as a motor overload protection device by UL.

When using the electronic thermal relay function as motor overload protection, set the rated motor current to Pr. 9 Electronic thermal O/L relay.

Electronic thermal relay function operation characteristic



This function detects the overload (overheat) of the motor, stops the operation of the inverter's output transistor, and stops the output. (The operation characteristic is shown on the left)

- When using the Mitsubishi constant-torque motor
 - 1) Set "1" in Pr. 71. (This provides a 100% continuous torque characteristic in the low-speed range.)
 - 2) Set the rated current of the motor in Pr. 9.
- When a value 50% of the inverter rated output current (current value) is set in Pr. 9
- The % value denotes the percentage to the inverter rated output current. It is not the percentage to the motor rated current.
- When you set the electronic thermal relay function dedicated to the Mitsubishi constant-torque motor, this characteristic curve applies to operation at 6Hz or higher.

= CAUTION

- Protective function by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-off.
- When multiple motors are operated by a single inverter, protection cannot be provided by the electronic thermal relay function.
- Install an external thermal relay to each motor.

 When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- A special motor cannot be protected by the electronic thermal relay function. Use the external thermal relay.

Appendix 3 Instructions for Compliance with the European Directives

(1) EMC Directive

We have self-confirmed our inverters as products compliant to the EMC Directive (second environment of conforming standard EN61800-3) and place the CE mark on the inverters.

Note: First environment

Environment including residential buildings. Includes buildings directly connected without a transformer to the low voltage power supply network which supplies power to residential buildings.

Second environment

Environment including all buildings except buildings directly connected without a transformer to the low voltage power supply network which supplies power to residential buildings.

1) Notes

Install the inverter and perform wiring according to the following instructions.


- * The inverter is equipped with a built-in EMC filter. Set the EMC filter valid (initial setting). For details, refer to page 8.
- * Connect the inverter to an earthed power supply.
- * Install a motor and a control cable written in the EMC Installation Manual (BCN-A21041-204) according to the instruction.
- * The cable length between the inverter and the motor is 5 m maximum.
- * Confirm that the inverter complies with the EMC Directive as the industrial drives application for final installation.

(2) Low Voltage Directive

We have self-confirmed our inverters as products compliant to the Low Voltage Directive (Conforming standard EN 50178) and place the CE mark on the inverters.

1)Outline of instructions

- * Do not use an earth leakage current breaker as an electric shock protector without connecting the equipment to the earth. Connect the equipment to the earth securely.
- * Wire the earth terminal independently. (Do not connect two or more cables to one terminal.)
- * Use the cable sizes on page 12 under the following conditions.
 - Ambient temperature: 40°C maximum
 - If conditions are different from above, select appropriate wire according to EN60204 Appendix C TABLE 5.
- * Use a tinned (plating should not include zinc) crimping terminal to connect the earth cable. When tightening the screw, be careful not to damage the threads.
 - For use as a product compliant with the Low Voltage Directive, use PVC cable whose size is indicated on page 12.
- * Use the moulded case circuit breaker and magnetic contactor which conform to the EN or IEC Standard.
- * When using an earth leakage current breaker, use a residual current operated protective device (RCD) of type B (breaker which can detect both AC and DC). If not, provide double or reinforced insulation between the inverter and other equipment, or put a transformer between the main power supply and inverter.
- * Use the inverter under the conditions of overvoltage category II (usable regardless of the earth condition of the power supply), overvoltage category III (usable with the earthed-neutral system power supply, 400V class only) and pollution degree 2 or lower specified in IEC664.
 - To use the inverter of 00770 or more (IP00) under the conditions of pollution degree 2, install it in the enclosure of IP 2X or higher.
 - To use the inverter under the conditions of pollution degree 3, install it in the enclosure of IP54 or higher.
 - To use the inverter of 00620 or less (IP20) outside of an enclosure in the environment of pollution degree 2, fix a fan cover with fan cover fixing screws enclosed.



- * On the input and output of the inverter, use cables of the type and size set forth in EN60204 Appendix C.
- * The operating capacity of the relay outputs (terminal symbols A1, B1, C1, A2, B2, C2) should be 30VDC, 0.3A. (Relay outputs are basically isolated from the inverter internal circuit.)
- * Control circuit terminals on page 7 are safely isolated from the main circuit.
- Environment

	During Operation	In Storage	During Transportation
Ambient temperature	LD: -10°C to +50°C SLD (initial setting): -10°C to +40°C	-20°C to +65°C	-20°C to +65°C
Ambient humidity	90% RH or less	90% RH or less	90% RH or less
Maximum altitude	1000m	1000m	10000m

Details are given in the technical information "Low Voltage Directive Conformance Guide" (BCN-A21041-203). Please contact your sales representative.

MEMO

D: (5)	*	<u> </u>
Print Date	*Manual Number	Revision
May, 2004	IB(NA)-0600192ENG-A	First edition
Aug., 2004	IB(NA)-0600192ENG-B	Additions FR-F740 - 02600 to 03610 - EC Pr.299 Rotation direction detection selection at restarting
Oct., 2004	IB(NA)-0600192ENG-C	Additions FR-F740 - 04320 to 12120 - EC
Jun., 2005	IB(NA)-0600192ENG-D	Partial modification Additions Panel cut dimension of heatsink protrusion
Sep, 2006	IB(NA)-0600192ENG-E	Additions Pr. 539 Modbus-RTU communication check time interval Voltage/current input switch

A For Maximum Safety

- Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised
 to install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the
 product are likely to cause a serious accident.
- Please do not use this product for loads other than three-phase induction motors.